




Ref No	Part No	Description
01	1TF-11102-01-00	Cylinder Head Assy
02	93440-14086-00	• . Circlip
03	4X7-11133-10-00	• . Guide, Intake Valve
04	4X7-11127-00-00	Absorber 3
05	91800-06030-00	Pin, Dowel
06	42H-11181-00-00	Gasket, Cylinder Head 1
07	4X7-11363-01-00	Bolt, Cylinder Holding 3
08	90116-12469-00	Bolt, Stud
09	90116-10344-00	Bolt, Stud
10	90179-12326-00	Nut
11	90201-125A3-00	Washer, Plate
12	90179-12325-00	Nut
13	90176-10075-00	Nut, Crown
14	90201-102G9-00	Washer, Plate
15	91314-08050-00	Bolt
16	95617-08640-00	Bolt, Stud
17	42X-11185-01-00	Cover, Cylinder Head Side 1
18	91314-06016-00	Bolt
19	42X-11152-00-00	Bracket, Cylinder Head Cover
20	90202-05208-00	Washer, Plate
21	42X-1111H-01-00	Cover, Cylinder Head Side 4
22	42X-11165-00-00	Plate, Breather
23	42X-11166-01-00	Pipe, Breather 1
24	90467-14015-00	Clip
25	93210-92448-00	O-ring
26	91314-06025-00	Bolt
27	42H-11186-01-00	Cover, Cylinder Head Side 2
28	4X7-11187-00-00	Cover, Cylinder Head Side 3
29	93210-62446-00	O-ring
30	91314-06016-00	Bolt
31	4X7-1111F-00-00	Plate
32	97017-08020-00	Bolt
33	90401-16065-00	Bolt, Union
34	90430-17168-00	Gasket
35	1RM-1112E-00-00	Cover, Cylinder Head 3
36	90480-23444-00	Grommet
37	91317-06010-00	Bolt
38	94701-00218-00	Plug, Spark (ngk Bpr7es)
38	94701-00220-00	Plug, Spark (nd W22epr-u)

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1TA-11310-00-00	Cylinder
02	93211-01467-00	O-ring
03	4X7-11161-00-00	Absorber 1
04	90387-087A5-00	Collar
05	91314-06040-00	Bolt
06	3EG-11351-00-00	Gasket, Cylinder
07	4X7-12215-00-00	Cap, Tensioner Case
08	4DW-12213-00-00	Gasket, Tensioner Case
09	91314-06025-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1TA-11411-00-00	Crankshaft
02	93306-30808-00	Bearing
03	4X7-13354-00-00	Sprocket, Drive
04	93306-30808-00	Bearing
05	1TA-11631-00-A0	Piston (std)
05	1TA-11636-00-00	Piston (0.50mm O/s)
05	1TA-11638-00-00	Piston (1.00mm O/s)
06	1TA-11610-00-00	Piston Ring Set (std)
06	1TA-11610-20-00	Piston Ring Set (0.50mm Ug)
06	1TA-11610-40-00	Piston Ring Set (1.00mm Ug)
07	5A8-11633-00-00	Pin, Piston
08	93450-24028-00	Circlip
09	5A8-11650-00-00	Connecting Rod Assy
10	4X7-11654-01-00	• . Bolt, Connecting Rod
11	90179-09379-00	• . Nut
12	5A8-11660-00-00	Connecting Rod Assy
13	4X7-11654-01-00	• . Bolt, Connecting Rod
14	90179-09379-00	• . Nut
15	4X7-11656-00-00	Plane Bearing, Connecting Rod
15	4X7-11656-10-00	Plane Bearing, Connecting Rod
15	4X7-11656-20-00	Plane Bearing, Connecting Rod
15	4X7-11656-30-00	Plane Bearing, Connecting Rod
15	4X7-11656-40-00	Plane Bearing, Connecting Rod
16	90280-16053-00	Key, Woodruff
17	90201-165H4-00	Washer, Plate
18	90179-16448-00	Nut
19	5G5-11656-00-00	Plane Bearing, Connecting Rod
19	5G5-11656-10-00	Plane Bearing, Connecting Rod
19	5G5-11656-20-00	Plane Bearing, Connecting Rod

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2J2-12111-01-00	Valve, Intake
02	5A8-12121-00-00	Valve, Exhaust
03	4X7-12116-00-00	Seat, Valve Spring
04	1TA-12113-00-00	Spring, Valve Inner
05	1TA-12114-00-00	Spring, Valve Outer
06	341-12119-02-00	Seal, Valve Stem
07	4X7-12117-00-00	Retainer, Valve Spring
08	4X7-12118-00-00	Cotter, Valve
09	42X-12151-00-00	Arm, Valve Rocker
10	4X7-12156-01-00	Shaft, Rocker 2
11	4X7-12159-00-00	Screw, Valve Adjusting
12	90170-08173-00	Nut

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4X7-11536-00-00	Gear, Drive (35z)
02	4X7-11534-00-00	Gear, Breaker Drive (35z)
03	90501-21133-00	Spring, Compression
04	93605-10090-00	Pin, Dowel
05	4X7-11540-02-00	Cam Chain Sprocket Assy 1 20/50z
06	4X7-11550-01-00	Cam Chain Sprocket Assy 2 20/50z
07	4X7-12247-01-00	Shaft, Tensioner
08	90209-06205-00	Washer
09	90105-06154-00	Bolt, Washer Based
10	42H-12171-00-00	Camshaft 1
11	42H-12181-00-00	Camshaft 2
12	42H-11145-00-00	Plate, Breather 2
13	90201-10774-00	Washer, Plate
14	90101-10303-00	Bolt
15	90380-25125-00	Bush, Solid
16	94590-45098-00	Chain
17	4X7-12176-00-00	Sprocket, Cam Chain (28z)
18	93604-10011-00	Pin, Dowel
19	4X7-12210-01-00	Tensioner Assy, Cam Chain
20	90338-06121-00	• . Plug
21	4X7-12231-00-00	Guide, Stopper 1
22	4X7-12241-00-00	Guide, Stopper 2
23	4X7-12221-00-00	Guide, Stopper 3
24	90109-08592-00	Bolt
25	95307-08700-00	Nut
26	92907-06600-00	Washer, Plate
27	91314-06025-00	Bolt
28	4DW-12213-00-00	Gasket, Tensioner Case

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	10L-13300-00-00	Oil Pump Assy
02	99510-08016-00	Pin, Dowel
03	93210-07438-00	O-ring
04	91317-06040-00	Bolt
05	4X7-13355-00-00	Sprocket, Driven (35z)
06	90105-06154-00	Bolt, Washer Based
07	10L-13327-00-00	Cover, Pump Gear
08	91317-06010-00	Bolt
09	94580-25066-00	Chain
10	4X7-13171-00-00	Pipe, Delivery 2
11	93210-07438-00	O-ring
12	91317-06010-00	Bolt
13	4X7-13405-00-00	Oil Pipe Comp. 1
14	4X7-15485-01-00	Clamp
15	4X7-15484-00-00	Clamp 2
16	90468-05113-00	Clip
17	1RM-13406-00-00	Oil Pipe Comp. 2
18	90401-16067-00	Bolt, Union
19	90430-17168-00	Gasket
20	90401-10102-00	Bolt, Union
21	90430-15169-00	Gasket
22	4X7-15485-01-00	Clamp
23	90468-05113-00	Clip
24	3JL-13455-00-00	Plug
25	214-11198-01-00	Gasket


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



5E3171-1070


Ref No	Part No	Description
01	4X7-13440-90-00	Element Assy, Oil Cleaner
02	93210-56459-00	O-ring
03	93210-54452-00	O-ring
04	1RM-13447-00-00	Cover, Oil Element
05	93210-07135-00	O-ring
06	90109-06667-00	Bolt
07	91314-06020-00	Bolt
08	91314-06050-00	Bolt
09	11H-13490-00-00	Relief Valve Assy
10	93210-10096-00	O-ring
11	90462-10098-00	Clamp

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1TA-13586-00-00	Joint, Carburetor 1
02	16G-13569-00-00	Plug, Blind
03	90467-10039-00	Clip
04	24M-13586-01-00	Joint, Carburetor 1
05	3CG-13542-00-00	Hose, Vacuum Sensing 1
06	90467-08092-00	Clip
07	42X-13564-01-00	Cover, Manifold
08	42X-13578-00-00	Washer
09	42X-13544-00-00	Hose, Vacuum Sensing 2
10	90467-08092-00	Clip
11	1TA-13595-00-00	Joint
12	42H-13532-00-00	Hose, Vacuum Sensing 3
13	90467-07093-00	Clip
14	93210-44545-00	O-ring
15	97027-06020-00	Bolt
16	92907-06600-00	Washer, Plate
17	16G-13569-00-00	Plug, Blind
18	90467-10039-00	Clip
19	2CG-14197-00-00	Pipe
20	3CG-14987-00-00	Hose
21	90467-14057-00	Clip
22	3CG-14396-00-00	Pipe
23	42H-13907-00-00	Fuel Pump Comp.
24	42H-13971-00-00	Pipe, Fuel 1
25	1TA-14349-00-00	Pipe
26	1TA-14348-00-00	Pipe 1
27	90413-07023-00	Way 3
28	90467-10091-00	Clip
29	90460-12256-00	Clamp, Hose
30	10L-14453-01-00	Joint, Air Cleaner 1
31	10L-14407-00-00	Cover, Joint
32	90460-65196-00	Clamp, Hose
33	90501-100F8-00	Spring, Compression
34	42X-14401-01-00	Air Cleaner Case Assy
35	92907-04600-00	Washer
36	42X-14477-00-00	Plate
37	97707-40112-00	Screw, Tapping
38	42X-14451-00-00	Element, Air Cleaner
39	1RM-14422-00-00	Cap, Cleaner Case 2
40	42X-14452-00-00	Seal
41	1TA-1441A-00-00	Cover, Cleaner Case 1
42	97707-50508-00	Screw, Tapping
43	98507-05012-00	Screw, Pan Head
44	92907-05600-00	Washer, Plate
45	98507-06080-00	Screw, Pan Head
46	98508-06050-00	Screw, Pan Head
47	92907-06600-00	Washer, Plate
48	1TA-1441E-00-00	Cover, Cleaner Case 2
49	97707-50508-00	Screw, Tapping
50	90387-07598-00	Collar
51	91317-06030-00	Bolt
52	92907-06200-00	Washer
53	91317-06012-00	Bolt
54	42X-14485-00-00	Pipe, Joint

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
55	90460-65195-00	Clamp, Hose
56	42X-14663-02-00	Plate, Air Cleaner
57	91317-06090-00	Bolt
58	92907-06200-00	Washer
59	42X-14484-00-00	Plate, Cleaner Case Fitting
60	95807-06025-00	Bolt, Flange
61	1RM-14603-00-00	Cover 1
62	1TA-1441K-00-00	Emblem
63	90480-14074-00	Grommet
64	95807-06014-00	Bolt, Flange
65	12R-14484-01-00	Plate, Cleaner Case Fitting
66	91317-06035-00	Bolt
67	92907-06200-00	Washer

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3LP-14900-01-00	Carburetor Assy
02	3LP-14901-01-00	• . Carburetor Assy 1
03	3LP-14902-01-00	• . Carburetor Assy 2
04	3CF-14984-01-00	•• .. Gasket, Float Chamber
05	3CF-14107-15-00	•• .. Needle Valve Set
06	3CN-1490J-00-00	•• .. Needle Set
07	3CF-14940-00-00	•• .. Diaphragm Assy
08	3CF-14933-00-00	•• .. Spring, Diaphragm
09	12R-14105-00-00	•• .. Pilot Screw Set
10	537-14186-00-00	•• .. Pin, Float
11	2VA-14185-00-00	•• .. Float
12	137-14153-00-00	•• .. Washer, Main Jet
13	620-14231-25-A0	•• .. Jet, Main (125)
13	620-1423A-75-00	•• .. Jet, Main (122.5)
14	3CF-14141-93-00	•• .. Nozzle, Main
15	4G0-14142-40-00	•• .. Jet, Pilot (40)
16	3G2-14231-12-00	•• .. Jet, Main (60)
17	98507-05010-00	•• .. Screw, Pan Head
18	98507-04008-00	•• .. Screw, Pan Head
19	3CF-1490H-00-00	•• .. Diaphragm Set 5
20	1HX-14231-28-00	•• .. Jet, Main (140)
21	3CF-1410A-00-00	•• .. Starter Set
22	98507-05016-00	•• .. Screw, Pan Head
23	92990-05100-00	•• .. Washer, Spring
24	12R-14191-00-00	•• .. Plug, Drain
25	2JU-14397-00-00	•• .. O-ring
26	22F-14991-00-00	•• .. Screw
27	2CF-14251-00-00	• . Nipple
28	3CF-14937-00-00	• . Clip
29	3CG-14197-00-00	• . Pipe
30	98507-05012-00	• . Screw, Pan Head
31	3CF-1490K-00-00	• . Stop Screw Set
32	3CF-14919-00-00	• . Clip
33	3CF-14103-01-00	• . Throttle Screw Set
34	98507-05014-00	• . Screw, Pan Head
35	3CF-14197-00-00	• . Pipe

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	42H-14611-00-00	Pipe, Exhaust 1
02	3EG-14714-00-00	Gasket, Muffler
03	1TA-14621-00-00	Pipe, Exhaust 2
04	2TN-14711-01-00	Muffler 1
05	3YF-14755-00-00	Gasket, Silencer
06	95027-08045-00	Bolt, Flange
07	95027-08045-00	Bolt, Flange
08	42X-14748-01-00	Protector, Muffler 4
09	4BD-14766-00-00	Washer, Protector
10	98904-06010-00	Screw, Bind
11	42X-1479H-00-00	Cover, 1
12	92907-06200-00	Washer
13	57A-14612-01-00	Nut, Ring
14	42X-1468A-00-00	Ring, Silencer 1
15	90179-08210-00	Nut
16	90179-08507-00	Nut
17	3EG-14613-00-00	Gasket, Exhaust Pipe
18	90101-06576-00	Bolt
19	90101-06576-00	Bolt
20	92907-06600-00	Washer, Plate
21	92907-06600-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	42H-15100-02-00	Crankcase Assy
02	99510-14016-00	• . Pin, Dowel
03	95617-10620-00	Bolt, Stud
04	95617-10620-00	Bolt, Stud
05	95617-10670-00	Bolt, Stud
06	93210-07438-00	O-ring
07	93210-07135-00	O-ring
08	90387-064E8-00	Collar
09	91317-10100-00	Bolt
10	91317-10070-00	Bolt
11	91317-10060-00	Bolt
12	91317-06080-00	Bolt
13	91317-06055-00	Bolt
14	91317-06030-00	Bolt
15	91314-06030-00	Bolt
16	90430-06014-00	Gasket
17	57A-15363-11-00	Plug, Oil
18	93210-29198-00	O-ring
19	90465-10168-00	Clamp
20	4X7-15491-00-00	Protector
21	4X7-13419-00-00	Plug
22	90480-20302-00	Grommet
23	42X-21164-00-00	Holder, Cable
24	90105-10275-00	Bolt, Washer Based

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1RM-15411-01-00	Cover, Crankcase 1
02	4X7-15361-00-00	Gauge, Level
03	2H7-15361-00-00	Gauge, Level
04	90465-08309-00	Clamp
05	98507-06010-00	Screw, Pan Head
06	3EG-15451-00-00	Gasket, Crankcase Cover 1
07	99530-10014-00	Pin, Dowel
08	91314-06040-00	Bolt
09	91314-06030-00	Bolt
10	91314-06020-00	Bolt
11	1L9-11186-00-00	Cover, Cylinder Head Side 2
12	93210-32172-00	O-ring
13	90462-08076-00	Clamp
14	1RM-15415-01-00	Cover, Generator
15	1RM-15455-00-00	Gasket 1
16	3JK-15425-00-00	Cover, Generator 2
17	98704-06016-00	Screw, Flat Head
18	98707-06014-00	Screw, Flat Head
19	42X-15417-01-00	Cover, Cap
20	91314-06055-00	Bolt
21	91314-06016-00	Bolt
22	1RM-15419-00-00	Cover, Shifter 1
23	3EG-15459-00-00	Gasket, Shifter Cover
24	91314-06016-00	Bolt
25	3CG-15429-00-00	Cover, Shifter
26	98507-06030-00	Screw, Pan Head
27	91314-06065-00	Bolt
28	42X-15441-00-00	Holder, Clutch Cable
29	3JK-W1542-01-00	Cover, Crankcase 3
30	93101-14102-00	Oil Seal
31	4X7-15388-00-00	Plate, Bearing Cover
32	91317-06016-00	Bolt
33	3EG-15462-00-00	Gasket, Crankcase Cover 3
34	99530-10020-00	Pin, Dowel
35	91314-06040-00	Bolt
36	91314-06025-00	Bolt
37	91380-06030-00	Bolt
38	90462-10143-00	Clamp
39	90462-10085-00	Clamp
40	90462-12142-00	Clamp
41	1RM-13161-00-00	Pipe, Delivery 1
42	93210-07438-00	O-ring
43	90110-06093-00	Bolt, Hexagon Socket Head

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3LP-15570-00-00	Starter Clutch Assy
02	99009-13400-00	Circlip
03	4X7-15521-00-00	Shaft 1
04	93210-14104-00	O-ring
05	3LP-15524-10-00	Wheel, Starter (23z)
06	1TA-15512-00-00	Gear, Idler 1
07	3LP-15517-10-00	Gear, Idler 2 (27z)
08	90387-172E5-00	Collar
09	90501-15636-00	Spring, Compression
10	90387-170E5-00	Collar
11	5A8-15550-00-00	Drive Lever Assy
12	93102-10247-00	Oil Seal
13	5A8-15542-01-00	Collar 2
14	90151-06013-00	Screw, Countersunk
15	5A8-15556-00-00	Lever, Drive
16	90508-26494-00	Spring, Torsion
17	90149-08166-00	Screw
18	3EG-15568-00-00	Gasket
19	95707-06500-00	Nut, Flange
20	90387-0801M-00	Collar

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4X7-16111-00-00	Gear, Primary Drive (47z)
02	90282-07042-00	Key, Straight
03	90214-20022-00	Washer, Claw
04	90215-20182-00	Washer, Lock
05	90170-20274-00	Nut
06	2H7-16396-00-00	Housing, Push Screw
07	93606-07082-00	Pin, Dowel
08	2H7-16395-01-00	Retainer, Ball
09	2H7-16341-00-00	Screw, Push
10	2H7-16343-00-00	Screw, Adjusting
11	93210-48364-00	O-ring
12	4X7-16340-00-00	Push Lever Assy
13	92907-08200-00	Washer
14	95307-08700-00	Nut
15	90506-10069-00	Spring, Tension
16	93104-14059-00	Oil Seal
17	4X7-16357-00-00	Rod, Push 2
18	4X7-16356-00-00	Rod, Push 1
19	93340-21505-00	Bearing
20	90201-154E9-00	Washer, Plate
21	4X7-16150-02-00	Primary Driven Gear Comp.
22	3Y1-16371-00-00	Boss, Clutch
23	1TA-16371-00-00	Boss, Clutch
24	4X7-16384-00-00	Plate, Seat
25	4X7-16383-01-00	Spring, Clutch Boss
26	4X7-16324-00-00	Plate, Clutch 1
27	4X7-16385-00-00	Ring, Clutch Boss
28	22U-16321-00-00	Plate, Friction
29	1TA-16325-00-00	Plate, Clutch 2
30	1TA-16351-00-00	Plate, Pressure 1
31	1TA-16334-00-00	Spring, Clutch 2
32	97017-06025-00	Bolt
33	1TA-16335-00-00	Housing, Spring
34	1TA-16352-00-00	Plate, Pressure 2
35	90215-20231-00	Washer, Lock
36	90170-20327-00	Nut

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1TA-17411-00-00	Axle, Main
02	4X7-17141-00-00	Gear, 4th Pinion (31z)
03	90209-22191-00	Washer
04	93410-25010-00	Circlip
05	4X7-17121-00-00	Gear, 2nd Pinion (24z/28z)
06	42X-17151-00-00	Gear, 5th Pinion (34z)
07	90201-20276-00	Washer, Plate (1.00)
08	99009-20400-00	Circlip
09	93306-30525-00	Bearing (b6305)
10	93104-20068-00	Oil Seal
11	93306-30424-00	Bearing (b6304a3)
12	4X7-17402-00-00	Drive Axle Assy
13	4X7-17221-00-00	Gear, 2nd Wheel (40z)
14	90209-27192-00	Washer
15	93440-30077-00	Circlip
16	42X-17251-00-00	Gear, 5th Wheel (29z)
17	4X7-17231-00-00	Gear, 3rd Wheel (36z)
18	90209-27192-00	Washer
19	93440-30077-00	Circlip
20	4X7-17241-00-00	Gear, 4th Wheel (32z)
21	1TA-17211-00-00	Gear, 1st Wheel
22	23W-17582-00-00	Gear, Middle Drive
23	93306-20421-00	Bearing (b6204)
24	93306-20550-00	Bearing (b6205du8)
25	23W-17583-00-00	Gear, Middle Driven
26	93316-01201-00	Bearing (b16012)
27	93306-91201-00	Bearing (b6912)

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1TA-Y1757-00-00	Middle Gear Comp.
02	93306-20901-00	Bearing (b6209rsh2-c2)
03	90179-44328-00	Nut
04	42X-17526-01-00	Cam, Drive
05	31A-17527-00-00	Cam, Driven
06	90501-70762-00	Spring, Compression
07	4X7-17524-00-00	Holder
08	3H5-17529-00-00	Washer, Thrust
09	4X7-17531-00-11	Shim, Pinion (0.15t)
09	4X7-17531-00-30	Shim, Pinion (0.30t)
09	4X7-17531-00-50	Shim, Pinion (0.50t)
10	90179-88336-00	Nut
11	93317-22210-00	Bearing
12	93311-44051-00	Bearing
13	90201-255A6-00	Washer, Plate
14	1J7-46129-Y1-00	Spacer, Expansion
15	11H-17551-00-00	Housing, Bearing
16	93210-71360-00	O-ring
17	93306-20548-00	Bearing (b620rc2)
18	4X7-17554-00-00	Retainer, Bearing
19	93210-52449-00	O-ring
20	93101-35099-00	Oil Seal
21	4X7-17558-00-00	Plate, Bearing
22	4X7-17556-00-00	Yoke, Joint
23	93210-14359-00	O-ring
24	90201-14633-00	Washer, Plate
25	90179-14317-00	Nut
26	90387-251E1-00	Collar
27	95827-08030-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4X7-18540-01-00	Shift Cam Assy
02	93306-90602-00	• . Bearing
03	4G0-18185-01-00	• . Segment
04	93604-20156-00	• . Pin, Dowel
05	93604-16092-00	• . Pin, Dowel
06	98701-05035-00	• . Screw, Flat Head
07	136-18542-00-00	• . Point, Neutral
08	90201-30297-00	• . Washer, Plate
09	4X7-18511-00-00	Fork, Shift 1
10	4X7-18512-00-00	Fork, Shift 2
11	4X7-18513-00-00	Fork, Shift 3
12	4X7-18531-00-00	Bar, Shift Fork Guide 1
13	4X7-18536-00-00	Stopper, Shift Bar
14	98707-06016-00	Screw, Flat Head

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	4X7-18120-01-00	Shift Lever Assy
02	90506-08227-00	• . Spring, Tension
03	4X7-18140-00-00	Stopper Lever Assy
04	90508-32535-00	Spring, Torsion
05	99006-10600-00	Circlip
06	90508-29531-00	Spring, Torsion
07	90201-12588-00	Washer, Plate
08	90387-124F4-00	Collar
09	90201-12588-00	Washer, Plate
10	90201-12166-00	Washer, Plate
11	93102-12106-00	Oil Seal
12	42X-18110-01-00	Shift Pedal Assy
13	2H9-18154-00-00	• . Cover, Dust
14	132-18113-01-00	• . Cover, Shift Pedal
15	90201-124E4-00	Washer, Plate
16	99009-12400-00	Circlip
17	42X-18112-01-00	Arm, Shift
18	2H9-18154-00-00	• . Cover, Dust
19	97024-06020-00	Bolt
20	29L-18115-00-00	Rod, Shift
21	90170-06228-00	Nut (verkehtheit Schraube)
22	95304-06700-00	Nut
23	93608-50158-00	Pin, Dowel


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



3LP7332-4190


Ref No	Part No	Description
01	3LP-21110-00-33	Frame Comp.
02	42X-21317-00-00	Stay, Engine 3
03	42X-21359-00-00	Bracket, Coil
04	98517-06012-00	Screw, Pan Head
05	92907-06100-00	Washer, Spring
06	92907-06600-00	Washer, Plate
07	90105-10297-00	Bolt, Washer Based
08	90176-10075-00	Nut, Crown
09	90179-12248-00	Nut
10	90201-125A3-00	Washer, Plate
11	42X-21315-01-00	Stay, Engine 2
12	42X-21316-01-00	Stay, Engine 3
13	90105-10298-00	Bolt, Washer Based
14	90201-105H3-00	Washer, Plate
15	90387-100E2-00	Collar
16	4X7-21485-00-00	Damper, Rubber 1
17	90105-10050-00	Bolt, Washer Based
18	90105-10300-00	Bolt, Washer Based
19	42X-21458-01-00	Bracket, Side Stand
20	90176-10075-00	Nut, Crown
21	90105-06069-00	Bolt, Washer Based
22	90202-05187-00	Washer, Plate
23	90338-07043-00	Plug
24	90462-08138-00	Clamp
25	97707-50508-00	Screw, Tapping
26	2AE-2139R-00-00	Cover 2
27	90159-06058-00	Screw, With Washer
29	134-23484-10-00	Cap, Handle Lock
30	90269-04003-00	Rivet
31	90208-04029-00	Washer, Conical Spring

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1MY-21510-00-P2	Front Fender Comp.
01	1MY-Y2151-40-5Y	Front Fender Comp.
02	4PW-21570-00-00	• . Graphic Set, Front Fender
03	97027-06012-00	Bolt
04	92907-06100-00	Washer, Spring
05	3EF-21610-00-P0	Rear Fender Comp.
05	3EF-Y2161-80-JW	Rear Fender C0mp.
06	4PW-21675-00-00	• . Graphic, Rear Fender
07	99236-00080-00	Emblem, Yamaha
08	97027-06012-00	Bolt
09	92907-06100-00	Washer, Spring
10	97027-08012-00	Bolt
11	92907-08100-00	Washer, Spring
12	1RM-2164F-00-00	Stay 1
13	1RM-2164G-00-00	Stay 2
14	3JK-2164H-00-00	Stay 3
15	3JK-2164J-00-00	Stay 4
16	1AE-2164A-00-00	Grip 1
17	95817-06016-00	Bolt, Flange
18	95827-06016-00	Bolt, Flange
19	90149-08225-00	Screw
20	90105-10217-00	Bolt, Washer Based
21	42X-21629-00-00	Guard, Mud
22	90159-06128-00	Screw, With Washer
23	26H-21308-00-00	Helmet Hanger Assy
24	90149-06154-00	Screw
25	3EF-21621-00-00	Flap
26	2AE-21641-00-00	Bracket, Reflector
27	90267-40076-00	Rivet, Blind
28	90201-04018-00	Washer, Plate
29	98507-06012-00	Screw, Pan Head
30	92907-06600-00	Washer, Plate
31	90202-05187-00	Washer, Plate
32	95317-06600-00	Nut
33	92907-06200-00	Washer
34	4G0-21639-00-00	Damper 2

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	42X-21711-00-P2	Cover, Side 1
01	42X-21711-00-JW	Cover, Side 1
02	42X-21781-00-00	Emblem 1
02	99237-00080-00	Emblem, Yamaha
03	90480-01401-00	Grommet
04	466-21717-00-00	Damper
05	42X-21721-00-P2	Cover, Side 2
05	42X-21721-00-JW	Cover, Side 2
06	42X-21782-00-00	Emblem 2
06	99237-00080-00	Emblem, Yamaha
07	90480-01401-00	Grommet
08	90480-12053-00	Grommet
09	42X-21171-00-00	Box
10	90480-20384-00	Grommet
11	90480-16233-00	Grommet
12	90387-060A7-00	Collar
13	90201-06765-00	Washer, Plate
14	97007-06020-00	Bolt
15	92907-06100-00	Washer, Spring
16	42X-28185-00-00	Lid
17	42X-2172W-02-00	Cover
18	98507-06010-00	Screw, Pan Head
19	92907-06100-00	Washer, Spring
20	42X-2176E-00-00	Plate
21	90159-06110-00	Screw, With Washer
22	42X-2117F-00-00	Cover
23	90159-06071-00	Screw, With Washer

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	1RM-22110-00-35	Rear Arm Comp.
02	93332-00010-00	Bearing
03	90387-17543-00	Collar
04	93120-25017-00	Oil Seal
05	42X-22141-00-00	Shaft, Pivot
06	90215-22238-00	Washer, Lock
07	1J7-22141-00-00	Shaft, Pivot
08	1J7-22143-00-00	Nut
09	2H7-2219X-00-00	Cover
10	95024-08035-00	Bolt, Flange
11	4X7-22189-01-00	Boot, Rubber
12	90338-20113-00	Plug
13	3JK-22210-01-00	Shock Absorber Assy, Rear
14	3JK-22220-01-00	Shock Absorber Assy, Rear
15	57A-22243-01-00	Washer 1
16	91317-08020-00	Bolt
17	90338-08163-00	Plug
18	90201-105R9-00	Washer, Plate
19	90176-10073-00	Nut, Crown
20	92990-10100-00	Washer, Spring
21	90106-10052-00	Bolt


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



1TE130-6230


Ref No	Part No	Description
01	56W-46101-02-00	Rear Axle Gear Case Assy
02	90116-10361-00	• . Bolt, Stud
03	90116-08360-00	• . Bolt, Stud
04	90116-10249-00	• . Bolt, Stud
05	4H7-46153-00-00	• . Collar, Guide
06	93101-30084-00	• . Oil Seal
07	93311-43729-00	• . Bearing
08	93317-41510-00	• . Bearing
09	2H7-46122-00-00	• . Race, Inner
10	1J7-17537-Y0-30	• . Shim, Thrust (0.30t)
10	1J7-17537-Y0-40	• . Shim, Thrust (0.40t)
10	1J7-17537-Y0-50	• . Shim, Thrust (0.50t)
11	93306-30533-00	• . Bearing
12	4H7-46125-00-00	• . Retainer, Bearing
13	93210-60426-00	• . O-ring
14	93101-38098-00	• . Oil Seal
15	4H7-46123-01-00	• . Coupling, Gear
16	90201-14632-00	• . Washer, Plate
17	90185-14070-00	• . Nut, Self-locking
18	4H7-46152-00-00	• . Housing, Bearing
19	1J7-46117-Y0-30	• . Shim, Ring Gear (0.30t)
19	1J7-46117-Y0-40	• . Shim, Ring Gear (0.40t)
19	1J7-46117-Y0-50	• . Shim, Ring Gear (0.50t)
20	93316-01403-00	• . Bearing
21	22U-46118-00-12	• . Washer, Thrust (1.2t)
21	22U-46118-00-14	• . Washer, Thrust (1.4t)
21	22U-46118-00-16	• . Washer, Thrust (1.6t)
21	22U-46118-00-18	• . Washer, Thrust (1.8t)
21	22U-46118-00-20	• . Washer, Thrust (2.0t)
22	93211-44348-00	• . O-ring
23	95333-08600-00	• . Nut
24	92901-08700-00	• . Washer, Wave
25	95811-10025-00	• . Bolt, Flange
26	93120-70167-00	• . Oil Seal
27	90340-14130-00	• . Plug, Straight Screw
28	214-11198-01-00	• . Gasket
29	56W-17590-00-00	• . Breather Comp.
30	90340-14118-00	• . Plug, Straight Screw
31	4X7-46172-00-00	Shaft, Drive
32	93108-23007-00	Oil Seal
33	90201-231A2-00	Washer, Plate
34	93410-23056-00	Circlip
35	93410-22039-00	Circlip
36	90501-16491-00	Spring, Compression
37	4X7-46180-00-00	Cross Joint Comp.
38	93399-99926-00	Bearing
39	93440-20088-00	Circlip
40	90176-10075-00	Nut, Crown
41	92990-10100-00	Washer, Spring
42	90387-172A5-00	Collar

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	93332-00001-00	Bearing
02	93332-00008-00	Bearing
03	1J7-23415-00-00	Cover, Ball Race 1
04	90179-25033-00	Nut
05	90202-26142-00	Washer, Plate
06	26H-23418-01-00	Washer, Special
07	90176-22050-00	Nut, Crown
08	42X-W2341-01-38	Crown, Handle
09	95024-08045-00	Bolt, Flange
10	92990-08100-00	Washer, Spring
11	92990-08600-00	Washer, Plate
12	1UF-23317-01-00	Holder, Cable
13	4H7-23441-00-38	Holder, Handle Upper
14	42X-23442-00-38	Holder, Handle Lower
15	90201-100A1-00	Washer, Plate
16	92907-10100-00	Washer, Spring
17	95307-10700-00	Nut
18	90468-12006-00	Clip
19	91314-08030-00	Bolt
20	90338-08163-00	Plug
21	1RM-23122-00-00	Cover, Outer 1
22	1RM-2317E-00-00	Stay
23	92014-06012-00	Bolt, Button Head
24	90338-08163-00	Plug
25	42X-2313A-00-00	Brace, Fork
26	95024-08020-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3LP-23102-30-00	Front Fork Assy (l.h)
02	3LP-23126-30-00	• . Tube, Outer (left)
03	3R4-23153-00-00	• . Ring, Snap
04	3EN-23145-00-00	• . Oil Seal
05	2YK-23125-00-00	• . Metal, Slide 1
06	4V2-23146-L0-00	• . Washer, Oil Seal
07	3EN-23144-00-00	• . Seal, Dust
08	1RM-23110-00-00	• . Inner Tube Comp.1
09	33M-23170-00-00	• . Cylinder Comp., Front Fork
10	1W1-23173-L0-00	• . Spindle, Taper
11	42H-23141-00-00	• . Spring, Front Fork
12	4FY-23149-00-00	• . Washer, Spring Upper
13	1W1-23114-L0-00	• . Gasket
14	509-23158-L0-00	• . Gasket
15	31A-23111-31-00	• . Bolt, Cap
16	42H-23168-00-00	• . Cap, Front Fork
17	278-23181-50-00	• . Bolt, Hexagon Socket Head
18	42X-23118-00-00	• . Spacer
19	3LP-23103-30-00	Front Fork Assy (r.h)
20	3LP-23136-30-00	• . Tube, Outer (right)
21	3R4-23153-00-00	• . Ring, Snap
22	3EN-23145-00-00	• . Oil Seal
23	2YK-23125-00-00	• . Metal, Slide 1
24	4V2-23146-L0-00	• . Washer, Oil Seal
25	3EN-23144-00-00	• . Seal, Dust
26	1RM-23110-00-00	• . Inner Tube Comp.1
27	33M-23170-00-00	• . Cylinder Comp., Front Fork
28	1W1-23173-L0-00	• . Spindle, Taper
29	42H-23141-00-00	• . Spring, Front Fork
30	4FY-23149-00-00	• . Washer, Spring Upper
31	1W1-23114-L0-00	• . Gasket
32	509-23158-L0-00	• . Gasket
33	31A-23111-31-00	• . Bolt, Cap
34	42H-23168-00-00	• . Cap, Front Fork
35	278-23181-50-00	• . Bolt, Hexagon Socket Head
36	97313-08045-00	• . Bolt
37	95333-08600-00	• . Nut
38	92990-08100-00	• . Washer, Spring
39	42X-23118-00-00	• . Spacer
40	2AE-23340-30-00	Under Bracket Comp.
41	91311-08030-00	Bolt
42	1RM-23132-00-00	Cover, Outer 2
43	1RM-23132-10-00	Cover, Outer 2
44	98580-05006-00	Screw, Pan Head

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3DR-24110-00-05	Fuel Tank Comp.
01	3DR-24110-00-07	Fuel Tank Comp.
02	3JK-24240-50-00	• . Graphic Set
02	4PW-24240-00-00	• . Graphic Set
03	1RM-24161-10-00	Emblem 1
03	4PW-24161-00-00	• . Emblem 1
04	1RM-24162-10-00	Emblem 2
04	4PW-24162-00-00	Emblem 2
05	4H7-24181-00-00	Damper, Locating 1
06	42X-24182-00-00	Damper, Locating 2
07	42X-24183-00-00	Damper, Locating 3
08	97007-08016-00	Bolt
09	42X-24186-00-00	Washer, Special
10	42X-24280-00-00	Tank, Fuel
11	91317-06020-00	Bolt
12	90201-06059-00	Washer, Plate
13	90387-062L2-00	Collar
14	90480-13163-00	Grommet
15	90560-06258-00	Spacer
16	90480-10408-00	Grommet
17	42H-24316-00-00	Pipe 6
18	90460-16192-00	Clamp, Hose
19	42H-24317-00-00	Pipe 7
20	90467-11044-00	Clip
21	90467-10135-00	Clip
22	4X7-24602-04-00	Cap Assy
23	4X7-24612-00-00	• . Gasket, Cap
24	91317-05010-00	Bolt
25	1FK-24560-00-00	Filter Assy
26	42H-24311-00-00	Pipe, Fuel 1
27	90467-10135-00	Clip
28	90467-11044-00	Clip
29	42H-24315-00-00	Pipe 5
30	90501-102A2-00	Spring, Compression
31	90467-11044-00	Clip
32	90467-10135-00	Clip
33	90465-08256-00	Clamp
34	98507-06010-00	Screw, Pan Head
35	92907-06100-00	Washer, Spring
36	42H-24452-00-00	Cover
37	3JK-23491-00-00	Joint
38	97007-06012-00	Bolt
39	92907-06100-00	Washer, Spring
40	98507-06012-00	Screw, Pan Head
41	92907-06100-00	Washer, Spring
42	92907-06600-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3CF-24730-10-00	Double Seat Assy
02	3CF-24731-10-00	• . Cover, Seat
03	509-24724-00-00	• . Damper, Seat
04	1L9-24741-00-00	• . Pad, Seat
05	91317-06016-00	Bolt
06	90110-06077-00	Bolt, Hexagon Socket Head
07	42X-2473R-00-00	Box 1
08	90480-24186-00	Grommet
09	90201-225A4-00	Washer, Plate (1.0d)
10	5A8-21708-00-00	Lock Assy 2
11	42X-2473T-00-00	Lid 1
12	3CF-24723-00-00	Damper, Seat
13	42X-2177K-00-00	Pin, Hinge
14	1RM-2162G-00-00	Plate 1
15	90176-06041-00	Nut, Crown
16	97017-06016-00	Bolt
17	92907-06100-00	Washer, Spring
18	90201-06057-00	Washer, Plate
19	5H9-21376-00-00	Band, Tool
20	47G-85150-00-00	Panel, Side
21	90183-05003-00	Nut, Spring
22	42X-28100-10-00	Tool Kit

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3LP-25111-00-35	Hub, Front
02	90560-15116-00	Spacer
03	93306-30202-00	Bearing
04	93102-22014-00	Oil Seal
05	56W-2312A-00-00	Boot Comp. (l)
06	56W-2312A-10-00	Boot Comp. (r)
07	90110-06091-00	Bolt, Hexagon Socket Head
08	90338-06162-00	Plug
09	94421-19526-00	Rim (2.15-19)
10	3LP-25104-00-00	Spoke Set, Front
11	94110-1904N-00	Tire (100/90-19 57h)
11	94110-1904P-00	Tire (100/90-19 57h)
12	93900-00030-00	Valve, Rim
13	3LP-25398-00-00	Balancer, Wheel
13	3LP-25398-10-00	Balancer, Wheel
13	3LP-25398-20-00	Balancer, Wheel
14	90387-15550-00	Collar
15	42X-25181-00-00	Axle, Wheel
16	42X-25190-00-00	Gear Unit Assy

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3LP-2582T-00-00	Disc, Brake
02	90109-08718-00	Bolt
03	3LP-2582U-00-00	Disc, Brake (right)
04	3LP-2516A-00-00	Damper
05	3LP-2580U-00-00	Caliper Assy (right)
06	3YX-W0057-50-00	• . Piston Assy, Caliper
07	3YX-W0047-50-00	•• .. Caliper Seal Kit
08	5R2-25397-00-00	• . Spoke Set, Outer 2
09	3YX-25397-00-00	• . Spoke Set, Outer 2
10	3LP-W0045-00-00	• . Brake Pad Kit
11	3YX-25919-00-00	• . Support, Pad
12	3YX-25929-00-00	• . Spring, Anti Rattle
13	51L-W0048-00-00	• . Bleed Screw Kit
14	4DN-25827-00-00	• . Shim, Caliper
15	3LP-2580T-00-00	Caliper Assy (left)
16	3YX-W0057-50-00	• . Piston Assy, Caliper
17	3YX-W0047-50-00	•• .. Caliper Seal Kit
18	5R2-25937-00-00	• . Boot 2
19	3YX-25937-00-00	• . Boot 2
20	3LP-W0045-00-00	• . Brake Pad Kit
21	3YX-25919-00-00	• . Support, Pad
22	3YX-25929-00-00	• . Spring, Anti Rattle
23	51L-W0048-00-00	• . Bleed Screw Kit
24	4DN-25827-00-00	• . Shim, Caliper
25	3LP-23317-00-00	Holder, Cable
26	90105-10638-00	Bolt, Washer Based

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3LP-25311-00-35	Hub, Rear
02	90560-17249-00	Spacer
03	146-25315-00-00	Flange, Spacer
04	93306-30309-00	Bearing
05	93306-20310-00	Bearing (b6203du)
06	93306-20310-00	Bearing (b6203du)
07	16G-25366-01-00	Clutch, Hub
08	42H-25364-00-00	Damper
09	93210-48530-00	O-ring
10	93210-59531-00	O-ring
11	16G-25412-00-00	Washer
12	90170-10219-00	Nut
13	93210-57428-00	O-ring
14	42H-25321-02-00	Plate, Brake Shoe
15	3DR-W2536-00-00	Brake Shoe Set
16	90507-20002-00	Spring, Tension
17	4H7-25351-00-00	Camshaft
18	3CF-25355-00-00	Lever, Camshaft
19	90201-14218-00	Washer, Plate
20	4H7-2533A-02-00	Plate, Indicator
21	90101-06764-00	Bolt
22	94430-15525-00	Rim
23	3LP-25304-00-00	Spoke Set, Rear
24	94114-1504R-00	Tire (140/90-15 70h)
24	94114-1504S-00	Tire (140/90-15 70h)
25	93900-00016-00	Valve, Rim
26	3LP-25398-00-00	Balancer, Wheel
26	3LP-25398-10-00	Balancer, Wheel
26	3LP-25398-20-00	Balancer, Wheel
27	42X-25381-00-00	Axle, Wheel
28	90201-146R0-00	Washer, Plate
29	90171-14029-00	Nut, Castle
30	4E7-25188-00-00	Cap
31	91401-30030-00	Pin, Cotter
32	4H7-25377-00-00	Collar, Wheel
33	42X-25371-01-00	Bar, Tension
34	90109-08406-00	Bolt
35	92990-08600-00	Washer, Plate
36	92990-08100-00	Washer, Spring
37	95304-08700-00	Nut
38	91490-20020-00	Pin, Cotter
39	90109-08368-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3CF-W2611-10-00	Handlebar
02	3JB-26241-00-00	Grip (left)
03	3JB-26273-00-00	Rotor
04	3JB-26240-00-00	Grip Assy
05	3JB-2628J-00-00	Cap, Grip
06	3CF-26311-00-00	Cable, Throttle 1
07	3CF-26312-00-00	Cable, Throttle 2
08	5H0-26393-00-00	Holder
09	98507-05008-00	Screw, Pan Head
10	57A-26335-00-00	Cable, Clutch
11	1E6-26342-00-00	Boot, Cable
12	90179-08148-00	Nut
13	90123-08046-00	Bolt
14	3CF-26331-01-00	Cable, Starter 1
15	1J7-26290-F0-00	Rear View Mirror Assy(right) (l)
16	1J7-26290-G0-00	Rear View Mirror Assy(right)

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	22R-25850-02-00	Master Cylinder Assy
02	4K0-25854-00-00	• . Diaphragm, Reservoir
03	3GM-25852-01-00	• . Cap, Reservoir
04	98707-04012-00	• . Screw, Flat Head
05	4K0-W0041-50-00	• . Cylinder Kit, Master
06	4L0-25867-00-00	Bracket, Master Cylinder
07	97007-06025-00	Bolt
08	92907-06100-00	Washer, Spring
09	3LP-25872-11-00	Hose, Brake 1
10	4L0-25862-00-00	Boot, Master Cylinder
11	90401-10159-00	Bolt, Union
12	90201-10118-00	Washer, Plate
13	42H-25885-01-00	Joint
14	3LP-25873-10-00	Hose, Brake 2
15	3LP-25874-10-00	Hose, Brake
16	90401-10160-00	Bolt, Union
17	90201-10118-00	Washer, Plate
18	90401-10159-00	Bolt, Union
19	90201-10118-00	Washer, Plate
20	55R-25875-00-00	Holder, Brake Hose 1
21	95024-06020-00	Bolt, Flange
22	55R-25876-00-00	Holder, Brake Hose 2
23	95024-06020-00	Bolt, Flange
24	90401-10159-00	Bolt, Union
25	90201-10118-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3CF-27211-00-93	Pedal, Brake
02	90109-06468-00	Bolt
03	92995-06100-00	Washer, Spring
04	42X-27212-01-00	Shaft, Brake Pedal
05	90506-20192-00	Spring, Tension
06	90101-06478-00	Bolt
07	90170-06184-00	Nut
08	3CF-27231-01-00	Rod, Brake
09	90240-06057-00	Pin, Clevis
10	90560-06201-00	Spacer
11	92907-06200-00	Washer
12	91490-20020-00	Pin, Cotter
13	3CF-27241-00-00	Rod, Joint
14	90240-06103-00	Pin, Clevis
15	90501-10245-00	Spring, Compression
16	90249-12008-00	Pin
17	90175-06019-00	Nut, Wing
18	42X-27111-00-R4	Stand, Main
19	97007-10016-00	Bolt
20	90201-10752-00	Washer, Plate
21	90506-35149-00	Spring, Tension
22	371-27114-00-00	Stopper, Main Stand
23	42X-27311-00-93	Stand, Side
24	3Y3-27315-00-00	Link, Side Stand
25	90109-101G3-00	Bolt
26	95304-10700-00	Nut
27	90506-26225-00	Spring, Tension
28	90506-18224-00	Spring, Tension
29	3CF-27410-00-93	Front Footrest Assy (left)
30	1NH-27413-00-00	• . Cover, Footrest
31	95601-06100-00	• . Nut, U
32	90508-18696-00	• . Spring, Torsion
33	91701-08038-00	• . Pin, Clevis
34	91401-25020-00	• . Pin, Cotter
35	90387-087K5-00	• . Collar
36	1RM-27420-00-93	Front Footrest Assy (right)
37	1NH-27413-00-00	• . Cover, Footrest
38	95607-06100-00	• . Nut, U
39	90508-18696-00	• . Spring, Torsion
40	91701-08038-00	• . Pin, Clevis
41	91401-25020-00	• . Pin, Cotter
42	90387-087K5-00	• . Collar
43	4X7-27414-00-00	Damper, Footrest
44	90387-107A7-00	Collar
45	90201-100A1-00	Washer, Plate
46	90109-100G0-00	Bolt
47	3CF-27471-01-00	Bar, Footrest 1
48	90338-09012-00	Plug
49	3CF-27472-01-00	Bar, Footrest 2
50	90105-10050-00	Bolt, Washer Based
51	90176-10075-00	Nut, Crown
52	1RM-27430-01-00	Rear Footrest Assy 1
53	1NH-27433-00-00	• . Cover, Rear Footrest
54	98517-06012-00	• . Screw, Pan Head

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
55	1HX-27437-00-00	• . Washer, Special
56	91701-06038-00	• . Pin, Clevis
57	91490-16020-00	• . Pin, Cotter
58	90501-12743-00	• . Spring, Compression
59	93501-04011-00	• . Ball
60	1RM-27440-01-00	Rear Footrest Assy 2
61	1NH-27433-00-00	• . Cover, Rear Footrest
62	98517-06012-00	• . Screw, Pan Head
63	1HX-27437-00-00	• . Washer, Special
64	91701-06038-00	• . Pin, Clevis
65	91490-16020-00	• . Pin, Cotter
66	90501-12743-00	Spring, Compression
67	93501-04011-00	• . Ball
68	95024-08020-00	Bolt, Flange
69	95024-08045-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3JK-81450-00-0I	Rotor Assy
02	1RM-81410-20-(	Stator Assy
03	91317-06030-00	Bolt
04	3JK-81670-00-0I	Pick-up Assy
05	91317-06016-00	Bolt
06	90201-06643-00	Washer, Plate


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	5A8-81800-10-00	Starting Motor Assy
02	5A8-81826-10-00	• . Bolt
03	11H-81844-00-00	• . Gasket
04	5A8-81830-10-00	• . Front Bracket Assy
05	5A8-81847-10-00	•• .. O-ring
06	5A8-81840-10-00	• . Brush Holder Assy
07	1J7-81847-60-00	• . O-ring
08	95817-06025-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.






42W110-4360

Ref No	Part No	Description
01	2EN-83310-00-00	Front Flasher Light Assy 1
02	1KT-83311-00-00	• . Bulb, Flasher (12v-21w)
03	42X-83312-00-00	• . Lens, Flasher
04	42X-83313-00-00	• . Gasket, Flasher Lens
05	42X-83363-00-00	• . Lens, Rim
06	98507-03020-00	• . Screw, Pan Head
07	42X-83359-00-00	• . Washer, Special
08	1AA-83318-00-00	Stay, Flasher 1
09	2EN-83330-00-00	Rear Flasher Light Assy 1
10	1KT-83311-00-00	• . Bulb, Flasher (12v-21w)
11	2AE-83312-00-00	• . Lens, Flasher
12	42X-83313-00-00	• . Gasket, Flasher Lens
13	42X-83363-00-00	• . Lens, Rim
14	341-83333-70-00	• . Screw, Lens Fitting
15	42X-83359-00-00	• . Washer, Special
16	1AA-83328-00-00	Stay, Flasher 2
17	95707-12500-00	Nut, Flange
18	97204-06030-00	Bolt
19	95704-06500-00	Nut, Flange
20	42X-83328-00-00	Stay, Flasher 2


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



3CF110-8370


Ref No	Part No	Description
01	1FL-83570-F0-00	Speedometer Assy
02	1RM-83540-00-00	Tachometer Assy
03	3LP-8353E-00-00	Case, Meter Upper
04	3CF-8353H-00-00	Case, Under
05	1FG-83519-00-00	Bracket, Meter
06	42X-83507-00-00	Cover, Speedometer
07	42X-83508-00-00	Cover, Tachometer
08	1FG-83523-00-00	Damper
09	90201-05031-00	Washer, Plate
10	95307-05600-00	Nut
11	98507-04008-00	Screw, Pan Head
12	97707-40014-00	Screw, Tapping
13	1RM-83509-00-00	Socket Cord Assy
14	42X-83517-00-00	Bulb (12v-3w)
15	36Y-82151-00-00	Fuse (15a-bl)
16	42S-82151-20-00	Fuse (10a)
17	42X-83559-00-00	Cover, Meter
18	1FK-83523-00-00	Damper
19	1FK-83535-00-00	Tube
20	98707-04010-00	Screw, Flat Head
21	55R-83579-00-00	Cover, Meter 2
22	92907-06200-00	Washer
23	92907-06100-00	Washer, Spring
24	95317-06600-00	Nut
25	584-83541-00-00	Damper
26	90387-06249-00	Collar
27	3LP-83550-00-00	Speedometer Cable Assy

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	42X-84315-01-00	Rim, Headlight
02	5Y3-84395-00-00	Ring, Retaining
03	2AE-84320-G0-00	Lens Assy
05	2F9-84375-00-00	Fitting Plate, Bulb
06	2F9-84397-01-00	Cover, Socket
08	34L-84346-00-00	Socket, Pilot Light
09	90157-04001-00	Screw, Pan Head
10	1A0-84332-G0-00	Spring, Screw
11	198-84334-60-00	Nut, Adjusting
12	42X-84124-60-00	Spring, Set
13	42X-84330-01-00	Body Assy
14	42X-84345-00-00	• . Damper, Headlight
15	42X-84338-00-00	• . Collar, Body Fitting
16	42X-84366-00-00	• . Damper, Headlight 1
17	90157-05084-00	Screw, Pan Head
18	90201-06073-00	Washer, Plate
19	97017-06016-00	Bolt
20	92907-06100-00	Washer, Spring
21	91317-08055-00	Bolt
22	42X-84318-00-00	Stay, Headlight 1
23	91317-06025-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	2EM-84700-E0-00	Taillight Assy
02	2AE-84721-00-00	• . Lens, Taillight
03	42X-84723-01-00	• . Gasket, Tail Lens
04	1RM-84704-00-00	• . Gasket, Taillight
05	97707-40625-00	• . Screw, Tapping
06	31L-84714-00-00	• . Bulb (12v-21/5w)
07	90119-06097-00	Bolt, With Washer
08	90387-065L5-00	Collar
09	90480-14229-00	Grommet
10	90480-16501-00	Grommet
11	90480-01502-00	Grommet
12	2YL-84751-00-00	Bracket, License
13	95807-06016-00	Bolt, Flange
14	92907-06600-00	Washer, Plate
15	95307-06600-00	Nut

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	10M-82911-00-00	Holder, Lever 1
02	2GV-83912-00-00	Lever 1
03	3Y6-82917-00-00	Switch
04	90109-06799-00	Bolt
05	95607-06100-00	Nut, U
06	93210-11368-00	O-ring
07	97007-06025-00	Bolt
08	92907-06100-00	Washer, Spring
09	2W1-83922-00-00	Lever 2
10	90149-06153-00	Screw
11	90170-06010-00	Nut
12	90501-10312-00	Spring, Compression
13	90109-06577-00	Bolt
14	95607-06100-00	Nut, U
15	1AT-83972-00-00	Switch, Handle 4
16	98507-05035-00	• . Screw, Pan Head
17	10M-83942-00-00	• . Cover, Starter
18	10M-83941-00-00	• . Lever, Starter
19	90209-10131-00	• . Washer
20	98507-06008-00	• . Screw, Pan Head
21	92907-06200-00	• . Washer
22	3LP-83972-00-00	Switch, Handle 4
23	98507-05040-00	• . Screw, Pan Head
24	98507-05045-00	• . Screw, Pan Head
25	437-83936-01-00	Band, Switch Cord

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	11K-82110-79-00	Battery Assy (yamaha Fb50-n18l-a2)
02	1E6-82131-00-00	Band, Battery
03	42H-82115-00-00	Wire, Plus Lead
04	42X-82116-00-00	Wire, Minus Lead
05	90445-081A9-00	Hose
06	4KM-82540-00-00	Neutral Switch Assy
07	90430-10148-00	Gasket
08	42X-82310-70-00	Ignition Coil Assy
09	42X-82320-70-00	Ignition Coil Assy
10	98980-05016-00	Screw, Bind
11	42X-82317-00-00	Damper, Ignition Coil
12	1J7-82370-00-00	Plug Cap Assy
13	57A-82314-00-00	Cover, Ignition Coil
14	98507-06012-00	Screw, Pan Head
15	92907-06600-00	Washer, Plate
16	98507-06025-00	Screw, Pan Head
17	92907-06600-00	Washer, Plate
18	2AE-82510-00-00	Main Switch Assy
19	97007-06016-00	Bolt
20	92907-06600-00	Washer, Plate
21	1A0-83980-30-00	Front Stop Switch Assy
22	42X-82530-02-00	Stop Switch Assy
23	42X-82539-00-00	Stay, Stop Switch
24	3LP-82590-00-00	Wire Harness Assy
25	3H5-82150-00-00	Fuse Holder Assy
26	2H7-82151-00-00	• . Fuse
27	3JK-82305-00-00	Ignitor Unit Assy
28	97707-60520-00	Screw, Tapping
29	90201-063A5-00	Washer, Plate
30	3JK-85720-00-00	Oil Level Gauge Assy
31	91317-06106-00	Bolt
32	33E-82566-00-00	Switch, Side Stand
33	90152-05021-00	Screw, Countersunk
34	1TA-82380-20-00	Sensor, Pressure
35	98517-06030-00	Screw, Pan Head
36	92907-06600-00	Washer, Plate
37	90170-06184-00	Nut

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	5A8-86110-50-00	Solenoid
02	25G-81950-01-00	Relay Assy
03	3JK-81815-00-00	Cord, Starter Motor
04	95307-06700-00	Nut
05	92907-06100-00	Washer, Spring
06	95307-08700-00	Nut
07	92907-08100-00	Washer, Spring
08	42X-81960-A1-00	Rectifier & Regulator Assy
09	98507-06016-00	Screw, Pan Head
10	92907-06100-00	Washer, Spring
11	92907-06600-00	Washer, Plate
12	90465-10264-00	Clamp
13	25G-81950-01-00	Relay Assy
14	4U8-81980-M0-00	Diode Assy
15	47G-83350-41-00	Flasher Relay Assy
16	1RM-83371-00-00	Horn
17	1RM-83371-10-00	Horn
18	91317-06012-00	Bolt
19	42H-85752-01-00	Sender Unit Assy, Fuel Meter
20	42X-85753-00-00	Gasket, Sender Unit
21	90149-06011-00	Screw
22	90202-05187-00	Washer, Plate
23	449-85131-02-00	Reflector, Rear 1

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.