# YAMAHA

# GENUINE


## PARTS CATALOGUE

## MOTORCYCLE


**A1**

YZ490N

# CYLINDER





| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 40T-11111-00-00 | HEAD, CYLINDER 1 | 1 | |
| 2 | 40T-11181-00-00 | GASKET, CYLINDER HEAD 1 | 1 | |
| 3 | NGK-B8EG0-00-00 | PLUG, SPARK (NGK B8EG) (94702-00323-00) | 1 | LM |
| 4 | 90116-08394-00 | BOLT, STUD | 7 | |
| 5 | 95333-08600-00 | NUT | 7 | |
| 6 | 90201-08649-00 | WASHER, PLATE | 7 | |
| 7 | 40T-11311-02-00 | CYLINDER 1 | 1 | |
| 8 | 40T-11351-00-00 | GASKET, CYLINDER | 1 | |
| 9 | 90116-12315-00 | BOLT, STUD | 2 | |
| 10 | 90116-12316-00 | BOLT, STUD | 2 | |
| 11 | 95701-12500-00 | NUT, FLANGE | 4 | |
| 12 | 91810-17016-00 | PIN, DOWEL | 2 | |
| 13 | 40T-14619-01-00 | HOOK, SPRING | 1 | |




# CRANKSHAFT-PISTON

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 40T-11400-00-00 | CRANKSHAFT ASSEMBLY (3R5-11400-00) (3R5-11400-00) | 1 | |
| 2 | 40T-11412-00-00 | . CRANK 1 | 1 | |
| 3 | 40T-11422-00-00 | . CRANK 2 | 1 | |
| 4 | 3R5-11650-00-00 | . CONNECTING ROD ASSEMBLY | 1 | |
| 5 | 3R5-11651-00-00 | . . ROD, CONNECTING | 1 | |
| 6 | 3R8-11681-00-00 | . . PIN, CRANK 1 | 1 | |
| 7 | 90209-25085-00 | . . WASHER, (90209-25220) | 2 | |
| 8 | 93310-425N4-00 | . . BEARING, CYLINDRICAL | 1 | |
| 9 | 93310-418E9-00 | . BEARING, CYLINDRICAL | 1 | |
| 10 | 40T-11630-00-00 | PISTON KIT STD | 1 | |
| 11 | 40T-11631-00-93 | PISTON STD | 1 | |
| 12 | 5X6-11601-00-00 | PISTON RINGSET STD | 1 | |
| 13 | 275-11633-00-00 | PIN, PISTON | 1 | |
| 14 | 93450-19052-00 | CIRCLIP, INNER | 2 | |
| 15 | 93306-30615-00 | BEARING (B6306) | 2 | |
| 16 | 93103-30150-00 | OIL SEAL (38W) | 1 | |
| 17 | 93103-40091-00 | OIL SEAL | 1 | |
| 18 | 40T-11630-10-00 | PISTON KIT 1ST | 1 | ALTERNATE PARTS |
| | 40T-11630-20-00 | PISTON KIT 2ND (2ND O/S) | 1 | ALTERNATE PARTS |
| | 40T-11630-30-00 | PISTON KIT 3RD (3RD O/S) | 1 | ALTERNATE PARTS |
| | 40T-11630-40-00 | PISTON KIT 4TH (4TH O/S) | 1 | ALTERNATE PARTS |
| | 40T-11635-00-00 | PISTON 1 O/S 0.250.25MM) | 1 | ALTERNATE PARTS |
| | 40T-11636-00-00 | PISTON 2 O/S 0.500.50MM) | 1 | ALTERNATE PARTS |
| | 40T-11637-00-00 | PISTON 3 O/S 0.750.75MM) | 1 | ALTERNATE PARTS |
| | 40T-11638-00-00 | PISTON 4 O/S 1.001.00MM) | 1 | ALTERNATE PARTS |
| | 5X6-11601-10-00 | PISTON RING SET (1ST O/S) | 1 | ALTERNATE PARTS |
| | 5X6-11601-20-00 | PISTON RING SET (2ND O/S) | 1 | ALTERNATE PARTS |


*CONTINUED ON NEXT FRAME ➤*




5X6100-2021

# CRANKSHAFT-PISTON


| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 18 | 5X6-11601-30-00 | PISTON RING SET (3RD O/S) . | 1 | ALTERNATE PARTS |
| | 5X6-11601-40-00 | PISTON RING SET (4TH O/S) . . | 1 | ALTERNATE PARTS |
| | 90280-03017-00 | KEY, WOODRUFF . . . . . | 1 | |




# INTAKE


| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 39X-13610-00-00 | REED VALVE ASSEMBLY .... | 1 | |
| 2 | 39X-13613-00-00 | . REED, VALVE ..... | 2 | |
| 3 | 39X-13616-00-00 | . STOPPER, REED VALVE .... | 2 | |
| 4 | 98580-03008-00 | . SCREW, PAN HEAD (98501-03008-00) ..... | 8 | |
| 5 | 92990-03100-00 | . WASHER, SPRING ..... | 8 | |
| 6 | 39X-13621-11-00 | GASKET, VALVE SEAT ..... | 1 | |
| 7 | 40T-13565-00-00 | JOINT, CARBURETOR ..... | 1 | |
| 8 | 40T-13581-00-00 | CHAMBER, AIR ..... | 1 | |
| 9 | 4V3-1441K-00-00 | EMBLEM ..... | 1 | |
| 10 | 26A-13575-00-00 | BAND ..... | 1 | |
| 11 | 40T-13584-00-00 | PIPE, MANIFOLD ..... | 1 | |
| 12 | 90467-23059-00 | CLIP ..... | 2 | |
| 13 | 86M-13575-00-00 | BAND ..... | 1 | |
| 14 | 91316-06020-00 | BOLT ..... | 6 | |
| 15 | 90460-74254-00 | CLAMP, HOSE ..... | 1 | |
| 16 | (40T-14453-00-00) | JOINT, AIR CLNR 1 ..... | 1 | |
| 17 | 56A-14459-00-00 | HOLDER, GUIDE ..... | 1 | |
| 18 | 39X-14462-00-00 | SEAL ..... | 1 | |
| 19 | 95601-05100-00 | NUT, U ..... | 6 | |
| 20 | 39K-14457-00-00 | SEAL ..... | 1 | |
| 21 | 90504-03033-00 | SPRING, COMPRESSION ..... | 1 | |
| 22 | 39X-W1441-00-00 | AIR CLEANER CASECOMP. .. | 1 | |
| 23 | 92990-05200-00 | WASHER, PLAIN ..... | 6 | |
| 24 | 39X-14451-00-00 | ELEMENT, AIR CLNR ..... | 1 | |
| 25 | 39X-14458-00-00 | GUIDE, ELEMENT ..... | 1 | |
| 26 | 56A-14468-00-00 | PLATE, ELEMENT FTNG ..... | 1 | |
| 27 | 43N-14412-00-00 | CAP, CLEANER CASE 1 ..... | 1 | |
| 28 | 39W-14452-00-00 | SEAL ..... | 1 | |

*CONTINUED ON NEXT FRAME ➤*




# INTAKE


| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 29 | 40T-21737-10-00 | EMBLEM | 1 | |
| 30 | 92990-06200-00 | WASHER, PLAIN | 3 | |
| 31 | 98580-06012-00 | SCREW, PAN HEAD (92501-06012-00) | 3 | |
| 32 | 92995-06100-00 | WASHER, SPRING | 3 | |
| 33 | 39X-14452-00-00 | SEAL | 1 | |
| 34 | 97013-06012-00 | BOLT | 2 | |
| 35 | 92995-06100-00 | WASHER, SPRING | 2 | |
| 36 | 90201-061A5-00 | WASHER, PLATE | 2 | |
| 37 | 90119-06560-0 | UNAVAILABLE IN PRICE BOOK | 1 | |




# CARBURETOR

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | (57H-14101-00-00) | CARBURETOR ASSEMBLY 1 . | 1 | |
| 2 | 193-14142-35-00 | . JET, PILOT # 5 . . . . . | 1 | U.R. ALT. PART |
| | 193-14142-40-A1 | . JET, PILOT (# 40) . . . . . | 1 | STD |
| | 193-14142-45-A1 | . JET, PILOT (# 45) . . . . . | 1 | U.R. ALT. PART |
| 3 | 8A7-14141-56-00 | . NOZZLE, MAIN Q 6 . . . . . | 1 | U.R. ALT. PART |
| | 8A7-14141-58-00 | . NOZZLE, MAIN Q 8 . . . . . | 1 | STD |
| | 8A7-14141-R0-00 | . NOZZLE, MAIN . . . . . | 1 | U.R. ALT. PART |
| 4 | 137-14143-84-00 | . JET, MAIN (420) . . . . . | 1 | U.R. ALT. PART |
| | 137-14143-86-00 | . JET, MAIN (430) . . . . . | 1 | U.R. ALT. PART |
| | 137-14143-88-00 | . JET, MAIN (440) . . . . . | 1 | STD |
| | 137-14143-90-00 | . JET, MAIN (450) . . . . . | 1 | U.R. ALT. PART |
| | 137-14143-92-00 | . JET, MAIN (460) . . . . . | 1 | U.R. ALT. PART |
| 5 | 40T-1490J-00-00 | . NEEDLE SET . . . . . | 1 | |
| 6 | 40T-14187-00-00 | . ARM, FLOAT . . . . . | 1 | |
| 7 | 23X-14107-35-00 | . NEEDLE VALVE SET . . . . . | 1 | |
| 8 | 537-14186-00-00 | . PIN, FLOAT . . . . . | 1 | |
| 9 | 363-14184-00-00 | . GASKET, FLOAT CHMBR . . . | 1 | |
| 10 | 214-14185-00-00 | . FLOAT . . . . . | 2 | |
| 11 | 40T-14115-00-00 | . PLUG, SCREW . . . . . | 1 | |
| 12 | 3R3-14153-00-00 | . WASHER, MAIN JET . . . . . | 1 | |
| 13 | 278-14117-00-00 | . WASHER, SCREW PLUG . . . . | 1 | |
| 14 | (40T-14146-00-00) | PLATE . . . . . | 1 | |
| 15 | 40T-14112-25-00 | . VALVE, THRTL 1 2 5 . . . . . | 1 | U.R.äALT. PART |
| | 40T-14112-30-00 | . VALVE, THRTL 1 3 0 . . . . . | 1 | STD |
| | 40T-14112-35-00 | . VALVE, THROTTLE . . . . . | 1 | U.R.äALT. PART |
| 16 | 98580-05016-00 | . SCREW, PAN HEAD . . . . . | 4 | |
| 17 | 92990-05100-00 | . WASHER, SPRING . . . . . | 4 | |
| 18 | 40T-14106-00-00 | . CBLE AJST SCRW SETSCREW SET . . . . . | 1 | |


*CONTINUED ON NEXT FRAME ➤*





# CARBURETOR

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 19 | 40T-14158-00-00 | . TOP, MIXING CHAMBER .... | 1 | |
| 20 | 8H0-14131-00-00 | . SPRING, THRTL VALVE ..... | 1 | |
| 21 | 310-14197-00-00 | . PIPE ..... | 2 | |
| 22 | 313-14146-00-00 | . PLATE ..... | 2 | |
| 23 | 40T-14103-00-00 | . THROTTLE SCREW SET .... | 1 | |
| 24 | 57H-1410A-00-00 | . STARTER SET ..... | 1 | |
| 25 | 23X-14104-00-00 | . AIR SCREW SET ..... | 1 | |
| 26 | 3Y3-14196-00-00 | . PIPE, OVERFLOW ..... | 1 | |
| 27 | 57H-14175-00-00 | . LEVER, STARTER 1 ..... | 1 | |

# EXHAUST





| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 40T-14610-00-00 | EXHAUST PIPE ASSEMBLY L . | 1 | |
| 2 | 40T-14613-00-00 | GASKET, EXST PIPE . . . . . | 1 | |
| 3 | 90507-20030-00 | SPRING, TENSION . . . . . | 3 | |
| 4 | 40T-14771-00-00 | STAY, MUFFLER 1 . . . . . | 1 | |
| 5 | 90201-08730-00 | WASHER, PLATE . . . . . | 3 | |
| 6 | 97313-08018-00 | BOLT, HEXAGON . . . . . | 2 | |
| 7 | 92990-08100-00 | WASHER, SPRING . . . . . | 2 | |
| 8 | 40T-14753-01-00 | SILENCER, EXHAUST . . . . . | 1 | |
| 9 | 40T-1469A-00-00 | . FIBER . . . . . | 1 | |
| 10 | 90267-40115-00 | . RIVET, BLIND . . . . . | 4 | |
| 11 | 39X-14747-00-00 | DAMPER, MUFFLER . . . . . | 1 | |
| 12 | 90387-081A3-00 | COLLAR . . . . . | 1 | |
| 13 | 90201-08612-00 | WASHER, PLATE . . . . . | 1 | |
| 14 | 90109-08512-00 | BOLT . . . . . | 1 | |
| 15 | 565-14771-00-00 | STAY, MUFFLER 1 . . . . . | 1 | |
| 16 | 90109-06551-00 | BOLT . . . . . | 1 | |
| 17 | 97313-06016-00 | BOLT . . . . . | 1 | |
| 18 | 92995-06100-00 | WASHER, SPRING . . . . . | 1 | |
| 19 | 90201-061A5-00 | WASHER, PLATE . . . . . | 1 | |





# CRANKCASE

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 3R5-W1511-01-00 | CRANKCASE 1 | 1 | |
| 2 | 137-13115-00-00 | . CONNECTOR, SCTN PPE | 1 | |
| 3 | 91316-06075-00 | BOLT | 1 | |
| 4 | 91316-06060-00 | BOLT | 7 | |
| 5 | 91316-06050-00 | BOLT | 1 | |
| 6 | 91316-06045-00 | BOLT | 2 | |
| 7 | 3SP-15381-00-00 | PLATE, BEARING COVER | 1 | |
| 8 | 98603-06012-00 | SCREW, OVAL HEAD (92701-06012) | 1 | |
| 9 | 90387-160H4-00 | COLLAR | 1 | |
| 10 | 98516-06012-00 | SCREW, PAN HEAD | 1 | |
| 11 | 23X-26393-00-00 | HOLDER | 1 | |
| 12 | 3R5-15121-05-00 | CRANKCASE 2 | 1 | |
| 13 | 90338-07011-00 | PLUG, SPEC''L SHAPE | 1 | |
| 14 | 99510-12016-00 | PIN, DOWEL | 4 | |
| 15 | 90387-160H4-00 | COLLAR | 1 | |
| 16 | 23X-15381-00-00 | PLATE, BRNG COVER | 1 | |
| 17 | 98580-06012-00 | SCREW, PAN HEAD (92501-06012-00) | 3 | |
| 18 | 4V4-15118-00-00 | HOLDER | 1 | |
| 19 | 98580-06010-00 | SCREW, PAN HEAD | 1 | |
| 20 | 3R4-15113-00-00 | PLATE | 1 | |
| 21 | 98580-06012-00 | SCREW, PAN HEAD (92501-06012-00) | 1 | |
| 22 | 90445-08605-00 | HOSE | 1 | |
| 23 | 90340-12097-00 | PLUG, STRAIGHT SCREW | 1 | |
| 24 | 90430-12207-00 | GASKET | 1 | |

# CRANKCASE COVER 1





| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 40T-15411-00-00 | COVER, CRANKCASE L | 1 | |
| 2 | 4V4-15451-00-00 | GASKET, CRANKCASE COVER | 1 | |
| 3 | 90465-06247-00 | CLAMP | 1 | |
| 4 | 98506-06035-00 | SCREW, PAN HEAD | 3 | |
| 5 | 92906-06600-00 | WASHER | 3 | |
| 6 | 23X-15421-00-00 | COVER, CRANKCASE 2 | 1 | |
| 7 | 98506-06025-00 | SCREW, PAN HEAD | 1 | |
| 8 | 92906-06100-00 | WASHER, SPRING | 1 | |
| 9 | 92906-06600-00 | WASHER | 1 | |
| 10 | 40T-15431-00-00 | COVER, CRANKCASE 3 | 1 | |
| 11 | 3R4-15462-00-00 | GASKET, CRANKCASE COVER 3 | 1 | |
| 12 | 91316-06025-00 | BOLT | 8 | |
| 13 | 1G8-15362-00-00 | PLUG, OIL LEVEL | 1 | |
| 14 | 93210-14104-00 | O-RING | 1 | |
| 15 | 98506-06008-00 | SCREW, PAN HEAD | 1 | |
| 16 | 90430-06016-00 | GASKET | 1 | |
| 17 | 56A-15378-00-00 | HOLDER | 1 | |





# GENERATOR

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 23X-85510-21-00 | STATOR ASSEMBLY | 1 | |
| 2 | 23X-85520-21-00 | . COIL, CHARGE | 1 | |
| 3 | 23X-85580-20-00 | . COIL, PULSER | 1 | |
| 4 | 104-81328-20-00 | . CLAMP | 1 | |
| 5 | 98503-04014-00 | . SCREW, PAN HEAD | 3 | |
| 6 | 92901-04100-00 | . WASHER, SPRING | 3 | |
| 7 | 97601-04106-00 | . SCREW, PN/HD.W/WSHR | 1 | |
| 8 | 23X-85550-20-00 | ROTOR ASSEMBLY | 1 | |
| 9 | 98580-06020-00 | SCREW, PAN HEAD | 2 | |
| 10 | 90201-061A5-00 | WASHER, PLATE | 2 | |
| 11 | 90170-12347-00 | NUT, HEXAGON | 1 | |
| 12 | 90201-12593-00 | WASHER, PLATE | 1 | |





# STARTER

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 57H-15661-00-00 | KICK AXLE ASSEMBLY | 1 | |
| 2 | 23X-15641-00-00 | GEAR, KICK | 1 | |
| 3 | 90468-26048-00 | CLIP | 1 | |
| 4 | 90201-20358-00 | WASHER, PLATE | 1 | |
| 5 | 90508-30422-00 | SPRING, TORSION | 1 | |
| 6 | 40T-15664-00-00 | GUIDE, SPRING | 1 | |
| 7 | 23X-15651-00-00 | GEAR, KICK IDLE | 1 | |
| 8 | 90201-17545-00 | WASHER, PLATE | 2 | |
| 9 | 99009-17400-00 | CIRCLIP | 1 | |
| 10 | 93102-20309-00 | OIL SEAL | 1 | |
| 11 | 40T-15620-01-00 | KICK CRANK ASSEMBLY | 1 | |
| 12 | 23X-15621-02-00 | . BOSS, KICK CRANK | 1 | |
| 13 | 93501-04011-00 | . BALL | 1 | |
| 14 | 90501-13720-00 | . SPRING, COMPRESSION | 1 | |
| 15 | 93210-19501-00 | . O-RING | 1 | |
| 16 | 90157-06048-00 | . SCREW, PAN HEAD - (90152-06010) | 1 | |
| 17 | 23X-15618-00-00 | . COVER, KICK LEVER | 1 | |
| 18 | 90179-12244-00 | NUT, SPEC''L SHAPE | 1 | |




# CLUTCH


| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 23X-16111-00-00 | GEAR, PRIMARY DRIVE | 1 | |
| 2 | 90282-07019-00 | KEY, STRAIGHT | 1 | |
| 3 | 90201-186H3-00 | WASHER, PLATE | 1 | |
| 4 | 90185-18126-00 | NUT, SELF-LOCKING | 1 | |
| 5 | 39X-16150-00-00 | PRI DRVN GEARGEAR COMP | 1 | |
| 6 | 23X-16371-00-00 | BOSS, CLUTCH | 1 | |
| 7 | 23X-16351-00-00 | PLATE, PRESSURE 1 | 1 | |
| 8 | 4H7-16325-00-00 | PLATE, CLUTCH 2 | 6 | |
| 9 | 5X5-16321-00-00 | PLATE, FRICTION | 7 | |
| 10 | 90501-24408-00 | SPRING, COMPRESSION | 6 | |
| 11 | 90159-06016-00 | SCREW, WITH WASHER | 6 | |
| 12 | 2K7-16154-00-00 | PLATE, THRUST 1 | 1 | |
| 13 | 2K7-16181-00-00 | SPACER 1 | 1 | |
| 14 | 2K7-16154-00-00 | PLATE, THRUST 1 | 1 | |
| 15 | 90215-20212-00 | WASHER, LOCK | 1 | |
| 16 | 90170-20255-00 | NUT | 1 | |
| 17 | 23X-16356-00-00 | ROD, PUSH 1 | 1 | |
| 18 | 93515-32029-00 | BALL | 1 | |
| 19 | 90149-06179-00 | SCREW | 1 | |
| 20 | 92995-06100-00 | WASHER, SPRING | 1 | |
| 21 | 95380-06600-00 | NUT, HEXAGON | 1 | |
| 22 | 3R5-16357-01-00 | ROD, PUSH 2 0 1 | 1 | |
| 23 | 93315-21721-00 | BEARING, CYLINDRICAL | 1 | |
| 24 | 93102-17263-00 | OIL SEAL | 1 | |
| 25 | 90201-17327-00 | WASHER, PLATE | 1 | |
| 26 | 90508-14423-00 | SPRING, TORSION | 1 | |
| 27 | 1LV-16380-00-00 | PUSH LEVER ASSEMBLY | 1 | |




# TRANSMISSION

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 5X6-17411-01-00 | AXLE, MAIN | 1 | |
| 2 | 93300-20501-00 | BEARING | 1 | |
| 3 | 5X6-17141-00-00 | GEAR, 4TH PINION (24T) | 1 | |
| 4 | 90201-253K0-00 | WASHER, PLATE (T=1.0) | 1 | |
| 5 | 93440-25084-00 | CIRCLIP | 1 | |
| 6 | 5X6-17131-00-00 | GEAR, 3RD PINION (22T) | 1 | |
| 7 | 5X6-17121-01-00 | GEAR, 2ND PINION | 1 | |
| 8 | 90201-203E7-00 | WASHER, PLATE | 1 | |
| 9 | 93410-20038-00 | CIRCLIP | 1 | |
| 10 | 90201-20276-00 | WASHER, PLATE (1.0T) | 1 | |
| 11 | 93311-62035-00 | BEARING, CYLINDRICAL | 1 | |
| 12 | 5X6-17421-00-00 | AXLE, DRIVE | 1 | |
| 13 | 93311-62035-00 | BEARING, CYLINDRICAL | 1 | |
| 14 | 93410-20038-00 | CIRCLIP | 1 | |
| 15 | 90201-20278-00 | WASHER, PLATE | 1 | |
| 16 | 5X6-17211-00-00 | GEAR, 1ST WHEEL (28T) | 1 | |
| 17 | 5X7-17241-00-00 | UNAVAILABLE IN PRICE BOOK | 1 | |
| 18 | 93440-25084-00 | CIRCLIP | 1 | |
| 19 | 90201-253K0-00 | WASHER, PLATE (T=1.0) | 1 | |
| 20 | 5X6-17231-00-00 | GEAR, 3RD WHEEL (23T) | 1 | |
| 21 | 5X6-17221-00-00 | GEAR, 2ND WHEEL (25T) | 1 | |
| 22 | 99009-30400-00 | CIRCLIP | 2 | |
| 23 | 90201-256K6-00 | WASHER, PLATE (0.9T) | 1 | |
| 24 | 93300-20501-00 | BEARING | 1 | |
| 25 | 93102-32M07-00 | OIL SEAL | 1 | |
| 26 | 90387-25663-00 | COLLAR | 1 | |
| 27 | 93834-13030-00 | SPROCKET, DRIVE 13T | 1 | ALTERNATE PART |
| | 93834-14051-00 | SPROCKET, DRIVE | 1 | STD |
| | 93834-15078-00 | SPROCKET, DRIVE | 1 | ALTERNATE PART |


*CONTINUED ON NEXT FRAME ➤*




# TRANSMISSION


| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 28 | 90215-21239-00 | WASHER, LOCK . . . . . | 1 | |
| 29 | 90179-20255-00 | NUT . . . . . | 1 | |

# SHIFT CAM-FORK




23X100-3120


| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 23X-18540-00-00 | SHIFT CAM ASSEMBLY | 1 | |
| 2 | 3R4-18140-00-00 | STOPPER LEVER ASSEMBLY | 1 | |
| 3 | 90508-26421-00 | SPRING, TORSION | 1 | |
| 4 | 50W-21631-00-00 | BOLT 1 | 1 | |
| 5 | 5X6-18513-00-00 | FORK, SHIFT 3 | 1 | |
| 6 | 5X6-18512-00-00 | FORK, SHIFT 2 | 1 | |
| 7 | 93606-14154-00 | PIN, DOWEL | 2 | |
| 8 | 5X5-18531-01-00 | BAR, SHIF FRK GDE 1 | 1 | |
| 9 | 5X5-18535-01-00 | BAR, SHIF FRK GDE 2 | 1 | |
| 10 | 93306-20110-00 | BEARING | 1 | |




23X100-3130

# SHIFT SHAFT


| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 23X-18101-01-00 | SHIFT SHAFT ASSEMBLY 1 .. | 1 | |
| 2 | 23X-18110-01-00 | SHIFT PEDAL ASSEMBLY .... | 1 | |
| 3 | 97011-06025-00 | BOLT (97001-06025) ..... | 1 | |
| 4 | 93102-12321-00 | OIL SEAL, SD-TYPE ..... | 1 | |
| 5 | 93608-25150-00 | PIN, DOWEL ..... | 1 | |
| 6 | 90560-12171-00 | SPACER ..... | 1 | |
| 7 | 90508-29361-00 | SPRING, TORSION ..... | 1 | |




# FRAME


| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | (57H-21110-00-FH) | FRAME | 1 | FIRE RED |
| 2 | 40T-21416-00-00 | BRACKET, FRT UPR 2 | 1 | |
| 3 | 40T-21415-00-00 | BRACKET, FRT UPR 1 | 1 | |
| 4 | 40T-2141K-00-00 | BRACKET, OUTER 1 | 1 | |
| 5 | 40T-2141L-00-00 | BRACKET, OUTER 2 | 1 | |
| 6 | 95811-08060-00 | BOLT, FLANGE | 4 | |
| 7 | 95811-08110-00 | BOLT, FLANGE | 1 | |
| 8 | 95601-08200-00 | NUT, SELF LOCKING | 4 | |
| 9 | 40T-21425-00-00 | BRACKET, REAR UPR 1 | 1 | |
| 10 | 40T-21426-00-00 | BRACKET, REAR UPR 2UPPER 2 | 1 | |
| 11 | 95811-08055-00 | BOLT, FLANGE | 2 | |
| 12 | 90202-08022-00 | WASHER, PLATE | 2 | |
| 13 | 95601-08200-00 | NUT, SELF LOCKING | 2 | |
| 14 | 95811-10065-00 | BOLT, FLANGE | 1 | |
| 15 | 92990-10200-00 | WASHER, PLAIN | 1 | |
| 16 | 90201-100L3-00 | WASHER, PLATE | 2 | |
| 17 | 95601-10200-00 | NUT, SELF-LOCKING | 1 | |
| 18 | 95811-08180-00 | BOLT, FLANGE | 1 | |
| 19 | 95601-08200-00 | NUT, SELF LOCKING | 2 | |
| 20 | 90339-13005-00 | PLUG | 2 | |
| 21 | 30X-22178-00-00 | TENSIONER | 2 | |
| 22 | 4V4-22184-00-00 | BUSH | 2 | |
| 23 | 90109-08705-00 | BOLT | 1 | |
| 24 | 95601-08200-00 | NUT, SELF LOCKING | 1 | |
| 25 | 90201-08753-00 | WASHER, PLATE | 1 | |
| 26 | 95811-08012-00 | BOLT, FLANGE (95801-08012-00) | 1 | |
| 27 | 90201-13202-00 | WASHER, PLATE | 1 | |

*CONTINUED ON NEXT FRAME ➤*





# FRAME

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 28 | 56A-28100-00-00 | TOOL KIT . . . . . | 1 | |
| 29 | 1HX-28135-00-00 | . SPANNER, SPECIAL . . . . . | 1 | |
| 30 | 2X4-2811A-01-00 | GAUGE, AIR . . . . . | 1 | |





# FENDER

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 5X6-21511-11-00 | FENDER, FRONT | 1 | WHITE |
| 2 | 90201-06571-00 | WASHER, PLATE | 4 | |
| 3 | 90387-06681-00 | COLLAR | 4 | |
| 4 | 97023-06020-00 | BOLT (3XF) (97302-06020) | 4 | |
| 5 | 92901-06700-00 | WASHER, WAVE (92902-06700) | 4 | |
| 6 | 3R4-21611-10-00 | FENDER, REAR | 1 | WHITE |
| 7 | 97313-06016-00 | BOLT | 4 | |
| 8 | 92901-06700-00 | WASHER, WAVE (92902-06700) | 4 | |
| 9 | 90201-06571-00 | WASHER, PLATE | 4 | |
| 10 | 39X-21620-00-00 | GUARD, MUD | 1 | |
| 11 | 437-83936-01-00 | BAND, SWITCH CORD | 1 | |
| 12 | 39X-21642-00-00 | GUARD, FLAP | 1 | |
| 13 | 90119-06042-00 | BOLT, WITH WASHER | 2 | |




# SIDE COVER


| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 39X-21711-11-98 | COVER, SIDE 1 | 1 | LOW GLOSS BLK/WHITE |
| 2 | 98503-06014-00 | SCREW, PAN HEAD (92501-06015) | 2 | |
| 3 | 92995-06100-00 | WASHER, SPRING | 2 | |
| 4 | 90201-06571-00 | WASHER, PLATE | 2 | |
| 5 | 39X-21721-11-98 | COVER, SIDE 2 | 1 | LOW GLOSS BLK/WHITE |
| 6 | 22W-24181-00-00 | DAMPER, LOCATING 1 | 4 | |
| 7 | 92990-08200-00 | WASHER, PLAIN | 2 | |
| | 98503-06014-00 | SCREW, PAN HEAD (92501-06015) | 2 | |
| 9 | 92995-06100-00 | WASHER, SPRING | 2 | |
| 10 | 90201-06571-00 | WASHER, PLATE | 2 | |
| 11 | 40T-21737-10-00 | EMBLEM | 1 | |
| 12 | 3R2-21782-00-00 | EMBLEM 2 | 2 | |




# REAR ARM


| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | (56A-22110-00-00) | REAR ARM | 1 | |
| 2 | 93317-32231-00 | BEARING | 2 | |
| 3 | 90380-22111-00 | BUSH, SOLID | 2 | |
| 4 | 93106-22019-00 | OIL SEAL (DC 22-28-8) | 2 | |
| 5 | 93342-22208-00 | BEARING | 2 | |
| 6 | 93108-35004-00 | OIL SEAL (35-41-8) | 2 | |
| 7 | 3R4-22129-00-00 | COVER, THRUST 2 | 2 | |
| 8 | 90380-16077-00 | BUSH, SOLID | 2 | |
| 9 | 240-22127-00-00 | SHIM (0.3T) | 1 | U.N. |
| 10 | 39W-22151-00-00 | SEAL, GUARD | 1 | |
| 11 | 5X6-22141-01-00 | SHAFT, PIVOT | 1 | |
| 12 | 90185-16127-00 | NUT, SELF-LOCKING | 1 | |
| 13 | 90201-160F6-00 | WASHER, PLATE | 1 | |
| 14 | 23X-22199-00-00 | SUPPORT, CHAIN | 1 | |
| 15 | 95811-08055-00 | BOLT, FLANGE | 2 | |
| 16 | 95601-08200-00 | NUT, SELF LOCKING | 2 | |
| 17 | 95811-06020-00 | BOLT, FLANGE | 2 | |
| 18 | 90201-06067-00 | WASHER, PLATE | 2 | |
| 19 | (39X-2217A-00-00) | ARM, RELAY | 1 | |
| 20 | 93317-32034-00 | BEARING, CYLINDRICAL | 1 | |
| 21 | 93109-20029-00 | OIL SEAL | 2 | |
| 22 | 90387-147G6-00 | COLLAR | 1 | |
| 23 | 90387-147G7-00 | COLLAR | 1 | |
| 24 | 90109-12701-00 | BOLT | 1 | |
| 25 | 93700-06M03-00 | NIPPLE, GREASE | 1 | |
| 26 | 90201-120A5-00 | WASHER, PLATE | 1 | |
| 27 | 90201-142M6-00 | WASHER, PLATE | 1 | |
| 28 | 90185-12119-00 | NUT, SELF-LOCKING | 1 | |
| 29 | 39X-2217F-00-00 | ROD, CONNECTING 1 | 1 | |

*CONTINUED ON NEXT FRAME ➤*




# REAR ARM

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 30 | 93315-31732-00 | BEARING, CYLINDRICAL .... | 2 | |
| 31 | 55K-22129-00-00 | COVER, THRUST 2 ..... | 4 | |
| 32 | 90387-121H1-00 | COLLAR ..... | 2 | |
| 33 | 90109-10702-00 | BOLT ..... | 1 | |
| 34 | 93700-06005-00 | NIPPLE, GREASE ..... | 1 | |
| 35 | 90201-120E6-00 | WASHER, PLATE ..... | 1 | |
| 36 | 90201-100E9-00 | WASHER, PLATE ..... | 1 | |
| 37 | 90185-10120-00 | NUT, SELF-LOCKING ..... | 1 | |
| 38 | 90109-10703-00 | BOLT ..... | 1 | |
| 39 | 93700-06M03-00 | NIPPLE, GREASE ..... | 1 | |
| 40 | 90201-100F7-00 | WASHER, PLATE ..... | 1 | |
| 41 | 95611-10100-00 | NUT, U ..... | 1 | |
| 42 | 5X3-2218A-00-00 | EMBLEM, REAR ARM ..... | 2 | |





# REAR SUSPENSION

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | (57H-22210-00-6W) | SHOCK ASSEMBLY, REAR . . . | 1 | NATIVE RED |
| 2 | (57H-22401-00-00) | DAMPER SUB ASSEMBLY . . . | 1 | |
| 3 | 93399-99934-00 | . . BEARING . . . . . | 1 | |
| 4 | 93440-30113-00 | . . CIRCLIP . . . . . | 2 | |
| 5 | 98511-04006-00 | . . SCREW, PAN HEAD . . . . . | 1 | |
| 6 | 56A-22463-00-00 | . . CABLE, CONTROL 1 . . . . . | 1 | |
| 7 | 23X-22475-00-00 | . SEAL, DUST 0 1 . . . . . | 1 | |
| 8 | 26A-22472-00-00 | . CAP, CASE 0 1 . . . . . | 1 | |
| 9 | 56A-22489-00-00 | . INACTIVE PART NUMBER . . . | 1 | |
| 10 | 93604-21193-00 | . PIN, DOWEL . . . . . | 1 | |
| 11 | 39X-22493-00-00 | . BUMP, STOP . . . . . | 1 | |
| 12 | 3R4-22228-00-00 | . SUPPORT, BUMP STOP . . . . | 1 | |
| 13 | 90206-14067-00 | . WASHER, WAVE . . . . . | 1 | |
| 14 | 39X-22409-00-00 | . UPPER BRKT SUB ASSEMBLYSUB ASSEMBLY . | 1 | |
| 15 | 93399-99934-00 | . BEARING . . . . . | 1 | |
| 16 | 93440-30113-00 | . CIRCLIP . . . . . | 2 | |
| 17 | 93104-18077-00 | . OIL SEAL . . . . . | 2 | |
| 18 | 5X3-22497-00-00 | . NUT, ADJUSTING . . . . . | 1 | |
| 19 | 93604-26132-00 | . PIN, DOWEL . . . . . | 1 | |
| 20 | 3R4-22221-01-00 | . COVER . . . . . | 2 | |
| 21 | 23X-22213-00-00 | . SEAT, SPRING UPPER . . . . . | 1 | |
| 22 | 90170-20320-00 | . NUT, HEXAGON . . . . . | 1 | |
| 23 | 39X-22212-00-6W | . SPRING, MXS STD . . . . . | 1 | NATIVE RED (SOFT) UR |
| | 39X-22212-20-6W | . SPRING, MXS HARD . . . . . | 1 | NATIVE RED (STD) |
| | 57H-22212-20-6W | . SPRING, SHOCK REAR . . . . . | 1 | NATIVE RED (HARD) UR |
| 24 | 23X-22214-00-00 | . GUIDE, SPRING 1 . . . . . | 2 | |
| 25 | 23X-22223-00-00 | . SEAT, SPRING LOWER . . . . . | 1 | |


*CONTINUED ON NEXT FRAME ➤*

# REAR SUSPENSION




| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 26 | 93440-51103-00 | . CIRCLIP | 1 | |
| 27 | 56A-22499-00-00 | . LABEL, CAUTION | 1 | |
| 28 | 90109-10704-00 | BOLT | 1 | |
| 29 | 90185-10120-00 | NUT, SELF-LOCKING | 1 | |
| 30 | 90201-100F7-00 | WASHER, PLATE | 1 | |
| 31 | 23X-22211-00-00 | COVER | 2 | |
| 32 | 90387-127G8-00 | COLLAR | 2 | |
| 33 | 90109-10700-00 | BOLT | 1 | |
| 34 | 90201-120E6-00 | WASHER, PLATE | 1 | |
| 35 | 90201-100E9-00 | WASHER, PLATE | 1 | |
| 36 | 90185-10120-00 | NUT, SELF-LOCKING | 1 | |
| 37 | 90387-126H8-00 | COLLAR | 2 | |
| 38 | 56A-22261-00-00 | DAMPER, SUB TANK | 1 | |
| 39 | 24X-22262-00-00 | HOLDER, SUB TANK | 1 | |
| 40 | 90480-25381-00 | GROMMET | 1 | |


# FRONT FORK




| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | (57H-23102-N0-00) | FRONT FORK ASSEMBLY LH . | 1 | |
| 2 | (56A-23126-L0-00) | TUBE, OUTER 1 . . . . . | 1 | |
| 3 | 4V4-23153-L0-00 | . RING, SNAP . . . . . | 1 | |
| 4 | 23X-23145-L0-00 | . OIL SEAL . . . . . | 1 | |
| 5 | 3XJ-23125-L0-00 | . METAL, SLIDE 1 . . . . . | 1 | |
| 6 | 23X-23144-L0-00 | . SEAL, DUST . . . . . | 1 | |
| 7 | 4V4-23146-L0-00 | . WASHER, OIL SEAL . . . . . | 1 | |
| 8 | 56A-23110-L0-00 | . INNER TUBE 1 . . . . . | 1 | |
| 9 | 4V4-23171-L0-00 | . . PISTON, FRONT FORK . . . . | 1 | |
| 10 | (56A-23170-L0-00) | CYLINDER, FRTFRK . . . . . | 1 | |
| 11 | 55Y-23152-M0-00 | . . SPRING, SUB . . . . . | 1 | |
| 12 | 4V4-23157-L0-00 | . . RING, PISTON FRTFRK . . . . | 2 | |
| 13 | 23X-23173-L0-00 | . SPINDLE, TAPER . . . . . | 1 | |
| 14 | 39X-23141-00-00 | . SPRING, FRTFRK STD (K@0.305) . . . . . | 1 | SOFT U.R. |
| | 39X-23141-20-00 | . SPRING, FRTFRK HARD (K@0.325) . . . . . | 1 | STD |
| | 57H-23141-20-00 | . SPRING, FRTFRK HARD (K@0.345) . . . . . | 1 | HARD U.R. |
| 15 | 4V4-23142-L0-00 | . SEAT, SPRING UPPER . . . . . | 2 | |
| 16 | 5X6-23118-10-00 | . SPACER (L=80) . . . . . | 1 | |
| 17 | 23X-23158-L0-00 | . GASKET . . . . . | 1 | |
| 18 | 122-23129-00-00 | . GASKET, DRAIN PLUG . . . . . | 1 | |
| 19 | 4H7-23119-00-00 | . PLUG, DRAIN . . . . . | 1 | |
| 20 | 43M-23111-L0-00 | . BOLT, CAP . . . . . | 1 | |
| 21 | 23X-23190-L0-00 | . AIR VALVE COMP. . . . . | 1 | |
| 22 | 4V4-23188-L0-00 | . O-RING . . . . . | 1 | |
| 23 | 3J2-23147-00-00 | . O-RING . . . . . | 1 | |
| 24 | 56A-2316A-L0-00 | . VALVE . . . . . | 1 | |
| 25 | 55Y-2312G-M0-00 | . PLUG . . . . . | 1 | |


*CONTINUED ON NEXT FRAME ➤*

# FRONT FORK





| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 26 | (56A-23103-L0-00) | FRONT FORK ASSEMBLY R .. | 1 | |
| 27 | (56A-23136-L0-00) | TUBE, OUTER 2 ..... | 1 | |
| 28 | 4V4-23153-L0-00 | . RING, SNAP ..... | 1 | |
| 29 | 23X-23145-L0-00 | . OIL SEAL ..... | 1 | |
| 30 | 3XJ-23125-L0-00 | . METAL, SLIDE 1 ..... | 1 | |
| 31 | 23X-23144-L0-00 | . SEAL, DUST ..... | 1 | |
| 32 | 4V4-23146-L0-00 | . WASHER, OIL SEAL ..... | 1 | |
| 33 | 56A-23110-L0-00 | . INNER TUBE 1 ..... | 1 | |
| 34 | 4V4-23171-L0-00 | . . PISTON, FRONT FORK .... | 1 | |
| 35 | (56A-23170-L0-00) | CYLINDER, FRTFRK ..... | 1 | |
| 36 | 55Y-23152-M0-00 | . . SPRING, SUB ..... | 1 | |
| 37 | 4V4-23157-L0-00 | . . RING, PISTON FRTFRK .... | 2 | |
| 38 | 23X-23173-L0-00 | . SPINDLE, TAPER ..... | 1 | |
| 39 | 39X-23141-00-00 | . SPRING, FRTFRK STD (K@0.305) ..... | 1 | |
| | 39X-23141-10-00 | . SPRING, FRTFRK SOFT (K@0.275) ..... | 1 | |
| | 39X-23141-20-00 | . SPRING, FRTFRK HARD (K@0.325) ..... | 1 | |
| 40 | 4V4-23142-L0-00 | . SEAT, SPRING UPPER ..... | 2 | |
| 41 | 5X6-23118-10-00 | . SPACER (L=80) ..... | 1 | |
| 42 | 23X-23158-L0-00 | . GASKET ..... | 1 | |
| 43 | 122-23129-00-00 | . GASKET, DRAIN PLUG ..... | 1 | |
| 44 | 4H7-23119-00-00 | . PLUG, DRAIN ..... | 1 | |
| 45 | 43M-23111-L0-00 | . BOLT, CAP ..... | 1 | |
| 46 | 23X-23190-L0-00 | . AIR VALVE COMP. ..... | 1 | |
| 47 | 4V4-23188-L0-00 | . O-RING ..... | 1 | |
| 48 | 3J2-23147-00-00 | . O-RING ..... | 1 | |
| 49 | 56A-2316A-L0-00 | . VALVE ..... | 1 | |
| 50 | 5X6-23181-L0-00 | . BOLT, HEXAGON SOCKET HEAD ..... | 2 | |

*CONTINUED ON NEXT FRAME ➤*





# FRONT FORK

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 51 | 55Y-2312G-M0-00 | . PLUG | 1 | |
| 52 | 43M-23191-L0-00 | BOOT, FRONT FORK | 2 | |
| 53 | 43M-23192-L0-00 | BAND | 2 | |
| 54 | 98506-04018-00 | SCREW, PAN HEAD | 2 | |
| 55 | 3LD-23489-00-00 | BAND | 2 | |
| 56 | 39X-23340-00-00 | UNDER BRACKET | 1 | |
| 57 | 90101-08340-00 | BOLT | 4 | |
| 58 | 92901-08600-00 | WASHER, PLATE | 4 | |
| 59 | 92990-08100-00 | WASHER, SPRING | 4 | |
| 60 | 95333-08600-00 | NUT | 4 | |




# STEERING


| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 3R4-23389-00-00 | GUIDE, CABLE | 1 | |
| 2 | 93332-00008-00 | BEARING | 1 | |
| 3 | 40G-23435-00-98 | UNAVAILABLE IN PRICE BOOK | 1 | LOW GLOSS BLK |
| 4 | 1E6-23442-00-00 | HOLDER, HANDLE LWR | 2 | |
| 5 | 307-22123-00-00 | BUSH 1 | 2 | |
| 6 | 90201-123E8-00 | WASHER, PLATE | 2 | |
| 7 | 90201-100A1-00 | WASHER, PLATE | 2 | |
| 8 | 90387-121E8-00 | COLLAR | 2 | |
| 9 | 90202-14077-00 | WASHER, PLATE | 2 | |
| 10 | 90185-10037-00 | NUT, SELF-LOCKING | 2 | |
| 11 | 91490-20020-00 | PIN, COTTER (91401-20020-00) | 2 | |
| 12 | 90105-08091-00 | BOLT, WASHER BASED | 4 | |
| 13 | 1E6-23441-00-00 | HOLDER, HANDLE UPPER | 2 | |
| 14 | 95811-08035-00 | BOLT, FLANGE | 4 | |
| 15 | 93332-00001-00 | BEARING | 1 | |
| 16 | 3HE-23416-00-00 | COVER, BALL RACE 2 | 1 | |
| 17 | 90179-25033-00 | NUT | 1 | |
| 18 | 90179-22330-00 | NUT, SPEC''L SHAPE | 1 | |
| 19 | 3XJ-23485-01-00 | PLATE, NUMBER | 1 | |
| 20 | 98503-06014-00 | SCREW, PAN HEAD (92501-06015) | 1 | |
| 21 | 90201-06571-00 | WASHER, PLATE | 1 | |
| 22 | 5X6-23395-00-00 | EMBLEM | 1 | |
| 23 | 34K-2319U-00-00 | CAP | 1 | |




# FUEL TANK

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 40T-24110-10-00 | FUEL TANK | 1 | CLEAN WHITE |
| 2 | 90480-18354-00 | GROMMET | 2 | |
| 3 | 24X-24144-00-00 | HOLDER, DAMPER | 2 | |
| 4 | 97313-06016-00 | BOLT | 4 | |
| 5 | 92995-06100-00 | WASHER, SPRING | 4 | |
| 6 | 90201-061A5-00 | WASHER, PLATE | 4 | |
| 7 | 90387-06387-00 | COLLAR | 2 | |
| 8 | 90201-06697-00 | WASHER, PLATE | 2 | |
| 9 | 97021-06030-00 | BOLT | 2 | |
| 10 | 92995-06100-00 | WASHER, SPRING | 2 | |
| 11 | 98903-06018-00 | SCREW, BIND | 1 | |
| 12 | 59V-24173-00-00 | BAND, TNK FITTING 1 | 1 | |
| 13 | 2K5-24500-00-00 | FUEL COCK ASSEMBLY 1 | 1 | |
| 14 | 214-24512-00-00 | . GASKET | 1 | |
| 15 | 1A0-24512-00-00 | . GASKET | 1 | |
| 16 | 619-24535-00-00 | . SCREW, LVR FITTING | 1 | |
| 17 | 90202-05187-00 | WASHER, PLATE | 2 | |
| 18 | 90149-06011-00 | SCREW | 2 | |
| 19 | 90445-11356-00 | HOSE | 1 | |
| 20 | 90467-10008-00 | CLIP | 2 | |
| 21 | 5X7-24611-01-00 | BODY, CAP (5X7-24611-00) | 1 | |
| 22 | 5X7-24612-00-00 | GASKET, CAP | 1 | |
| 23 | 90445-09252-00 | HOSE | 1 | |
| 24 | 39X-24181-00-00 | DAMPER, LOCATING 1 | 1 | |
| 25 | 23X-24184-00-00 | DAMPER, LOCATING 4 | 1 | |
| 26 | 5X6-2415F-01-00 | STAY, CHAMBER | 1 | |
| 27 | 98580-06010-00 | SCREW, PAN HEAD | 2 | |
| 28 | 90201-061A5-00 | WASHER, PLATE | 2 | |
| 29 | 40T-2412F-00-00 | BRACKET, SEAT | 1 | |


*CONTINUED ON NEXT FRAME ➤*




# FUEL TANK

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 30 | 98580-06012-00 | SCREW, PAN HEAD (92501-06012-00) | 2 | |
| 31 | 90201-061A5-00 | WASHER, PLATE | 2 | |
| 32 | 57H-24250-11-00 | GRAPHIC SET | 1 | |

# SEAT








43N010-4241


| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 39X-W2473-20-00 | SEMI-DBL-SEAT ASSEMBLYASSY . . . . . | 1 | RED |
| 2 | 23X-24731-20-00 | . COVER, DOUBLE SEAT . . . . . | 1 | |
| 3 | 22W-24741-00-00 | PAD, SEAT . . . . . | 2 | |
| 4 | 509-24724-00-00 | DAMPER, SEAT . . . . . | 1 | |
| 5 | 39W-24738-00-00 | BRACKET, SEAT . . . . . | 2 | |
| 6 | 95811-06012-00 | BOLT, FLANGE (95801-06012) . | 4 | |
| 7 | 5X6-24748-10-00 | BRACKET, SEAT . . . . . | 1 | |
| 8 | 97013-06012-00 | BOLT . . . . . | 2 | |
| 9 | 90201-061A5-00 | WASHER, PLATE . . . . . | 2 | |
| 10 | 97313-08018-00 | BOLT, HEXAGON . . . . . | 2 | |
| 11 | 92990-08100-00 | WASHER, SPRING . . . . . | 2 | |
| 12 | 90201-087F0-00 | WASHER, PLATE . . . . . | 2 | |





# FRONT WHEEL

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | (56A-25111-00-98) | HUB, FRONT | 1 | LOW GLOSS BLK |
| 2 | 90560-15227-00 | SPACER | 1 | |
| 3 | 93306-20209-00 | BEARING | 2 | |
| 4 | 93106-20021-00 | OIL SEAL, DD-TYPE | 2 | |
| 5 | 94416-21412-00 | RIM 1. 0 | 1 | |
| 6 | 56A-25104-00-00 | SPOKE SET, FRONT | 1 | |
| 7 | (94110-210F9-00) | 100/90-21 M23 (TT) | 1 | BRIDGESTONE |
| 8 | 94209-21229-00 | TUBE (80/100C-21 TR4) | 1 | BRIDGESTONE |
| 9 | 94330-21084-00 | BAND, RIM (70-80/100-21) | 1 | BRIDGESTONE |
| 10 | 4V5-25194-00-00 | SPACER, BEAD | 1 | |
| 11 | 3R4-25181-01-00 | AXLE, WHEEL | 1 | |
| 12 | 90387-152J3-00 | COLLAR | 1 | |
| 13 | 322-25118-00-00 | COVER, HUB DUST | 1 | |
| 14 | 90387-157L9-00 | COLLAR | 1 | |

# FRONT BRAKE-CALIPER





| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 56A-25831-00-00 | DISC, BRAKE | 1 | |
| 2 | 90109-06757-00 | BOLT | 4 | |
| 3 | 2HH-2580T-00-00 | CALIPER ASSEMBLY RH | 1 | |
| 4 | 56A-W0057-00-00 | . PISTON ASSEMBLY, CALIPER | 1 | |
| 5 | 56A-W0047-00-00 | . . CALIPER SEAL KIT | 1 | |
| 6 | 5R2-25937-00-00 | . BOOT 2 | 1 | |
| 7 | 56A-25937-00-00 | . BOOT 2 | 1 | |
| 8 | 51L-W0048-00-00 | . BLEED SCREW KIT | 1 | |
| 9 | 56A-25919-00-00 | . SUPPORT, PAD | 1 | |
| 10 | 56A-25919-10-00 | . SUPPORT, PAD | 1 | |
| 11 | 56A-W0046-00-00 | . BRAKE PAD KIT | 1 | |
| 12 | 56A-25926-00-00 | . BOLT | 1 | |
| 13 | 34X-25845-00-00 | . CAP, INDICATOR | 1 | |
| 14 | 95811-08040-00 | BOLT, FLANGE | 2 | |




# REAR WHEEL

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 57H-25311-00-98 | HUB, REAR | 1 | LOW GLOSS BLK |
| 2 | 90560-20226-00 | SPACER | 1 | |
| 3 | 93306-00418-00 | BEARING | 2 | |
| 4 | 93306-00406-00 | BEARING (B6004Z) | 2 | |
| 5 | 93106-28023-00 | OIL SEAL | 1 | |
| 6 | 40T-25321-00-98 | PLATE, BRAKE SHOE | 1 | LOW GLOSS BLK |
| 7 | 40T-W2536-00-00 | BRAKESHOE SET-2PCS | 2 | |
| 8 | 90507-20002-00 | SPRING, TENSION | 2 | |
| 9 | 1E6-25151-00-00 | CAMSHAFT | 1 | |
| 10 | 5X6-25355-00-00 | LEVER, CAMSHAFT | 1 | |
| 11 | 90101-06291-00 | BOLT | 1 | |
| 12 | 90387-200H1-00 | COLLAR | 1 | |
| 13 | 90508-29641-00 | SPRING, TORSION | 1 | |
| 14 | 93109-14021-00 | OIL SEAL, SDO-TYPE | 1 | |
| 15 | 94425-18415-00 | RIM 2. 0 | 1 | |
| 16 | 57H-25304-00-00 | SPOKE SET, REAR | 1 | |
| 17 | (94114-181F0-00) | 140/90-18 M22 (TT) | 1 | BRIDGESTONE |
| 18 | (94214-18231-00) | TUBE 140/80- 8 | 1 | |
| 19 | 94340-18086-00 | BAND, RIM (4.00-18) | 1 | BRIDGESTONE |
| 20 | 40T-25394-00-00 | SPACER, BEAD | 2 | |
| 21 | 3R4-25444-01-XX | SPROCKET, DRIVN 44T | 1 | ALTERNATE PART |
| | 3R4-25445-01-XX | SPROCKET, DRIVEN (45T) (39W-25445-01-00) | 1 | ALTERNATE PART |
| | 3R4-25446-01-XX | SPROCKET, DRIVN 46T | 1 | STD |
| | 3R4-25448-01-XX | SPROCKET, DRIVN 48T | 1 | ALTERNATE PART |
| | 3R4-25450-01-XX | SPROCKET, DRIVN 50T | 1 | ALTERNATE PART |
| | 3R4-25452-01-XX | SPROCKET, DRIVN 52T | 1 | ALTERNATE PART |
| 22 | 90109-08706-00 | BOLT | 6 | |
| 23 | 95611-08100-00 | NUT, U | 6 | |


*CONTINUED ON NEXT FRAME ➤*




# REAR WHEEL


| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 24 | 90201-081A6-00 | WASHER, PLATE | 6 | |
| 25 | 90387-200H2-00 | COLLAR | 1 | |
| 26 | 4V4-25367-00-00 | COVER, HUB DUST | 1 | |
| 27 | 23X-25327-00-00 | COVER, PLATE | 1 | |
| 28 | 93210-31114-00 | O-RING | 1 | |
| 29 | 56A-25388-01-00 | PULLER, CHAIN 1 | 1 | |
| 30 | 57H-25389-01-00 | PULLER, CHAIN 2 | 1 | |
| 31 | 90101-08699-00 | BOLT | 2 | |
| 32 | 95303-08700-00 | NUT | 2 | |
| 33 | 23X-25381-00-00 | AXLE, WHEEL | 1 | |
| 34 | 90209-21243-00 | WASHER, PLATE (90201-210G3) | 1 | |
| 35 | 90209-18244-00 | WASHER, PLATE (90201-180G2) | 1 | |
| 36 | 90185-18104-00 | NUT, SELF-LOCKING | 1 | |
| 37 | 94585-20112-00 | 520DS-112L112L) | 1 | |
| 38 | 94685-20001-00 | . JOINT CHAIN | 1 | |
| 39 | 23X-25371-00-00 | BAR, TENSION | 1 | |
| 40 | 93399-99910-00 | BEARING | 1 | |
| 41 | 93112-19006-00 | OIL SEAL | 2 | |
| 42 | 90102-08034-00 | BOLT, WITH HOLE | 1 | |
| 43 | 90109-08370-00 | BOLT | 1 | |
| 44 | 95601-08200-00 | NUT, SELF LOCKING | 2 | |
| 45 | 92901-08600-00 | WASHER, PLATE | 1 | |
| 46 | 91490-20020-00 | PIN, COTTER (91401-20020-00) | 2 | |
| 47 | 90387-083F0-00 | COLLAR | 1 | |
| 48 | 93210-14167-00 | O-RING | 2 | |

# STEERING HANDLE-CABLE





| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 23X-26111-00-00 | HANDLEBAR | 1 | |
| 2 | 4V4-26241-01-00 | GRIP LH (4V4-26341-00) (L.H.) | 1 | |
| 3 | 1LX-26242-01-00 | GRIP (RIGHT) | 1 | |
| 4 | 23X-26243-00-00 | TUBE, THRTL GUIDE | 1 | |
| 5 | 90338-12192-00 | PLUG | 1 | |
| 6 | 23X-26281-00-00 | CAP, GRIP UPPER | 1 | |
| 7 | 431-26282-01-98 | CAP, GRIP LOWER | 1 | LOW GLOSS BLK |
| 8 | 5X2-2628H-01-00 | CAP, WIRE | 1 | |
| 9 | 98706-04012-00 | SCREW, FLAT HEAD | 2 | |
| 10 | 98586-05016-00 | SCREW, PAN HEAD | 2 | |
| 11 | 40T-26311-00-00 | CABLE, THROTTLE 1 | 1 | |
| 12 | 510-26329-00-00 | . CAP, RUBBER | 1 | |
| 13 | 40T-26335-00-00 | CABLE, CLUTCH | 1 | |
| 14 | 382-26372-01-00 | . COVER, HANDLE LEVER | 1 | |
| 15 | 90179-08401-00 | NUT | 1 | |
| 16 | 90123-08090-00 | BOLT | 1 | |
| 17 | 90465-16258-00 | CLAMP | 2 | |
| 18 | 91311-06016-00 | BOLT | 2 | |
| 19 | 90201-061A5-00 | WASHER, PLATE | 2 | |

# FRONT MASTER CYLINDER





| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 56A-25870-01-00 | MSTR CYLINDER SUB ASSEMBLYSUB ASSEMBLY .. | 1 | |
| 2 | 56A-W0041-00-00 | . CYLINDER KIT, MASTER .... | 1 | |
| 3 | 56A-25854-00-00 | . DIAPHRAGM, RESERVOIR .. | 1 | |
| 4 | 2VN-25852-01-00 | . CAP, RESERVOIR ..... | 1 | |
| 5 | 98706-04012-00 | . SCREW, FLAT HEAD ..... | 2 | |
| 6 | 56A-25867-00-00 | BRACKET, MASTER CYLINDER | 1 | |
| 7 | 97016-06025-00 | BOLT ..... | 2 | |
| 8 | 92906-06600-00 | WASHER ..... | 2 | |
| 9 | 56A-25872-00-00 | HOSE, BRAKE 1 ..... | 1 | |
| 10 | 90201-10118-00 | WASHER, PLATE ..... | 4 | |
| 11 | 90401-10034-00 | BOLT, UNION ..... | 2 | |
| 12 | 56A-26372-01-00 | COVER, HANDLE LEVER 1 ... | 1 | |




# STAND-FOOTREST


| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 39X-27311-00-00 | STAND, SIDE | 1 | |
| 2 | 56A-27200-00-00 | PEDAL, BRAKE | 1 | |
| 3 | 95811-08016-00 | BOLT, FLANGE | 1 | |
| 4 | 90201-08730-00 | WASHER, PLATE | 1 | |
| 5 | 90506-16372-00 | SPRING, TENSION | 1 | |
| 6 | 39X-26351-00-00 | CABLE, BRAKE | 1 | |
| 7 | 91790-08021-00 | PIN, CLEVIS | 1 | |
| 8 | 92901-08600-00 | WASHER, PLATE | 1 | |
| 9 | 91401-25020-00 | PIN, COTTER | 1 | |
| 10 | 90249-12008-00 | PIN | 1 | |
| 11 | 90175-06016-00 | NUT, WING | 1 | |
| 12 | 23X-27411-02-00 | FOOTREST 1 | 1 | |
| 13 | 23X-27421-03-00 | FOOTREST 2 | 1 | |
| 14 | 90240-10101-00 | PIN, CLEVIS | 2 | |
| 15 | 91401-25020-00 | PIN, COTTER | 2 | |
| 16 | 90508-20583-00 | SPRING, TORSION | 1 | |
| 17 | 90201-10119-00 | WASHER, PLATE | 2 | |
| 18 | 90101-06586-00 | BOLT | 1 | |
| 19 | 95380-06700-00 | NUT | 1 | |




# ELECTRICAL 1

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 23X-85540-20-00 | CDI UNIT ASSEMBLY | 1 | |
| 2 | 2A7-85546-00-00 | BAND | 1 | |
| 3 | 25G-83936-01-00 | BAND, SWITCH CORD | 1 | |
| 4 | 437-83936-11-00 | BAND, SWITCH CORD | 3 | |
| 5 | 43G-82310-40-00 | IGNITION COIL ASSEMBLY | 1 | |
| 6 | 98503-06014-00 | SCREW, PAN HEAD (92501-06015) | 2 | |
| 7 | 81E-82370-20-00 | PLUG CAP ASSEMBLY | 1 | |
| 8 | 5X1-82519-01-00 | WIRE, EARTH LEAD | 1 | |

# HANDLE SWITCH-LEVER







56AH10-5320

| Ref. No. | Part Number | Description | Qty | Remarks |
|---|---|---|---|---|
| 1 | 38V-82911-00-00 | HOLDER, LEVER 1 | 1 | |
| 2 | 38V-82913-00-00 | HOLDER, LEVER LOWER 1 | 1 | |
| 3 | 23X-83912-00-00 | LEVER L | 1 | |
| 4 | 90109-06797-00 | BOLT | 1 | |
| 5 | 90201-082A9-00 | WASHER, PLATE | 1 | |
| 6 | 95616-06100-00 | NUT, U | 1 | |
| 7 | 98506-05018-00 | SCREW, PAN HEAD | 2 | |
| 8 | 92906-05100-00 | WASHER, SPRING | 2 | |
| 9 | 55Y-83922-00-00 | LEVER 2 | 1 | |
| 10 | 90109-06577-00 | BOLT | 1 | |
| 11 | 95616-06100-00 | NUT, U | 1 | |
| 12 | 90149-06153-00 | SCREW, SPEC''L SHAPE | 1 | |
| 13 | 90170-06010-00 | NUT | 1 | |
| 14 | 90501-10312-00 | SPRING, COMPRESSION | 1 | |
| 15 | 23X-83976-00-00 | SWITCH, HANDLE 1 | 1 | |
| 16 | 437-83936-01-00 | BAND, SWITCH CORD | 2 | |