

PARTS CATALOGUE
MODEL YEAR 1995
FZR600RG (3HHE) U49
FZR600RGC (3UU6) CALIFORNIA

3HHE	Frame Serial No.	3HH-079101 and following
	Engine Serial No.	3HH-079101 and following
3UU6	Frame Serial No.	3UU-015101 and following
	Engine Serial No.	3UU-015101 and following

OWNERS	LIT-11626-09-28
ASSEMBLY	LIT-11666-07-60
SERVICE	LIT-11616-FZ-00

Color Code	Color Name	Abbrevi-ation
06G	NEW YAMAHA BLACK	NYB/VDMC1
251	REDDISH YELLOW COCKTAIL 1	RYC1





YAMAHA GENUINE Parts & Accessories

FOREWORD

-INTRODUCTION-
To The Yamaha Parts Fiche

This parts fiche lists parts and sub-assemblies for the FZR600RG/RGC. When preparing a parts order, please refer to the most recently updated microfiche for this model.

THE YAMAHA PARTS FICHE

SYMBOLS

[ ]	Inactive, no longer available
U.R.	Use size (thickness) and/or number as required
U.N.	Use as many as you need
T	Number of teeth in a gear
V	Voltage for light bulbs
S	"S" type oil seal or "S" type circlip
SD,SO,SW	"SD", "SO", or "SW" type oil seal
E,R	"E" or "R" type circlip
F/No.	Frame No. (Applicable Machine No.)
L.M.	Locally made
O.L.	Obtain locally
AP	Alternate Part

SUPERSEDED PART NUMBERS

If part 'A' has been superseded by part 'B', the superseding part number "B" will appear in the part number listing with the superseded part number "A" appearing in parentheses immediately following the description.

EXAMPLE:

Ref. No.	Part No.	Description	Qty.
	(Part 'B')	(Part 'A')	
8	123-45678-00-00	CYLINDER (111-12345-00-00)	1

A part that has been supersede to a kit may be identified by a 99999-00000-00 part number appearing in the part number column. The old superseded part number will appear in parentheses immediately following the description. Listed directly below the 99999 part number will be those parts making up the kit. The description of the parts making up the kit will be preceded by a small black dot (.) and the description will be indented one letter space.

EXAMPLE:

Ref. No.	Part No.	Description	Qty.
8	99999-12345-00	CYLINDER (111-12345-00-00)	1
	234-56789-00-00	• HEAD, CYLINDER	1

SIZES

Except for steel balls (ball sizes are indicated in inches), all parts sizes are indicated in millimeters as in the following examples:

Hose (Rubber or Vinyl) ..... Inside Diameter - Length

O-Ring ..... Section Area - Inside Diameter

Washer, Shim, Collar ..... Inside Diameter - Outside Diameter
Thickness (Length)

ASSEMBLIES AND COMPONENT PARTS

Assemblies and their component parts, are identified by an indention of one letter space, and the description is preceded by a dot (.). If two main assemblies are listed, and have the same basic description (i.e.: left and right sides of the same assembly), one will immediately follow the other. If each of these main assemblies is made up of almost the same components, these component parts will be listed immediately under the second main assembly line and will be indicated, as noted above.


If the component is the same for both main assemblies, the quantity indicated will be the total required. If the component is not the same for both main assemblies, the quantity for each separate item will be listed separately.


EXAMPLE:

Description	Qty
CARBURETOR ASSY, LEFT	1
CARBURETOR ASSY, RIGHT	1
. JET, PILOT	2
. NOZZLE, MAIN	2
. LEVER, STARTER, LEFT	1
. LEVER, STARTER, RIGHT	1

APPLICABLE SERIAL NO.

(1) Engine Serial No. (2) Frame Serial No.






FOREWORD

THE YAMAHA PART NUMBER

The Yamaha part number consists of 12 digits. Each number represents a specific piece of information relating to a replacement part. The following is a guide for reading and interpreting the Yamaha part number.

BASIC PART NUMBER CONFIGURATION:



MODEL CODE NUMBER

FIRST THREE DIGITS . . . 000-00000-00-00


Every model in each Yamaha product line is assigned a model number to identify that particular model. All component parts are given the model code number relating to the model on which they were first used.

Example: 4DU-00000-00-00 identifies the XJ600SE.
3FA-00000-00-00 identifies the YFA1E.

BASIC CODE NUMBER


MIDDLE FIVE DIGITS . . . 000-00000-00-00

These "MIddle Five Digits" indicate the type of part i.e., piston, rings, lower units, etc. The five digits are broken down as follows:



The "Major Classification" indicates the section to which the parts belong, i.e., engine, electrical etc. The "Intermediate" and "Minor Classifications" indicate more specific details.

Example:



DESIGN CODE NUMBER: 000-00000-00-00

The design code distinguishes like component parts from one another when specification differences are involved. For example, distinguishing a standard size piston ring from an oversized piston ring.

Example:

4BR-11610- 0 **0-00** Standard Piston Ring Set for XJ600SE
4BR-11610- 2 **0-00** Oversize Piston Ring Set for XJ600SE

DESIGN CHANGE CODE NUMBER: 000-00000-00-00

This code number is used to identify a difference between a new component part and old one when a new part is created by changing the old one.

Example: YFZ350E

2GU-11610-0 0 **-00** PISTON RING SET, STD. - ORIGINAL
2GU-11610-0 1 **-00** PISTON RING SET, STD. - FIRST DESIGN CHANGE


Only major changes to performance, durability, quality, appearance, cost or interchangeability will affect a part number change.

COLOR CODE & SIZE CODE NUMBER: 000-00000-00-00

When applicable, the last two digits of the part number identify:

1. Color Code: The painted color or type of plating or surface treatment used on certain parts.
2. Size Code: The last two digits are also used to show the size of parts (mm). Such as the thickness of shims or the size of pistons.

HARDWARE (Fastener) PART NUMBER CONFIGURATION:



TYPE:

A fastener part number always begins with the number "9" followed by either a 0, 1, 2, 3, 4, 5, 6, 7 or 8 designating one of eight major divisions within this group.

FOREWORD

Example:

9 0 000-00000-00 "0" designates various types.
9 1 000-00000-00 "1" designates bolts, cotter pins, etc.
9 2 000-00000-00 "2" designates screw, nuts, etc.
9 3 000-00000-00 "3" designates oil seals, o-rings, bearings, etc.
9 4 000-00000-00 "4" designates spark plugs.
9 5 000-00000-00 "5" designates bolts and nuts.
9 7 000-00000-00 "7" designates ISO bolts.
9 8 000-00000-00 "8" designates ISO screws and nuts.

The only major divisions which the mechanic should become familiar with are those related to the general hardware (nuts, bolts, and washers), since these are the most commonly used and most often replaced items. By knowing how to interpret the part number, the dimensions of a piece of hardware can be determined. This can be very helpful during major engine repair, and general parts replacement.

BOLT EXAMPLE:

91311 - 06 018 - 00

6mm outside diameter — 18mm in length

EXCEPTION:

It is NOT possible to identify the LENGTH of bolts having a 901 prefix. Only the bolt diameter can be identified with this number.

NUT AND WASHER EXAMPLE:


95301 - 08600 - 00 NUT

8mm inside diameter

90201 - 25290 - 00 WASHER

25mm inside diameter


CYLINDER HEAD



3HE332-9010

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-11101-00-00	CYLINDER HEAD ASSEMBLY .	1	FOR NON-CA
	3HW-11101-00-00	CYLINDER HEAD ASSEMBLY .	1	FOR CA ONLY
2	1WG-11133-10-00	. GUIDE, INTAKE VALVE	16	
3	93440-10153-00	. CIRCLIP	16	
4	99510-08016-00	. PIN, DOWEL	12	
5	90340-12112-00	. PLUG, STRAIGHT SCREW ...	6	
6	90105-06384-00	. BOLT, WASHER BASED	24	
7	90338-08174-00	. PLUG	12	
8	90116-06437-00	BOLT, STUD	8	
9	90201-087K2-00	WASHER, PLATE	12	
10	90179-08530-00	NUT	12	
11	NGK-CR9E0-00-00	PLUG, SPARK (NGK R CR9E) .	4	
12	3HE-11181-00-00	GASKET, CYLINDER HEAD 1 .	1	
13	2TK-11191-00-00	COVER, CYLINDER HEAD 1 ..	1	
14	1WG-11193-00-00	GASKET, HEAD COVER 1	1	
15	90109-064F0-00	BOLT	8	
16	90209-11262-00	WASHER	8	
17	2GH-1111G-00-00	RUBBER, MOUNT 1	8	


CYLINDER



3HE332-9020

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-11310-00-00	CYLINDER	1	FOR NON-CA
	3HW-11310-00-00	CYLINDER	1	FOR CA ONLY
2	93210-63442-00	O-RING	4	
3	99510-12016-00	PIN, DOWEL	2	
4	3HE-11351-00-00	GASKET, CYLINDER	1	
5	90153-06045-00	SCREW, HEXAGON	2	
6	90430-06014-00	GASKET	2	


CRANKSHAFT - PISTON



Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-11411-00-00	CRANKSHAFT	1	
2	93101-26156-00	OIL SEAL	1	
3	1WG-11416-00-00	PLANE BEARING, CRANKSHAFT 1	12	BLUE
	1WG-11416-10-00	PLANE BEARING, CRANKSHAFT 1	12	BLACK
	1WG-11416-20-00	PLANE BEARING, CRANKSHAFT 1	12	BROWN
	1WG-11416-30-00	PLANE BEARING, CRANKSHAFT 1	12	GREEN
	1WG-11416-40-00	PLANE BEARING, CRANKSHAFT 1	12	YELLOW
4	3HE-11631-00-00	PISTON (STD)	4	
	3HE-11636-00-00	PISTON (0.50MM O/S)	4	AP
	3HE-11638-00-00	PISTON (1.00MM O/S)	4	AP
5	3HE-11610-00-00	PISTON RING SET (STD)	4	
	3HE-11610-20-00	PISTON RING SET (0.50MM O/S)	4	AP
	3HE-11610-40-00	PISTON RING SET (1.00MM O/S)	4	AP
6	3HE-11633-00-00	PIN, PISTON	4	
7	93450-17044-00	CIRCLIP	8	
8	3HE-11650-01-00	CONNECTING ROD ASSEMBLY	4	
9	1WG-11654-00-00	. BOLT, CONNECTING ROD	2	
10	90179-07531-00	. NUT	2	
11	1WG-11656-00-00	PLANE BEARING, CONNECTING ROD	8	BLUE
	1WG-11656-10-00	PLANE BEARING, CONNECTING ROD	8	BLACK
	1WG-11656-20-00	PLANE BEARING, CONNECTING ROD	8	BROWN
	1WG-11656-30-00	PLANE BEARING, CONNECTING ROD	8	GREEN

CONTINUED ON NEXT FRAME ➤

VALVE




1WG010-6040

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-12111-01-00	VALVE, INTAKE	8	
2	3HE-12121-00-00	VALVE, EXHAUST	8	
3	1WG-12116-00-00	SEAT, VALVE SPRING	16	
4	3HE-12113-00-00	SPRING, VALVE INNER	16	
5	1WG-12117-00-00	RETAINER, VALVE SPRING	16	
6	1WG-12118-00-00	COTTER, VALVE	32	
7	1WG-12119-00-00	SEAL, VALVE STEM	16	
8	1WG-12153-09-00	LIFTER, VALVE (O/S)	16	WHITE
	1WG-12153-21-00	LIFTER, VALVE	16	BLUE
	1WG-12153-30-00	LIFTER, VALVE (1WG-12153-31-00)	16	RED
9	1HX-12168-00-00	PAD, ADJUSTING 2 (1.20)	16	
	1HX-12168-20-00	PAD, ADJUSTING 2 (1.25)	16	
	1HX-12168-40-00	PAD, ADJUSTING 2 (1.30)	16	
	1HX-12168-60-00	PAD, ADJUSTING 2 (1.35)	16	
	1HX-12168-80-00	PAD, ADJUSTING 2 (1.40)	16	
	1HX-12168-A0-00	PAD, ADJUSTING 2 (1.45)	16	
	1HX-12168-F0-00	PAD, ADJUSTING 2 (1.50)	16	
	1HX-12168-H1-00	PAD, ADJUSTING 2 (1.55)	16	
	1HX-12168-K1-00	PAD, ADUSTING 2 (1.60)	16	
	1HX-12168-M1-00	PAD, ADJUSTING 2 (1.65)	16	
	1HX-12168-R1-00	PAD, ADJUSTING 2 (1.70)	16	
	1HX-12168-U1-00	PAD, ADJUSTING 2 (1.75)	16	
	1HX-12168-W1-00	PAD, ADJUSTING 2 (1.80)	16	
	1HX-12168-Y1-00	PAD, ADJUSTING 2 (1.85)	16	
	1HX-12169-11-00	PAD, ADJUSTING 2 (1.90)	16	
	1HX-12169-31-00	PAD, ADJUSTING 2 (1.95)	16	
	1HX-12169-50-00	PAD, ADJUSTING 2 (2.00)	16	
	1HX-12169-70-00	PAD, ADJUSTING 2 (2.05)	16	

CONTINUED ON NEXT FRAME ➤


VALVE




1WG010-6040

Ref. No.	Part Number	Description	Qty	Remarks
9	1HX-12169-90-00	PAD, ADJUSTING 2 (2.10)	16	
	1HX-12169-E0-00	PAD, ADJUSTING 2 (2.15)	16	
	1HX-12169-G0-00	PAD, ADJUSTING 2 (2.20)	16	
	1HX-12169-J0-00	PAD, ADJUSTING 2 (2.25)	16	
	1HX-12169-L0-00	PAD, ADJUSTING 2 (2.30)	16	
	1HX-12169-N0-00	PAD, ADJUSTING 2 (2.35)	16	
	1HX-12169-T0-00	PAD, ADJUSTING 2 (2.40)	16	

CAMSHAFT - CHAIN






FWD

3HE332-9050

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-12171-00-00	CAMSHAFT 1	1	FOR NON-CA
	3UU-12171-00-00	CAMSHAFT 1	1	FOR CA ONLY
2	3HE-12181-00-00	CAMSHAFT 2	1	FOR NON-CA
	3UU-12181-00-00	CAMSHAFT 2	1	FOR CA ONLY
3	1WG-12176-00-00	SPROCKET, CAM CHAIN	2	
4	90105-07385-00	BOLT, WASHER BASED	4	
5	94581-32118-00	CHAIN (D.I.D. 215F DHA 118L)	1	
6	94681-32021-00	. JOINT, CHAIN (D.I.D.215F-LJ)	1	
7	1WG-12241-00-00	GUIDE, STOPPER 2	1	
8	3GM-12210-00-00	TENSIONER ASSEMBLY, CAM CHAIN	1	
9	90109-112F1-00	BOLT	1	
10	4BE-12213-00-00	GASKET, TENSIONER CASE	1	
11	91316-06025-00	BOLT	2	
12	3HE-12251-00-00	DAMPER, CHAIN 1	1	
13	3HE-12252-00-00	DAMPER, CHAIN 2	1	
14	90109-065A8-00	BOLT	2	


WATER PUMP



3HH110-3060

Ref. No.	Part Number	Description	Qty	Remarks
1	3TJ-Y1242-00-00	WATER PUMP ASSEMBLY	1	
2	1WG-12439-00-00	. O-RING	1	
3	91311-06025-00	. BOLT, SOCKET HEAD	2	
4	95026-06012-00	. BOLT, FLANGE	1	
5	90430-06014-00	. GASKET	1	
6	93210-33133-00	. O-RING	1	
7	91316-06035-00	BOLT	2	
8	3HE-12579-00-00	HOSE 4	1	
9	1WG-12481-00-00	PIPE 1	1	
10	93210-21190-00	O-RING	2	
11	91316-06012-00	BOLT	2	
12	1WG-12446-01-00	JOINT	1	
13	93210-17746-00	O-RING	2	
14	91316-06040-00	BOLT, SOCKET HEAD	3	
15	91316-06025-00	BOLT	1	
16	1WG-12482-00-00	PIPE 2	1	
17	1WG-12483-00-00	PIPE 3	1	
18	93210-15566-00	O-RING	2	
19	91316-06012-00	BOLT	2	
20	3HE-12576-00-00	HOSE 1	1	
21	3HE-12577-00-00	HOSE 2	1	
22	46X-12410-00-00	THERMOSTAT ASSEMBLY	1	
23	1WG-12417-00-00	HOUSING, THERMOSTAT	1	
24	1WG-12413-01-00	COVER, THERMOSTAT	1	
25	91311-06020-00	BOLT, SOCKET HEAD	2	
26	90450-32051-00	HOSE CLAMP ASSEMBLY	2	
27	90450-28014-00	HOSE CLAMP ASSEMBLY	4	


RADIATOR - HOSE



Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-12461-00-00	RADIATOR ASSEMBLY	1	
2	3HE-12405-00-00	BLOWER ASSEMBLY	1	
3	1AA-12630-00-00	. MOTOR ASSEMBLY	1	
4	1UF-12611-00-00	. FAN	1	
5	98507-05008-00	. SCREW, PAN HEAD	3	
6	92901-05600-00	. WASHER, PLATE	3	
7	90119-06044-00	. BOLT, WITH WASHER	3	
8	2TK-12590-00-00	CONDUCTION ASSEMBLY	1	
9	22W-12462-00-00	. CAP, RADIATOR	1	
10	95826-06010-00	BOLT, FLANGE	2	
11	90450-32051-00	HOSE CLAMP ASSEMBLY	4	
12	90445-096E8-00	HOSE	1	
13	90467-08003-00	CLIP	2	
14	90338-20188-00	PLUG	1	
15	90480-15483-00	GROMMET	2	
16	90387-074W0-00	COLLAR	2	
17	95817-06025-00	BOLT, FLANGE	2	
18	3HE-12578-00-00	HOSE 3	1	
19	3HE-12588-10-00	HOSE 5	1	
20	25G-83936-01-00	BAND, SWITCH CORD	1	

FWD

3HH110-1070




3HE332-9080

OIL PUMP

Ref. No.	Part Number	Description	Qty	Remarks
1	1WG-13330-01-00	PUMP SHAFT ASSEMBLY	1	
2	1WG-13316-00-00	COVER, PUMP	1	
3	90201-113K2-00	WASHER, PLATE	1	
4	93603-17070-00	PIN, DOWEL	1	
5	1WG-13310-00-00	ROTOR ASSEMBLY 1	1	
6	93603-09106-00	PIN, DOWEL	2	
7	1WG-13336-00-00	HOUSING, ROTOR	1	
8	98580-06020-00	SCREW, PAN HEAD (98501-06020)	1	
9	99510-08012-00	PIN, DOWEL	1	
10	1WG-13329-00-00	GASKET, PUMP COVER	1	
11	90110-06130-00	BOLT, HEXAGON SOCKET HEAD	3	
12	1WG-13412-00-00	HOUSING, STRAINER	1	
13	4H7-13411-02-00	STRAINER, OIL	1	
14	90110-06225-00	BOLT, HEXAGON SOCKET HEAD	2	


OIL COOLER



3HH110-1090

Ref. No.	Part Number	Description	Qty	Remarks
1	3TJ-13461-00-00	PLATE, ADAPTOR	1	
2	90401-20145-00	BOLT, UNION	1	
3	93210-87723-00	O-RING	1	
4	3FV-13440-00-00	ELEMENT ASSEMBLY, OIL CLEANER	1	
5	11H-13490-00-00	RELIEF VALVE ASSEMBLY	1	
6	93210-10096-00	O-RING	1	
7	1WG-13417-00-00	COVER, STRAINER	1	
8	3HE-13414-10-00	GASKET, STRAINER COVER	1	
9	91316-06025-00	BOLT	14	
10	99510-08016-00	PIN, DOWEL	2	
11	3VD-13455-00-00	PLUG	1	
12	214-11198-01-00	GASKET	1	
13	90465-10306-00	CLAMP	1	
14	3HE-13161-00-00	PIPE, DELIVERY 1	1	
15	91316-06012-00	BOLT	1	
16	90401-10106-00	BOLT, UNION	2	
17	90430-10171-00	GASKET	4	


INTAKE



3HHE110-5100

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-13586-00-00	JOINT, CARBURETOR 1	2	
2	3HE-13596-00-00	JOINT, CARBURETOR 2	1	FOR CA ONLY
	3HE-13596-00-00	JOINT, CARBURETOR 2	2	FOR NON-CA
3	3HW-13596-00-00	JOINT, CARBURETOR 2	1	FOR CA ONLY
4	91316-06020-00	BOLT	8	
5	90450-49020-00	HOSE CLAMP ASSEMBLY	4	
6	3HE-14411-00-00	CASE, AIR CLEANER 1	1	FOR NON-CA
	3HW-14411-00-00	CASE, AIR CLEANER 1	1	FOR CA ONLY
7	1WG-14421-00-00	CASE, AIR CLEANER 2	1	
8	1VJ-14462-00-00	SEAL	1	
9	97780-50125-00	SCREW, TAPPING	11	
10	1WG-14451-00-00	ELEMENT, AIR CLEANER	1	
11	3HE-14412-00-00	CAP, CLEANER CASE 1	1	
12	5T0-14457-00-00	SEAL	1	
13	3HE-14453-00-00	JOINT, AIR CLEANER 1	4	
14	90460-58015-00	CLAMP, HOSE	4	
15	90445-11452-00	HOSE	1	
16	90467-10008-00	CLIP, SCISSOR	3	
17	4X7-2149Y-00-00	FILTER ASSEMBLY	1	
18	90445-115E8-00	HOSE	1	
19	98507-05016-00	SCREW, PAN HEAD	4	
20	92901-05600-00	WASHER, PLATE	4	
21	31A-14435-00-00	GROMMET	1	FOR CA ONLY

EMISSION CONTROL DEVICE (CALIFORNIA




3UU110-0110

Ref. No.	Part Number	Description	Qty	Remarks
1	31A-14419-00-00	PIPE	1	
2	3BM-14714-00-00	GASKET, MUFFLER	4	
3	3HW-14872-00-00	PIPE 2	1	
4	90450-22052-00	. HOSE CLAMP ASSEMBLY	2	
5	3HW-14873-00-00	PIPE 3	1	
6	90450-22052-00	. HOSE CLAMP ASSEMBLY	2	
7	2LJ-14883-00-00	HOSE, BEND 3	4	
8	90468-08104-00	CLIP	8	
9	3HW-14808-00-00	REED VALVE ASSEMBLY	1	
10	90480-14229-00	GROMMET	4	
11	90387-07391-00	COLLAR	4	
12	95027-06025-00	BOLT, FLANGE	4	
13	2LJ-14874-00-00	PIPE 4	1	
14	2LJ-14881-00-00	HOSE, BEND 1	2	
15	2LJ-14882-00-00	HOSE, BEND 2	1	
16	90467-17089-00	CLIP	1	
17	3HF-14840-00-00	AIR CUT VALVE ASS''Y	1	
18	90462-20188-00	CLAMP	1	
19	98506-06016-00	SCREW, PANHEAD (92506-06016-00)	1	
20	92906-06100-00	WASHER, SPRING	1	
21	92906-06600-00	WASHER	1	
22	90445-090G9-00	HOSE	1	
23	90467-08092-00	CLIP	2	
24	3HW-14885-00-00	HOSE, BEND 5	1	
25	3HW-14875-00-00	PIPE 5	1	
26	95026-06012-00	BOLT, FLANGE	2	
27	3HW-14884-00-00	HOSE, BEND 4	1	
28	90467-14015-00	CLIP	1	

CONTINUED ON NEXT FRAME ➤


EMISSION CONTROL DEVICE (CALIFORNIA

Ref. No.	Part Number	Description	Qty	Remarks
29	90464-30040-00	CLAMP	2	
30	90464-23041-00	CLAMP	1	



3UU110-0110

CARBURETOR




3HHE110-5120

Ref. No.	Part Number	Description	Qty	Remarks
1	3HH-14901-04-00	CARBURETOR ASSEMBLY 1 .	1	FOR NON-CA
	3UU-14901-04-00	CARBURETOR ASSEMBLY 1 .	1	FOR CA ONLY
2	3HH-14902-04-00	CARBURETOR ASSEMBLY 2 .	1	NON-CA
	3UU-14902-04-00	CARBURETOR ASSEMBLY 2 .	1	FOR CA ONLY
3	3HH-14903-04-00	CARBURETOR ASSEMBLY 3 .	1	FOR NON-CA
	3UU-14903-04-00	CARBURETOR ASSEMBLY 3 .	1	FOR CA ONLY
4	3HH-14904-04-00	CARBURETOR ASSEMBLY 4 .	1	FOR NON-CA
	3UU-14904-04-00	CARBURETOR ASSEMBLY 4 .	1	FOR CA ONLY
5	1A8-14953-00-00	. WASHER	1	
6	256-14997-00-00	. SEAL	1	4
	256-14997-00-00	. SEAL	2	3
7	98580-04010-00	. SCREW, PAN HEAD	2	
8	98507-05016-00	. SCREW, PAN HEAD	2	
9	92906-05100-00	. WASHER, SPRING	2	
10	92906-05600-00	. WASHER, PLATE	2	
11	3EN-14243-00-00	. PLATE	1	
12	3EN-14239-00-00	. SEAL	1	
13	3GM-14147-00-00	. O-RING	1	
14	1AE-14565-00-00	. SCREW	1	
15	137-14153-00-00	. WASHER, MAIN JET	1	
16	1AE-14147-00-00	. O-RING	1	
17	3EN-1411E-00-00	. BLOCK JET ASSEMBLY (3EN-1411A-00-00)	1	
18	3GM-14997-00-00	. SEAL	1	
19	3HE-14933-00-00	. SPRING, DIAPHRAGM	1	
20	3HE-14940-00-00	. DIAPHRAGM ASSEMBLY . . .	1	
21	3HE-14985-00-00	. FLOAT	1	
22	353-14186-00-00	. PIN, FLOAT	1	
23	3HH-14107-10-00	. NEEDLE VALVE SET	1	

CONTINUED ON NEXT FRAME ➤

CARBURETOR




3HHE110-5120

Ref. No.	Part Number	Description	Qty	Remarks
24	3EN-14147-00-00	. O-RING	1	
25	12R-14191-00-00	. PLUG, DRAIN	1	
26	98507-05012-00	. SCREW, PAN HEAD	1	
	98507-05012-00	. SCREW, PAN HEAD	2	
27	3EN-1410A-00-00	. STARTER SET	1	
28	12R-14105-00-00	. PILOT SCREW SET	1	
29	3HH-1490J-00-00	. NEEDLE SET	1	
30	3G2-1423A-72-00	. JET, MAIN (107.5)	1	
31	3EN-14141-90-00	. NOZZLE, MAIN	1	
32	4G0-14142-32-A0	. JET, PILOT (32.5)	1	
33	830-1423A-77-00	. JET, PILOT AIR (132.5)	1	
34	3G2-14231-10-00	. JET, POWER (50)	1	FOR CA ONLY
	3G2-1423A-61-00	. JET, STARTER (52.5)	1	FOR NON-CA
35	3HE-1411A-00-00	. BLOCK JET ASSEMBLY	1	
36	1AE-14227-00-00	. O-RING	1	
37	3F9-14118-00-00	. CAP	1	
38	3HE-14103-00-00	THROTTLE SCREW SET	1	
39	95380-05600-00	NUT	1	
40	2GV-14953-00-00	WASHER	1	
41	3EN-14997-00-00	SEAL	6	
42	3HE-14163-00-00	SPACER	2	
43	3EN-14197-00-00	PIPE	2	
44	8U9-14139-00-00	CLIP, PIPE	2	
45	3EN-14988-00-00	PIPE, STARTER CONNECTING	1	
46	822-14147-00-00	O-RING	4	
47	17A-14251-00-00	NIPPLE	2	
48	3HE-14148-00-00	PIPE	1	
49	95601-06200-00	NUT, U FLANGE	1	
50	92990-06600-00	WASHER, PLATE	1	

CONTINUED ON NEXT FRAME ➤


CARBURETOR



3HHE110-5120

Ref. No.	Part Number	Description	Qty	Remarks
51	3EN-1490K-00-00	STOP SCREW SET	3	
52	3EN-14261-00-00	HOLDER	2	
53	98507-05008-00	SCREW, PAN HEAD	1	


EXHAUST (NON-CALIFORNIA)



3HE351-0130

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-14602-00-00	EXHAUST PIPE COMP.	1	
2	90101-06576-00	. BOLT	4	
3	92906-06600-00	. WASHER	4	
4	3YF-14613-01-00	GASKET, EXHAUST PIPE	4	
5	90179-06499-00	NUT	8	
6	95816-08030-00	BOLT, FLANGE	1	
7	90201-08730-00	WASHER, PLATE	1	
8	3HH-14710-10-00	MUFFLER ASSEMBLY 1	1	
9	3HE-14755-00-00	. GASKET, SILENCER	1	
10	95816-08045-00	. BOLT, FLANGE	1	
11	95817-08012-00	BOLT, FLANGE	1	


EXHAUST 2 (CALIFORNIA ONLY)



3UU110-1130

Ref. No.	Part Number	Description	Qty	Remarks
1	3HW-14610-00-00	EXHAUST PIPE ASSEMBLY 1 .	1	
2	90101-06576-00	. BOLT	4	
3	92906-06600-00	. WASHER	4	
4	3FH-14821-01-00	. ARM, SHAFT (VALVE)	1	
5	3FH-14811-00-00	. HOUSING	1	
6	3FH-14815-00-00	. GASKET	1	
7	2TK-14845-00-00	. DUST SEAL ASSEMBLY	1	
8	2TK-14867-01-00	. BRACKET	1	
9	90119-06115-00	. BOLT, WITH WASHER	3	
10	90201-106M5-00	. WASHER, PLATE	1	
11	90380-10197-00	. BUSH, SOLID	2	
12	2TK-14865-01-00	. PULLEY	1	
13	92990-05200-00	. WASHER, PLAIN	1	
14	97011-05012-00	. BOLT	1	
15	90387-106U7-00	. COLLAR	1	
16	4HD-14826-00-00	PROTECTOR, EXHAUST	1	
17	3EN-14624-10-00	COVER, EXHAUST	1	
18	90119-06131-00	BOLT, WITH WASHER	3	
19	3YF-14613-01-00	GASKET, EXHAUST PIPE	4	
20	90179-06499-00	NUT	8	
21	95817-08030-00	BOLT, FLANGE	1	
22	90201-08730-00	WASHER, PLATE	1	
23	3HH-14710-10-00	MUFFLER ASSEMBLY 1	1	
24	3HE-14755-00-00	. GASKET, SILENCER	1	
25	95816-08045-00	. BOLT, FLANGE	1	
26	95817-08012-00	BOLT, FLANGE	1	
27	3HX-1133E-03-00	CABLE, PULLEY 1	1	
28	3HX-1133F-03-00	CABLE, PULLEY 2	1	


CRANKCASE



Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-15100-10-00	CRANKCASE ASSEMBLY	1	
2	11H-15138-00-00	. NOZZLE 1	1	
3	26H-15138-00-00	. NOZZLE 1	1	
4	99510-12016-00	. PIN, DOWEL	1	
5	1HX-15138-00-00	. NOZZLE 1	1	
6	93210-12152-00	. O-RING	1	
7	2H7-15361-00-00	. GAUGE, LEVEL	1	
8	36Y-15189-00-00	. PLUG	2	
9	93210-16629-00	. O-RING	2	
10	90201-237K5-00	. WASHER, PLATE	1	
11	93315-32516-00	. BEARING	1	
12	90116-08526-00	BOLT, STUD	2	
13	90116-08525-00	BOLT, STUD	10	
14	90105-08630-00	BOLT, WASHER BASED	12	
15	90201-087K3-00	WASHER, PLATE	12	
16	95816-06040-00	BOLT	10	
17	95816-06050-00	BOLT, FLANGE	5	
18	95816-06070-00	BOLT, FLANGE	3	
19	95816-06080-00	BOLT, FLANGE	1	
20	95816-06090-00	BOLT, FLANGE	2	
21	95816-08070-00	BOLT, FLANGE	1	
22	90430-06166-00	GASKET	1	
23	90465-10307-00	CLAMP	1	
24	90465-10308-00	CLAMP	1	
25	3HE-11165-00-00	PLATE, BREATHER	1	
26	98511-06012-00	SCREW, PAN HEAD	2	
27	3HE-11145-00-00	PLATE, BREATHER 2	1	
28	98511-06012-00	SCREW, PAN HEAD	4	
29	1WG-11166-00-00	PIPE, BREATHER 1	1	


CONTINUED ON NEXT FRAME ➤

CRANKCASE



Ref. No.	Part Number	Description	Qty	Remarks
30	90467-14015-00	CLIP	2	
31	90445-116E9-00	HOSE	1	
32	90465-06289-00	CLAMP	1	
33	90467-10038-00	CLIP	1	
34	1WG-15381-00-00	PLATE, BEARING COVER	1	
35	91316-06012-00	BOLT	2	
36	3HE-15105-00-00	NOZZLE ASSEMBLY	2	
37	93210-06632-00	O-RING	2	
38	99510-12016-00	PIN, DOWEL	2	


CRANKCASE COVER 1




Ref. No.	Part Number	Description	Qty	Remarks
1	2TK-15411-00-00	COVER, CRANKCASE 1	1	
2	1L9-15417-00-00	COVER, CAP	1	
3	1WG-15316-00-00	DAMPER, ENGINE MOUNT 1	1	
4	1WG-15427-00-00	COVER, CAP 2	1	
5	98901-05008-00	SCREW, BIND	4	
6	3HE-15451-10-00	GASKET, CRANKCASE COVER 1	1	
7	3HE-15467-10-00	GASKET	1	
8	99510-08016-00	PIN, DOWEL	2	
9	90110-06149-00	BOLT, HEXAGON SOCKET HEAD	4	
10	90110-06130-00	BOLT, HEXAGON SOCKET HEAD	1	
11	2TK-15421-00-00	COVER, CRANKCASE 2	1	
12	3HE-15461-10-00	GASKET, CRANKCASE COVER 2	1	
13	99510-08016-00	PIN, DOWEL	2	
14	91311-06025-00	BOLT, SOCKET HEAD	2	
15	91311-06035-00	BOLT, SOCKET HEAD	4	
16	91311-06045-00	BOLT	1	
17	2TK-15431-01-00	COVER, CRANKCASE 3	1	
18	1WG-15425-00-00	COVER, GENERATOR 2	1	
19	1WG-15326-00-00	DAMPER, ENGINE MOUNT 2	1	
20	98901-05008-00	SCREW, BIND	4	
21	3HE-15462-10-00	GASKET, CRANKCASE COVER 3	1	
22	99510-08016-00	PIN, DOWEL	2	
23	91311-06025-00	BOLT, SOCKET HEAD	8	
24	91311-06035-00	BOLT, SOCKET HEAD	2	
25	3F9-15362-00-00	PLUG, OIL LEVEL	1	

CONTINUED ON NEXT FRAME ➤

CRANKCASE COVER 1



Ref. No.	Part Number	Description	Qty	Remarks
26	93210-27778-00	O-RING	1	
27	3HE-15415-01-00	COVER, GENERATOR	1	
28	90340-08M04-00	PLUG, STRAIGHT SCRW	1	
29	99510-08016-00	PIN, DOWEL	2	
30	91311-06025-00	BOLT, SOCKET HEAD	3	
31	91311-06035-00	BOLT, SOCKET HEAD	1	
32	91311-06035-00	BOLT, SOCKET HEAD	1	
33	90462-10182-00	CLAMP	1	
34	98580-06010-00	SCREW, PAN HEAD	1	




3HE332-9160

STARTER CLUTCH

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-15521-00-00	SHAFT 1	1	
2	3HE-15512-00-00	GEAR, IDLER 1	1	
3	3HE-15517-00-00	GEAR, IDLER 2	1	
4	3TJ-15521-00-00	SHAFT 1	2	
5	3HE-15590-02-00	STARTER ONE-WAY ASSEMBLY	1	
6	3HE-15524-00-00	WHEEL, STARTER	1	
7	91316-08020-00	BOLT	3	
8	4JH-15515-00-00	GEAR 3	1	
9	90280-16053-00	KEY, WOODRUFF (90280-05048-00)	1	
10	90201-107K6-00	WASHER, PLATE	1	
11	90105-10445-00	BOLT, WASHER BASED	1	
12	93306-20005-00	BEARING (B6200) (93306-20006-00)	1	NTN


CLUTCH



3HE332-9170

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-16150-00-00	PRIMARY DRIVEN GEAR COMP.	1	
2	1WG-16154-00-00	PLATE, THRUST 1	1	
3	3HE-16371-00-00	BOSS, CLUTCH	1	
4	21V-16321-00-00	PLATE, FRICTION	9	
5	131-16324-00-00	PLATE, CLUTCH 1	8	
6	2TK-16351-00-00	PLATE, PRESSURE 1	1	
7	90501-227E0-00	SPRING, COMPRESSION	5	
8	90119-05001-00	BOLT, WITH WASHER	5	
9	1WG-16356-00-00	ROD, PUSH 1	1	
10	93210-48364-00	O-RING	1	
11	90215-18225-00	WASHER, LOCK	1	
12	90170-18221-00	NUT	1	
13	93109-08058-00	OIL SEAL (SD07 8-21-5.5 HS)	1	
14	1WG-16357-01-00	ROD, PUSH 2	1	
15	93505-16006-00	BALL	1	
16	1WG-16340-01-00	PUSH LEVER ASSEMBLY	1	
17	1WG-16304-00-00	BALL SCREW HOUSING ASSEMBLY	1	
18	90113-08021-00	BOLT, SET	1	
19	90179-08179-00	NUT	1	
20	90506-09232-00	SPRING, TENSION	1	
21	90157-05065-00	SCREW, PAN HEAD	2	
22	132-16346-00-00	HOOK, SPRING	1	
23	90387-212R3-00	COLLAR	1	
24	1WG-16164-00-00	PLATE, THRUST 2	1	
25	1WG-16181-00-00	SPACER 1	1	
26	93310-345R8-00	BEARING	1	

TRANSMISSION




3HE332-9180

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-17411-10-00	AXLE, MAIN (13T)	1	
2	3HE-17151-00-00	GEAR, 5TH PINION (26T)	1	
3	90209-18208-00	WASHER	1	
4	93410-22039-00	CIRCLIP	1	
5	3HE-17131-00-00	GEAR, 3RD PINION (21T)	1	
6	3HE-17161-00-00	GEAR, 6TH PINION (27T)	1	
7	3HE-17121-10-00	GEAR, 2ND PINION (22T)	1	
8	93306-37208-00	BEARING	1	
9	93440-54152-00	CIRCLIP	1	
10	93399-99933-00	BEARING	1	
11	278-17425-00-00	CIRCLIP 2	1	
12	3HE-17421-00-00	AXLE, DRIVE	1	
13	93306-30550-00	BEARING	1	
14	3HE-17221-10-00	GEAR, 2ND WHEEL (37T)	1	
15	90209-27192-00	WASHER	1	
16	93440-30077-00	CIRCLIP	1	
17	3HE-17261-10-00	GEAR, 6TH WHEEL (30T)	1	
18	3HE-17231-00-00	GEAR, 3RD WHEEL (31T)	1	
19	3HE-17241-00-00	GEAR, 4TH WHEEL (28T)	1	
20	90209-22191-00	WASHER	1	
21	93440-25084-00	CIRCLIP	1	
22	3HE-17251-00-00	GEAR, 5TH WHEEL (31T)	1	
23	3HE-17211-10-00	GEAR, 1ST WHEEL (42T)	1	
24	90387-255V4-00	COLLAR	1	
25	93102-35109-00	OIL SEAL (SD-35-62-6 HS)	1	
26	3HE-17460-00-00	SPROCKET, DRIVE (15T)	1	
27	90215-21022-00	WASHER, LOCK	1	
28	90179-18020-00	NUT	1	
29	90201-20276-00	WASHER, PLATE (1.0T)	1	

CONTINUED ON NEXT FRAME ➤


TRANSMISSION



3HE332-9180

Ref. No.	Part Number	Description	Qty	Remarks
30	93311-42045-00	BEARING (20NG3315NE)	1	
31	278-17424-01-00	CIRCLIP 1	1	
32	278-17425-00-00	CIRCLIP 2	1	
33	4G0-17433-01-00	NOZZLE	1	


SHIFT CAM - SHIFT FORK



1WG010-6180


Ref. No.	Part Number	Description	Qty	Remarks
1	1WG-18540-01-00	SHIFT CAM ASSEMBLY	1	
2	90501-06022-00	. SPRING, COMPRESSION	1	
3	278-18542-00-00	. POINT, NEUTRAL	1	
4	278-18566-00-00	. PLATE, SIDE 2	1	
5	98701-05012-00	. SCREW, FLAT HEAD	1	
6	1WG-18531-01-00	BAR, SHIFT FORK GUIDE 1	1	
7	1WG-18535-01-00	BAR, SHIFT FORK GUIDE 2	1	
8	1WG-18511-00-00	FORK, SHIFT 1	1	
9	1WG-18512-00-00	FORK, SHIFT 2	1	
10	1WG-18513-00-00	FORK, SHIFT 3	1	
11	1WG-18536-00-00	STOPPER, SHIFT BAR	1	
12	1HX-18127-00-00	STOPPER, SCREW	1	
13	90508-23707-00	SPRING, TORSION	1	
14	1WG-18562-00-00	PLATE, STOPPER 2	1	
15	36Y-18140-00-00	STOPPER LEVER ASSEMBLY	1	
16	90109-063F7-00	BOLT	1	
17	95817-06016-00	BOLT, FLANGE	2	

SHIFT SHAFT



Ref. No.	Part Number	Description	Qty	Remarks
1	3EN-18101-01-00	SHIFT SHAFT ASSEMBLY	1	
2	90508-32682-00	. SPRING, TORSION	1	
3	93102-12321-00	OIL SEAL, SD-TYPE	1	
4	90560-12211-00	SPACER	1	
5	93109-12053-00	OIL SEAL (SDO 12/18/4-1)	2	
6	3HE-18110-00-00	SHIFT PEDAL ASSEMBLY	1	
7	2H9-18154-00-00	. COVER, DUST	1	
8	132-18113-01-00	. COVER, SHIFT PEDAL	1	
9	1WG-18112-01-00	ARM, SHIFT	1	
10	2H9-18154-00-00	. COVER, DUST	1	
11	97011-06020-00	BOLT	1	
12	1WG-18115-00-00	ROD, SHIFT	1	
13	90170-06228-00	NUT (COUNTER CLOCKWISE)	1	
14	95380-06700-00	NUT (95303-06700-00)	1	


FRAME



Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-21110-01-T9	FRAME COMP.	1	COMP. SILVER (NON-CA)
	3HW-21110-01-T9	FRAME COMP.	1	COMP. SILVER (CA ONLY)
2	1WG-2143A-00-00	CAP	2	
3	3HE-2117E-00-00	BRACKET, TAILLIGHT	1	
4	90109-06757-00	BOLT	4	
5	3HH-21140-01-T9	DOWN TUBE COMP.	1	COMP. SILVER (NON-CA)
	3HW-21140-00-T9	DOWN TUBE COMP.	1	COMP. SILVER (CA ONLY)
6	3HH-21150-01-T9	DOWN TUBE COMP. 2	1	COMP. SILVER (NON-CA)
	3HW-21150-00-T9	DOWN TUBE COMP. 2	1	COMP. SILVER (CA ONLY)
7	90105-10436-00	BOLT, WASHER BASED	4	
8	95701-10500-00	NUT, FLANGE	4	
9	91311-08020-00	BOLT, SOCKET HEAD	4	
10	95811-10080-00	BOLT, FLANGE	2	
11	91011-10295-00	BOLT, FLANGE	1	
12	91011-10165-00	BOLT, FLANGE	1	
13	95701-10500-00	NUT, FLANGE	4	
14	1WG-21459-00-00	SPACER	2	
15	1WG-2142M-00-00	BRACKET, RADIATOR 3	1	
16	95817-06016-00	BOLT, FLANGE	1	
17	3HE-21238-00-00	BRACKET	1	
18	95811-06012-00	BOLT, FLANGE (95801-06012)	1	
19	90480-18171-00	GROMMET	1	
20	3HE-2137Y-00-00	GUIDE, AIR	1	
21	1WG-2139W-00-00	COVER	1	
22	95702-06600-00	NUT, FLANGE	1	


CONTINUED ON NEXT FRAME ➤

FRAME



Ref. No.	Part Number	Description	Qty	Remarks
23	90480-01401-00	GROMMET	1	
24	90480-13398-00	GROMMET	1	
25	3HE-2137W-00-00	SCOOP, AIR 1	1	
26	3HE-2137X-00-00	SCOOP, AIR 2	1	
27	3HE-2139U-00-00	DAMPER 2	2	
28	90119-06079-00	BOLT, WITH WASHER	3	
29	90387-06681-00	COLLAR	2	
30	3HE-2117M-00-00	COVER 2	1	
31	3HE-2117N-00-00	COVER 3	1	
32	90338-15202-00	PLUG	2	
33	3HE-2117R-00-00	COVER 4	2	
34	3HE-2117T-00-00	COVER 5	2	
35	3HE-21446-00-00	STAY, MUFFLER 2	1	
36	3HW-2149T-00-00	BRACKET, SERVO MOTOR	1	FOR CA ONLY
37	95807-06016-00	BOLT, FLANGE	2	FOR CA ONLY


FENDER



3HHE110-5240

Ref. No.	Part Number	Description	Qty	Remarks
1	3FH-21510-00-0Y	FRONT FENDER COMP.	1	VDMC
	3FH-21510-00-1Y	FRONT FENDER COMP.	1	RYC1
2	26H-21746-00-00	. DAMPER	2	
3	46X-2313A-00-00	BRACE, FORK	1	
4	90105-06456-00	BOLT, WASHER BASED	4	
5	90338-12192-00	PLUG	1	
6	3FH-25875-00-00	HOLDER, BRAKE HOSE 1	1	
7	3FH-25876-00-00	HOLDER, BRAKE HOSE 2	1	
8	95023-06025-00	BOLT, FLANGE	2	
9	3HE-21611-10-00	FENDER, REAR	1	
10	2MG-21639-00-00	DAMPER 2	1	
11	90480-10258-00	GROMMET	2	
12	90387-066M3-00	COLLAR	2	
13	90119-06108-00	BOLT, WITH WASHER	4	
14	31A-14477-00-00	PLATE	2	
15	3HE-85132-01-00	BRACKET, REFLECTOR 1	1	
16	90267-40029-00	RIVET, BLIND	2	
17	90201-044A2-00	WASHER, PLATE	2	
18	25G-28379-00-00	HOOK	1	
19	90267-40076-00	RIVET, BLIND	2	
20	90201-044A2-00	WASHER, PLATE	2	
21	26L-82131-00-00	BAND, BATTERY	1	
22	34M-21649-00-00	DAMPER	1	
23	3HE-21629-00-00	GUARD, MUD	1	
24	3HE-21651-00-6G	COVER, REAR FENDER	1	NYB
	3HE-21651-00-P5	COVER, REAR FENDER	1	RYC1
25	99231-00080-00	EMBLEM, YAMAHA	1	NYB
	99233-00080-00	EMBLEM, YAMAHA	1	RYC 1
26	2GH-21575-00-00	SEAL 1	1	

CONTINUED ON NEXT FRAME ➤




3HHE110-5240

FENDER

Ref. No.	Part Number	Description	Qty	Remarks
27	2GH-21576-00-00	SEAL 2	1	
28	2GH-21735-00-00	SEAL 2	2	
29	3HH-21660-00-00	GRAPHIC	1	RYC 1
30	1WG-28100-01-00	TOOL KIT	1	
31	90159-06033-00	SCREW, WITH WASHER	4	
32	J44-78248-00-00	SEAL 4	1	
33	2LJ-21688-00-00	BRACKET, REAR STAY	1	
34	2LJ-21689-00-00	BRACKET, REAR STAY 2	1	
35	90267-40076-00	RIVET, BLIND	4	
36	90201-044A2-00	WASHER, PLATE	4	
37	4U7-28186-00-00	POUCH	1	
38	4K5-2814E-10-00	HOOK	1	


SIDE COVER



Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-Y2171-0F-6G	COVER, SIDE 1	1	NYB
	3HE-Y2171-0G-P2	COVER, SIDE 1	1	RYC1
2	3HH-2173E-60-00	. GRAPHIC 1	1	FOR RYC1
	3HH-2173L-80-00	. GRAPHIC SET 1	1	FOR NYB
3	3HH-21781-30-00	. EMBLEM 1	1	FOR RYC1
4	3HE-21735-00-00	. SEAL 2	1	
5	3HE-21732-00-00	. SEAL 1	2	
6	2GH-21735-00-00	. SEAL 2	1	
7	3HE-Y2172-U0-6G	COVER, SIDE 2	1	NYB
	3HE-Y2172-V0-P2	COVER, SIDE 2	1	RYC1
8	3HH-2173F-60-00	. GRAPHIC 2	1	FOR RYC1
	3HH-2174L-80-00	. GRAPHIC SET 2	1	FOR NYB
9	3HH-21781-30-00	. EMBLEM 1	1	FOR RYC1
10	3HE-21735-00-00	. SEAL 2	1	
11	3HE-21732-00-00	. SEAL 1	2	
12	2GH-21735-00-00	. SEAL 2	1	
13	90480-01401-00	GROMMET	4	
14	90480-14052-00	GROMMET	2	
15	1WG-2177G-00-00	BOX, BATTERY	1	
16	90480-22362-00	GROMMET	1	
17	90480-14229-00	GROMMET	2	
18	90387-07391-00	COLLAR	2	
19	31A-14477-00-00	PLATE	2	
20	90119-06097-00	BOLT, WITH WASHER	2	
21	120-82131-00-00	BAND, BATTERY	1	
22	1WG-21871-00-00	TANK, RECOVERY	1	
23	4L0-21875-00-00	CAP	1	
24	1AA-21874-00-00	GASKET	1	
25	3GM-21816-00-00	PIPE 1	1	


CONTINUED ON NEXT FRAME ➤

SIDE COVER



Ref. No.	Part Number	Description	Qty	Remarks
26	90159-06033-00	SCREW, WITH WASHER	2	
27	90159-06033-00	SCREW, WITH WASHER	2	
28	3HH-2179V-70-00	PLATE, EPA 1	1	NON-CA
	3UU-2179R-50-00	PLATE, EPA 2	1	CA ONLY
29	34X-21691-00-00	FLAP	1	

REAR ARM




3HHE110-5260

Ref. No.	Part Number	Description	Qty	Remarks
1	3HH-22110-00-T9	REAR ARM COMP.	1	COMP. SILVER
2	33M-22184-00-00	BUSH	1	
3	93320-32403-00	BEARING	2	
4	4X7-22129-00-00	COVER, THRUST 2	2	
5	90201-161J3-00	WASHER, PLATE	2	
6	93317-21746-00	BEARING	2	
7	93109-17048-00	OIL SEAL (SDO 17-24-4)	2	
8	90387-122R5-00	COLLAR	1	
9	3HH-22151-00-00	SEAL, GUARD	1	
10	90387-06681-00	COLLAR	2	
11	90387-062M9-00	COLLAR	2	
12	97095-06016-00	BOLT	4	
13	3GM-22311-00-00	CASE, CHAIN	1	
14	90119-06108-00	BOLT, WITH WASHER	1	
15	46X-22141-00-00	SHAFT, PIVOT	1	
16	90185-14070-00	NUT, SELF-LOCKING	1	
17	1WG-2217A-00-00	ARM, RELAY	1	
18	93317-31701-00	BEARING	1	
19	93317-21746-00	BEARING	2	
20	93109-17048-00	OIL SEAL (SDO 17-24-4)	4	
21	90387-102R4-00	COLLAR	1	
22	90387-122R5-00	COLLAR	1	
23	93399-99919-00	BEARING	1	
24	93101-16131-00	OIL SEAL	2	
25	90387-124W2-00	COLLAR	2	
26	1WG-2217M-00-00	ARM 1	2	
27	90105-10376-00	BOLT, WASHER BASED	1	
28	90101-10658-00	BOLT	2	
29	90101-10659-00	BOLT	1	

CONTINUED ON NEXT FRAME ➤


REAR ARM



3HHE110-5260

Ref. No.	Part Number	Description	Qty	Remarks
30	90201-101J1-00	WASHER, PLATE	3	
31	95611-10100-00	NUT, U	4	
32	90119-06117-00	BOLT, WITH WASHER	1	

REAR SUSPENSION




Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-22210-10-00	SHOCK ABSORBER ASSEMBLY, REAR	1	
2	90387-124T2-00	COLLAR	1	
3	90109-10554-00	BOLT	1	
4	90201-101J1-00	WASHER, PLATE	1	
5	95601-10100-00	NUT, U (95602-10100-00)	1	



3HE332-9250

STEERING




Ref. No.	Part Number	Description	Qty	Remarks
1	93332-00001-00	BEARING	1	
2	93332-00008-00	BEARING	1	
3	3HE-23416-00-00	COVER, BALL RACE 2	1	
4	90179-25033-00	NUT, SPEC''L SHAPE	2	
5	90202-26142-00	WASHER, PLATE	1	
6	26H-23418-01-00	WASHER, SPECIAL	1	
7	90176-22050-00	NUT, CROWN	1	
8	3HE-23435-00-00	CROWN, HANDLE	1	
9	91609-40210-00	. PIN, SPRING	2	
10	91311-08030-00	BOLT	2	
11	3HE-2317E-00-00	STAY	1	

FWD

3HE351-1250

FRONT FORK




3HHE110-5290

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-23102-10-00	FRONT FORK ASSEMBLY (L.H)	1	
2	3HE-23126-10-00	. TUBE, OUTER (LEFT)	1	
3	3R4-23153-00-00	. RING, SNAP	1	
4	3EN-23145-00-00	. OIL SEAL	1	
5	2YK-23125-00-00	. METAL, SLIDE 1	1	
6	3EN-23144-00-00	. SEAL, DUST	1	
7	4V2-23146-L0-00	. WASHER, OIL SEAL	1	
8	3BF-23110-50-00	. INNER TUBE COMP. 1	1	
9	3HE-23170-00-00	. CYLINDER COMP., FRONT FORK	1	
10	2YK-23173-00-00	. SPINDLE, TAPER	1	
11	3HE-23141-00-00	. SPRING, FRONT FORK	1	
12	509-23158-L0-00	. GASKET	1	
13	3EN-23111-00-00	. BOLT, CAP	1	
14	4DN-23149-40-00	. WASHER, SPRING UPPER	1	
15	1W4-23114-L0-00	. GASKET	1	
16	278-23181-50-00	. BOLT, HEXAGON SOCKET HEAD	1	
17	1WG-23118-00-00	. SPACER	1	
18	3HE-23103-10-00	FRONT FORK ASSEMBLY (R.H)	1	
19	3HE-23136-10-00	. TUBE, OUTER (RIGHT)	1	
20	3R4-23153-00-00	. RING, SNAP	1	
21	3EN-23145-00-00	. OIL SEAL	1	
22	2YK-23125-00-00	. METAL, SLIDE 1	1	
23	3EN-23144-00-00	. SEAL, DUST	1	
24	4V2-23146-L0-00	. WASHER, OIL SEAL	1	
25	3BF-23110-50-00	. INNER TUBE COMP. 1	1	
26	3HE-23170-00-00	. CYLINDER COMP., FRONT FORK	1	
27	2YK-23173-00-00	. SPINDLE, TAPER	1	

CONTINUED ON NEXT FRAME ➤


FRONT FORK



3HHE110-5290

Ref. No.	Part Number	Description	Qty	Remarks
28	3HE-23141-00-00	. SPRING, FRONT FORK	1	
29	509-23158-L0-00	. GASKET	1	
30	3EN-23111-00-00	. BOLT, CAP	1	
31	4DN-23149-40-00	. WASHER, SPRING UPPER	1	
32	1W4-23114-L0-00	. GASKET	1	
33	278-23181-50-00	. BOLT, HEXAGON SOCKET HEAD	1	
34	1WG-23128-00-00	. BOLT, AXLE HOLDER	1	
35	1WG-23118-00-00	. SPACER	1	
36	1WG-23340-00-00	UNDER BRACKET COMP.	1	
37	2NX-23356-00-00	BOLT 2	2	


FUEL TANK



Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-24110-00-00	FUEL TANK COMP.	1	FOR CA ONLY
	3HE-24110-10-00	FUEL TANK COMP.	1	FOR NON-CA
2	1HX-24181-00-00	DAMPER, LOCATING 1	2	
3	90387-06380-00	COLLAR	1	
4	95807-06080-00	BOLT, FLANGE	1	
5	3EN-21346-00-00	BRACKET, TANK FITTING	2	
6	95807-06016-00	BOLT, FLANGE	4	
7	1WG-21345-00-00	BRACKET, TANK FITTING	1	
8	90179-08410-00	NUT	2	
9	1HX-24182-00-00	DAMPER, LOCATING 2	2	
10	90464-13080-00	CLAMP	2	
11	1WG-21348-00-00	BRACKT, TANK FITTING	1	
12	95807-06016-00	BOLT, FLANGE	2	
13	1WG-24185-00-00	DAMPER, LOCATING 5	1	
14	1WG-24602-00-00	CAP ASSEMBLY	1	FOR NON-CA
	3FH-24602-00-00	CAP ASSEMBLY	1	FOR CA ONLY
15	3HE-24500-00-00	FUEL COCK ASSEMBLY 1	1	
16	4X8-24512-00-00	. O-RING	1	
17	3AJ-24534-00-00	. SEAL, COCK	1	
18	98580-03008-00	. SCREW, PAN HEAD (98501-03008-00)	2	
19	3HE-24524-00-00	LEVER, COCK	1	
20	98707-04018-00	SCREW, FLAT HEAD	1	
21	90202-05187-00	WASHER, PLATE	2	
22	90149-06011-00	SCREW, SPEC''L SHAPE	2	
23	1FK-24560-00-00	FILTER ASSEMBLY	1	
24	26H-24568-00-00	BAND, FILTER	1	
25	1WG-24566-00-00	BRACKET, FILTER	1	
26	1WG-24398-01-00	BAND 1	1	

CONTINUED ON NEXT FRAME ➤


FUEL TANK



Ref. No.	Part Number	Description	Qty	Remarks
27	3HE-24491-00-00	BRACKET, FUEL PUMP	1	
28	98907-05014-00	SCREW, BIND	3	
29	90480-14229-00	GROMMET	1	
30	90387-07391-00	COLLAR	1	
31	95707-06500-00	NUT, FLANGE	1	
32	90480-11454-00	GROMMET	1	
33	1WG-24311-00-00	PIPE, FUEL 1	1	
34	90445-137F4-00	HOSE	1	
35	90467-10135-00	CLIP	1	
36	90467-11044-00	CLIP	3	
37	3HE-Y217F-0C-2Y	COVER, TOP (FUEL TANK)	1	NYB/VDMC1
	3HE-Y217F-0E-P0	COVER, TOP (FUEL TANK)	1	RYC1
38	99221-00140-00	. EMBLEM, YAMAHA	2	FOR NYB
	99223-00180-00	. EMBLEM, YAMAHA	2	FOR RYC 1
39	3HH-24244-80-00	. GRAPHIC, FUEL TANK 1	1	FOR NYB
40	90480-18495-00	. GROMMET	2	
41	3HE-24614-00-00	. PLATE, CAP	1	
42	90110-06134-00	. BOLT, HEXAGON SOCKET HEAD	3	
43	1WG-24665-00-00	. DAMPER	3	
44	90110-06133-00	. BOLT, HEXAGON SOCKET HEAD	3	
45	90201-06067-00	. WASHER, PLATE	3	
46	95307-06600-00	. NUT	3	
47	3EN-13907-00-00	FUEL PUMP COMP.	1	
48	90445-146F9-00	HOSE	1	
49	90467-13123-00	CLIP	2	
50	1WG-24183-00-00	DAMPER, LOCATING 3	2	
51	90154-06040-00	SCREW, BINDING	2	


CONTINUED ON NEXT FRAME ➤

FUEL TANK



Ref. No.	Part Number	Description	Qty	Remarks
52	4X7-21719-00-00	GROMMET	2	
53	90387-112R6-00	COLLAR	2	
54	90201-06697-00	WASHER, PLATE	2	
55	98507-06025-00	SCREW, PAN HEAD	2	
56	90110-06170-00	BOLT, HEXAGON SOCKET HEAD	2	
57	1WG-2414A-00-00	COVER, FILLER	1	
58	1WG-24622-00-00	WASHER, RING	2	
59	90560-03220-00	SPACER	1	
60	90445-070F1-00	HOSE	1	


FUEL TANK 2 (CALIFORNIA ONLY)



3UU110-0290

Ref. No.	Part Number	Description	Qty	Remarks
1	25H-24180-00-00	ROLL OVER VALVE ASSEMBLY	1	
2	90461-15100-00	CLAMP	1	
3	98507-05010-00	SCREW, PAN HEAD	1	
4	92907-05600-00	WASHER, PLATE	1	
5	3FH-24313-00-00	PIPE 3	1	
6	90445-11706-00	HOSE	1	
7	90445-11501-00	HOSE	1	
8	90467-10008-00	CLIP, SCISSOR	6	
9	42H-24119-00-00	TUBE, CONNECTING	1	
10	3FH-24170-00-00	CANISTER ASSEMBLY	1	
11	2JU-2419E-00-00	COVER, CANISTER	1	
12	3FH-24190-00-00	CANISTER HOLDER ASSEMBLY	1	
13	98507-05016-00	SCREW, PAN HEAD	2	
14	92907-05100-00	WASHER, SPRING	2	
15	97007-06020-00	BOLT	2	
16	92907-06100-00	WASHER, SPRING	2	
17	90201-06067-00	WASHER, PLATE	2	
18	90480-15058-00	GROMMET	2	
19	90387-060A7-00	COLLAR	2	
20	3HW-24312-00-00	PIPE 2	1	
21	90445-11611-00	HOSE	1	
22	3H3-24376-00-00	PIPE, JOINT 1	1	
23	90467-10008-00	CLIP, SCISSOR	6	
24	90445-11732-00	HOSE	1	


SEAT



3HH110-2280

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-24710-00-00	SINGLE SEAT ASSEMBLY	1	
2	3HE-24711-00-00	. COVER, SINGLE SEAT	1	
3	1T4-24741-00-00	. PAD, SEAT	1	
4	116-24741-00-00	. PAD, SEAT	1	
5	22W-24741-00-00	. PAD, SEAT	4	
6	3HE-24742-00-00	. GROMMET	1	
7	3HE-24750-00-00	TANDEM SEAT ASSEMBLY	1	
8	4K0-24748-00-00	. BRACKET, SEAT	2	
9	3HE-24796-00-00	. COVER	1	
10	90164-05026-00	. SCREW, TAPPING	2	
11	3HE-24734-00-00	. BAND, SEAT	1	
12	95817-06016-00	. BOLT, FLANGE	2	
13	4L0-24712-11-00	. PLATE	2	
14	90468-10050-00	. CLIP	2	
15	47X-24739-00-00	. BOLT, SEAT FITTING	2	
16	3HE-24705-02-00	SEAT LOCK ASSEMBLY (3HH-24705-01-00)	1	
17	95811-06030-00	BOLT, FLANGE (95802-06030)	2	
18	26H-21308-00-00	HELMET HANGER ASSEMBLY	1	
19	90149-06150-00	SCREW	1	


FRONT WHEEL



3HE332-9300

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-25168-00-P1	CAST WHEEL, FRONT	1	LRYS1 FOR RYC1
	3HE-25168-00-TR	CAST WHEEL, FRONT	1	RR FOR RYC1
2	90560-15314-00	SPACER	1	
3	93306-30202-00	BEARING	2	
4	93102-22014-00	OIL SEAL	1	
5	341-25149-00-00	CLUTCH, METER	1	
6	341-25846-00-00	RETAINER, CLUTCH	1	
7	93105-45017-00	OIL SEAL	1	
8	94111-173X4-00	TIRE (110/70 VR17 V240)	1	DUNLOP (CA ONLY)
	94111-175X5-00	TIRE (MCS110/70 VR17 V240)	1	BRIDGE- STONE (NON-CA)
9	93900-00030-00	VALVE, RIM	1	
10	29L-25398-00-00	BALANCER, WHEEL (10G)	1	
	29L-25398-10-00	BALANCER, WHEEL (20G)	1	
	29L-25398-20-00	BALANCER, WHEEL (30G)	1	
11	1WG-25190-00-00	GEAR UNIT ASSEMBLY	1	
12	42X-25181-00-00	AXLE, WHEEL	1	
13	90387-15550-00	COLLAR	1	


FRONT BRAKE CALIPER



3HE351-1300

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-2581T-00-00	. DISC BRAKE ASSEMBLY	2	
2	90109-08718-00	BOLT	12	
3	3HE-2580T-51-00	CALIPER ASSEMBLY (LEFT)	1	
4	3HE-W0057-50-00	. PISTON ASSEMBLY, CALIPER	2	
5	3HE-W0047-50-00	. . CALIPER SEAL KIT	2	
6	3GM-W0045-01-00	. BRAKE PAD KIT	1	
7	3GM-25919-00-00	. SUPPORT, PAD	1	
8	3HE-25924-00-00	. PIN, PAD	2	
9	3GM-25925-00-00	. CLIP	2	
10	1J3-W0048-00-00	. BLEED SCREW KIT	1	
11	1KT-25836-00-00	. COVER, DUST	1	
12	3HE-2580U-51-00	CALIPER ASSEMBLY (RIGHT)	1	
13	3HE-W0057-50-00	. PISTON ASSEMBLY, CALIPER	2	
14	3HE-W0047-50-00	. . CALIPER SEAL KIT	2	
15	3GM-W0045-01-00	. BRAKE PAD KIT	1	
16	3GM-25919-00-00	. SUPPORT, PAD	1	
17	3HE-25924-00-00	. PIN, PAD	2	
18	3GM-25925-00-00	. CLIP	2	
19	1J3-W0048-00-00	. BLEED SCREW KIT	1	
20	1KT-25836-00-00	. COVER, DUST	1	
21	90105-10638-00	BOLT, WASHER BASED	4	

REAR WHEEL




3HE351-1310

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-25338-50-P1	CAST WHEEL, REAR	1	LRYS1 FOR RYC1
	3HE-25338-50-TR	CAST WHEEL, REAR	1	RR FOR NYB
2	93306-30309-00	BEARING	1	
3	93306-20314-00	BEARING (B6203)	2	
4	93102-25044-00	OIL SEAL	1	
5	90387-174V8-00	COLLAR	1	
6	1UF-25364-00-00	DAMPER	3	
7	94114-183X5-00	TIRE (140/60 VR18 V240)	1	DUNLOP (CA ONLY)
	94114-185X6-00	TIRE (MCS 140/60 VR18 V240)	1	BRIDGESTONE (NON-CA)
8	93900-00030-00	VALVE, RIM	1	
9	29L-25398-00-00	BALANCER, WHEEL (10G)	1	
	29L-25398-10-00	BALANCER, WHEEL (20G)	1	
	29L-25398-20-00	BALANCER, WHEEL (30G)	1	
10	1UF-25366-00-00	CLUTCH, HUB	1	
11	93306-37207-00	BEARING	1	
12	93105-42024-00	OIL SEAL	1	
13	1AE-25445-21-00	SPROCKET, DRIVEN (45T)	1	
14	90116-10485-00	BOLT, STUD	6	
15	95601-10200-00	NUT, SELF-LOCKING	6	
16	90387-177K0-00	COLLAR	1	
17	94581-42106-00	CHAIN (D.I.D.50 VA-6-106L)	1	
18	3HH-25388-00-00	PULLER, CHAIN 1	2	
19	95333-08600-00	NUT (6L2)	4	
20	3HH-22174-00-00	END 1	2	
21	92901-08600-00	WASHER, PLATE	2	
22	3HE-25371-50-00	BAR, TENSION	1	
23	90105-08321-00	BOLT, WASHER BASED	2	
24	95701-08500-00	NUT, FLANGE (95702-08500)	2	

CONTINUED ON NEXT FRAME ➤


REAR WHEEL



3HE351-1310

Ref. No.	Part Number	Description	Qty	Remarks
25	91490-20020-00	PIN, COTTER (91401-20020-00)	2	
26	3HE-25381-00-00	AXLE, WHEEL	1	
27	90201-177K7-00	WASHER, PLATE	2	
28	90387-177Y5-00	COLLAR	1	
29	90387-173L5-00	COLLAR	1	
30	90171-16024-00	NUT, CASTLE	1	
31	91401-30030-00	PIN, COTTER (91401-30025-00)	1	


REAR BRAKE CALIPER



3HE351-0330


Ref. No.	Part Number	Description	Qty	Remarks
1	2NX-25831-00-00	DISC, BRAKE (RIGHT)	1	
2	90109-08718-00	BOLT	6	
3	3HE-2580W-00-00	CALIPER ASSEMBLY, REAR 2	1	
4	31A-W0057-00-00	. PISTON ASSEMBLY, CALIPER	1	
5	31A-W0047-00-00	. . CALIPER SEAL KIT	1	
6	1FK-W0046-01-00	. BRAKE PAD KIT 2	1	
7	1WG-25919-00-00	. SUPPORT, PAD	1	
8	3HE-25924-00-00	. PIN, PAD	2	
9	3HE-25925-00-00	. CLIP	2	
10	1J3-W0048-00-00	. BLEED SCREW KIT	2	
11	51J-25836-00-00	. COVER, DUST	1	
12	1FK-25827-00-00	. SHIM, CALIPER	1	
13	1FK-25828-00-00	. SHIM, CALIPER	1	
14	3HE-25819-01-00	BRACKET, CALIPER	1	
15	90105-10638-00	BOLT, WASHER BASED	2	

STEERING HANDLE - CABLE



Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-26121-00-00	BOSS, HANDLE (LEFT)	1	
2	3HE-26122-00-00	BOSS, HANDLE (RIGHT)	1	
3	91311-06020-00	BOLT, SOCKET HEAD	4	
4	3HE-26111-00-00	HANDLEBAR	1	
5	91316-08025-00	BOLT, SOCKET HEAD	2	
6	341-23469-00-00	CAP, BOLT	2	
7	51J-26246-00-00	END, GRIP	2	
8	1KG-26241-00-00	GRIP (LEFT)	1	
9	3FH-26240-00-00	GRIP ASSEMBLY	1	
10	3EN-26311-00-00	CABLE, THROTTLE 1	1	
11	3HE-26312-00-00	CABLE, THROTTLE 2	1	
12	5H0-26393-00-00	HOLDER	1	
13	98506-05008-00	SCREW, PAN HEAD	1	
14	3HE-26335-01-00	CABLE, CLUTCH	1	
15	90179-08316-00	NUT	1	
16	90123-08083-00	BOLT	1	
17	3EN-26331-00-00	CABLE, STARTER 1	1	
18	3HE-83940-00-00	STARTER ASSEMBLY	1	
19	1WG-83941-00-00	. LEVER, STARTER	1	
20	3HE-28357-00-00	. STAY 2	1	
21	1WG-83942-00-00	. COVER, STARTER	1	
22	98906-03006-00	. SCREW, BIND	2	
23	90209-10131-00	. WASHER	1	
24	98906-06008-00	. SCREW, BIND	1	
25	95826-06020-00	BOLT, FLANGE	1	
26	3HE-26112-00-00	BAR, HANDLE	1	


FRONT MASTER CYLINDER



3HHE110-5380

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-2583T-00-00	MASTER CYLINDER ASSEMBLY	1	
2	3HE-25852-00-00	. CAP, RESERVOIR	1	
3	98706-04012-00	. SCREW, FLAT HEAD	2	
4	36Y-25854-00-00	. DIAPHRAGM, RESERVOIR	1	
5	36Y-W0041-00-00	. CYLINDER KIT, MASTER	1	
6	36Y-25867-00-00	BRACKET, MASTER CYLINDER	1	
7	91316-06025-00	BOLT	2	
8	92906-06100-00	WASHER, SPRING	2	
9	3HE-25872-02-00	HOSE, BRAKE 1	1	
10	3HE-25873-12-00	HOSE, BRAKE 2	2	
11	11U-25885-00-00	JOINT	1	
12	91316-06025-00	BOLT	2	
13	90401-10160-00	BOLT, UNION	1	
14	90401-10159-00	BOLT, UNION	4	
15	90201-10118-00	WASHER, PLATE	11	
16	90338-09012-00	PLUG	1	

STAND - FOOTREST




3HE332-9360

Ref. No.	Part Number	Description	Qty	Remarks
1	2KT-27311-00-00	STAND, SIDE	1	
2	90109-10474-00	BOLT	1	
3	90185-10037-00	NUT, SELF-LOCKING	1	
4	90506-18224-00	SPRING, TENSION	1	
5	90506-26225-00	SPRING, TENSION	1	
6	1TX-27351-00-00	GUIDE, SIDE STAND	1	
7	2KT-27315-00-00	LINK, SIDE STAND	1	
8	3HE-27410-00-00	FRONT FOOTREST ASSEMBLY (LEFT)	1	
9	2GH-27413-00-00	. COVER, FOOTREST	1	
10	90157-05079-00	. SCREW, PAN HEAD	2	
11	3HE-27435-00-00	. BOLT	1	
12	3HE-27420-00-00	FRONT FOOTREST ASSEMBLY (RIGHT)	1	
13	2GH-27413-00-00	. COVER, FOOTREST	1	
14	90157-05079-00	. SCREW, PAN HEAD	2	
15	3HE-27435-00-00	. BOLT	1	
16	3HE-27442-00-00	BRACKET 2	1	
17	3HE-27443-00-00	BRACKET 3	1	
18	1HX-27431-00-00	FOOTREST, REAR 1	1	
19	1HX-27441-00-00	FOOTREST, REAR 2	1	
20	90501-12743-00	SPRING, COMPRESSION	2	
21	93501-04011-00	BALL 1 4	2	
22	1HX-27437-00-00	WASHER, SPECIAL	2	
23	91701-06035-00	PIN, CLEVIS	2	
24	91490-20020-00	PIN, COTTER (91401-20020-00)	2	
25	90387-064H8-00	COLLAR	2	
26	3HE-2741L-00-00	BRACKET 4	1	
27	3HE-2742L-01-00	BRACKET 5	1	

CONTINUED ON NEXT FRAME ➤


STAND - FOOTREST



3HE332-9360

Ref. No.	Part Number	Description	Qty	Remarks
28	95817-08025-00	BOLT, FLANGE	4	
29	3HE-27445-01-00	PLATE 1	1	
30	3HE-27446-01-00	PLATE 2	1	
31	95024-06016-00	BOLT, FLANGE	4	
32	90109-103A9-00	BOLT	2	
33	90206-17084-00	WASHER, WAVE	2	
34	95024-08025-00	BOLT, FLANGE	4	


REAR MASTER CYLINDER



3HE351-0370

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-27211-00-00	PEDAL, BRAKE	1	
2	22N-18113-00-00	COVER, SHIFT PEDAL	1	
3	90506-20377-00	SPRING, TENSION	1	
4	90446-17267-00	HOSE	1	
5	1WG-25850-50-00	MASTER CYLINDER ASSEMBLY	1	
6	1WG-W0042-50-00	. CYLINDER KIT, MASTER	1	
7	36Y-2582A-50-00	. JOINT	1	
8	93210-15620-00	. O-RING	1	
9	98517-04012-00	. SCREW, PAN HEAD	1	
10	92901-04100-00	. WASHER, SPRING	1	
11	92901-04600-00	. WASHER	1	
12	92017-08025-00	BOLT, BUTTON HEAD	2	
13	31A-27222-00-00	JOINT	1	
14	95307-08700-00	NUT	1	
15	90240-08013-00	PIN, CLEVIS	1	
16	90201-08083-00	WASHER, PLATE	1	
17	91490-20020-00	PIN, COTTER (91401-20020-00)	1	
18	31A-25894-01-00	TANK, RESERVOIR	1	
19	360-25854-00-00	DIAPHRAGM, RESERVOIR	1	
20	2GU-25855-00-00	BUSH, DIAPHRAGM	1	
21	2KF-25852-50-00	CAP, RESERVOIR	1	
22	90159-06056-00	SCREW, WITH WASHER	1	
23	31A-14477-00-00	PLATE	1	
24	1WG-25895-00-00	HOSE, RESERVOIR	1	
25	90467-14057-00	CLIP	2	
26	3HE-25872-61-00	HOSE, BRAKE 1	1	
27	90401-10159-00	BOLT, UNION	2	
28	90201-10118-00	WASHER, PLATE	4	


COWLING 1



Ref. No.	Part Number	Description	Qty	Remarks
1	3HH-28381-10-00	WINDSHIELD	1	
2	90150-05020-00	SCREW, ROUND HEAD	6	
3	95707-05500-00	NUT, FLANGE	6	
4	36Y-28348-00-00	MOLE 4	1	
5	3HE-2835G-00-6G	BODY, FRONT UPPER 1	1	NYB
	3HE-2835G-00-P2	BODY, FRONT UPPER 1	1	RYC1
6	3EN-2835U-20-00	PANEL 1	1	
7	3EN-2835V-20-00	PANEL 2	1	
8	99233-00080-00	EMBLEM, YAMAHA	1	FOR RYC 1
9	3HH-28390-80-00	GRAPHIC SET, COWLING	1	FOR NYB
10	3HE-21596-00-00	HOLDER	1	
11	3HE-28356-30-00	STAY 1	1	
12	90480-14229-00	GROMMET	4	
13	90179-06499-00	NUT	4	
14	90105-08748-00	BOLT, WASHER BASED	2	
15	90110-05201-00	BOLT, HEXAGON SOCKET HEAD	2	
16	90149-05299-00	SCREW	2	
17	90202-05180-00	WASHER, PLATE	4	
18	90183-05024-00	NUT, SPRING	4	
19	3HE-26280-10-00	REAR VIEW MIRROR ASSEMBLY (LEFT)	1	BLACK
20	3HE-26290-10-00	REAR VIEW MIRROR ASSEMBLY (RIGHT)	1	BLACK
21	1AE-26298-00-00	PLATE, MIRROR FITTING 1	2	
22	3CV-26298-00-00	PLATE, MIRROR FITTING 1	2	
23	90176-06055-00	NUT, CROWN	4	
24	98707-06025-00	SCREW, FLAT HEAD	4	
25	97707-50014-00	SCREW, TAPPING	6	
26	3EN-Y283J-0C-1Y	BODY, FRONT LOWER 1	1	NYB/VDMC1

CONTINUED ON NEXT FRAME ➤


COWLING 1



Ref. No.	Part Number	Description	Qty	Remarks
26	3EN-Y283J-E1-P0	BODY, FRONT LOWER 1	1	RYC1
27	3HH-28301-80-00	. GRAPHIC SET, LOWER COVER 1	1	FOR NYB/VDMC1
	3HH-28301-90-00	. GRAPHIC SET, LOWER COVER 1	1	FOR RYC1
28	3HH-28328-40-00	. EMBLEM	1	FOR NYB
29	90480-13398-00	. GROMMET	4	
30	90387-067K6-00	. COLLAR	4	
31	2HE-2848K-00-00	. SEAT 2	1	
32	3EN-Y283K-0G-1Y	BODY, FRONT LOWER 2	1	NYB/VDMC 1
	3EN-Y283K-0H-P0	BODY, FRONT LOWER 2	1	RYC1
33	3HH-28303-80-00	. GRAPHIC SET, LOWER COVER 2	1	FOR NYB
	3HH-28303-90-00	. GRAPHIC SET LOWER COVER 2	1	FOR RYC1
34	3HH-28328-40-00	. EMBLEM	1	FOR NYB
35	90480-13398-00	. GROMMET	4	
36	90387-067K6-00	. COLLAR	4	
37	3HE-2848L-00-00	. SEAT 3	1	
38	90110-06200-00	BOLT, HEXAGON SOCKET HEAD	8	
39	90149-05299-00	SCREW	2	
40	90202-05180-00	WASHER, PLATE	2	
41	90179-05523-00	NUT	2	
42	3HE-2831U-00-00	STAY, SIDE 1	2	
43	95807-06012-00	BOLT, FLANGE	2	
44	1WG-2836A-00-00	BRACKET 1	2	
45	3EN-2836A-01-00	BRACKET 1	1	
46	1WG-2836E-00-00	BRACKET 2	1	
47	95807-06010-00	BOLT, FLANGE	4	


CONTINUED ON NEXT FRAME ➤

COWLING 1



Ref. No.	Part Number	Description	Qty	Remarks
48	3EN-2838N-00-00	DUCT 1	1	
49	3EN-2838R-00-00	DUCT 2	1	
50	3EN-2838T-00-00	DUCT 3	1	
51	3EN-2838U-00-00	DUCT 4	1	
52	3HE-2838J-01-00	DUCT 5	2	
53	90460-49058-00	CLAMP, HOSE	4	
54	90154-06046-00	SCREW, BINDING	4	
55	3HE-2831W-00-00	STAY, MIRROR 1	1	
56	91317-06016-00	BOLT	2	
57	3EN-28313-00-00	LID	1	
58	3JJ-2835Y-00-00	LABEL, CAUTION	1	
59	3HF-2848M-00-00	SEAT 4	1	FOR CA ONLY
60	3HF-2848N-00-00	SEAT 5	1	FOR CA ONLY


GENERATOR



3HE332-9390

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-81450-00-00	ROTOR ASSEMBLY	1	
2	3HE-81410-01-00	STATOR ASSEMBLY	1	
3	91311-06035-00	BOLT, SOCKET HEAD	3	
4	98507-05016-00	SCREW, PAN HEAD	2	
5	92990-05100-00	WASHER, SPRING	2	
6	92901-05600-00	WASHER, PLATE	2	
7	90280-03047-00	KEY, WOODRUFF	1	
8	90105-10430-00	BOLT, WASHER BASED	1	
9	90201-107K6-00	WASHER, PLATE	1	


STARTING MOTOR



3HE332-9400

Ref. No.	Part Number	Description	Qty	Remarks
1	3HW-81800-00-00	STARTING MOTOR ASSEMBLY	1	
2	3HE-81840-00-00	. BRUSH HOLDER ASSEMBLY	1	
3	1HX-81815-00-00	. CORD, STARTER MOTOR	1	
4	3HE-81850-00-00	. ARMATURE ASSEMBLY	1	
5	3AJ-81809-00-00	. WASHER KIT	1	
6	3HE-81830-00-00	. FRONT BRACKET ASSEMBLY	1	
7	3HE-81826-00-00	. BOLT	1	
8	5H0-81871-00-00	. CAP	1	
9	11H-81844-00-00	. GASKET	2	
10	26H-81847-00-00	. O-RING	1	
11	95023-06025-00	BOLT, FLANGE	2	


FLASHER LIGHT -TURNSIGNAL



3HH110-9400

Ref. No.	Part Number	Description	Qty	Remarks
1	1UF-83310-00-00	FRONT FLASHER LIGHT ASSEMBLY 1	1	
2	51L-83332-01-00	. LENS, FLASHER	1	
3	256-84714-61-00	. BULB (12V-27/8W)	1	
4	97706-40620-00	. SCREW, TAPPING	1	
5	1UF-83320-00-00	FRONT FLASHER LIGHT ASSEMBLY 2	1	
6	51L-83342-01-00	. LENS, FLASHER 2	1	
7	256-84714-61-00	. BULB (12V-27/8W)	1	
8	97706-40620-00	. SCREW, TAPPING	1	
9	1UF-83330-00-00	REAR FLASHER LIGHT ASSEMBLY 1	1	
10	51L-83342-01-00	. LENS, FLASHER 2	1	
11	256-83311-70-00	. BULB (12V-27W)	1	
12	97706-40620-00	. SCREW, TAPPING	1	
13	1UF-83340-00-00	FLASHER LIGHT ASSEMBLY 2	1	
14	51L-83332-01-00	. LENS, FLASHER	1	
15	256-83311-70-XX	. BULB (12V-27W) (256-83311-70-00)	1	
16	97706-40620-00	. SCREW, TAPPING	1	
17	95707-12500-00	NUT, FLANGE	4	
18	18G-83365-00-00	CAP	4	
19	2MA-28365-41-00	COVER	2	BLACK
	2MA-28365-50-00	COVER	2	YELLOW
20	90183-04045-00	NUT, SPRING	4	
21	90480-35526-00	GROMMET	2	


METER



Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-83570-60-00	SPEEDOMETER ASSEMBLY . .	1	MPH
2	3GM-83540-00-00	TACHOMETER ASSEMBLY . . .	1	
3	3EN-83590-50-00	WATER TEMPERATURE ASSEMBLY	1	
4	3GM-83559-00-00	COVER, METER	1	
5	3GM-8353H-00-00	CASE, UNDER	1	
6	2GH-83578-00-00	KNOB, TRIP METER	1	
7	3HE-83509-50-00	SOCKET CORD ASSEMBLY . .	1	
8	4G1-84744-00-00	BULB, MTR. (12V-3.4W)	4	
9	3GM-83517-00-00	BULB (12V-1.7W)	3	
10	2GV-83517-00-00	BULB (12V-1.7W, T6.5)	1	
11	98507-04010-00	SCREW, PAN HEAD	4	
12	92907-04100-00	WASHER, SPRING	4	
13	92907-04600-00	WASHER	4	
14	90167-04057-00	SCREW, TAPPING	2	
15	98507-03010-00	SCREW, PAN HEAD	3	
16	92907-03100-00	WASHER	3	
17	90159-03102-00	SCREW, WITH WASHER	3	
18	90164-04008-00	SCREW, TAPPING	4	
19	90167-03058-00	SCREW, TAPPING	1	
20	4FM-83520-00-00	SOCKET CORD ASSEMBLY . .	1	
21	3GM-83513-00-00	DAMPER	1	
22	3GM-83525-00-00	CLIP	3	
23	98507-03012-00	SCREW, PAN HEAD	1	
24	92907-03100-00	WASHER	1	
25	90480-14229-00	GROMMET	2	
26	90387-07391-00	COLLAR	2	
27	95307-06600-00	NUT	2	
28	90201-06059-00	WASHER, PLATE	2	


CONTINUED ON NEXT FRAME ➤

METER



Ref. No.	Part Number	Description	Qty	Remarks
29	1RH-83550-00-00	SPEEDOMETER CABLE ASSEMBLY	1	


HEADLIGHT



3HH110-4420

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-84330-00-00	BODY ASSEMBLY	1	
2	2AX-84320-A0-00	LENS ASSEMBLY	1	
3	2AX-8432A-A0-00	LENS ASSEMBLY	1	
4	1ML-84314-00-XX	BULB (12V-35/35W) (1FM-84314-H0-00)	2	HALOGEN
5	2F9-84375-00-00	SETTING PLATE, BULB	2	
6	3MA-8430M-00-00	GEAR UNIT ASSEMBLY	2	
7	97706-40616-00	SCREW, TAPPING	4	
8	2AX-84331-00-00	SCREW, RIM ADJUSTING	2	
9	3AJ-8431U-00-00	HOLDER	2	
10	51L-84334-00-00	NUT, ADJUSTING	4	
11	3HE-84366-00-00	DAMPER, HEADLIGHT 1	1	
12	46X-84397-01-00	COVER, SOCKET	2	
13	3HH-84359-30-00	CORD, HEADLIGHT	1	
14	2F9-84397-01-00	COVER, SOCKET	2	

TAILLIGHT







3HH110-9430

Ref. No.	Part Number	Description	Qty	Remarks
1	52X-84710-60-00	TAILLIGHT UNIT ASSEMBLY . .	1	
2	47X-84721-00-00	. LENS, TAILLIGHT	1	
3	47X-84723-00-00	. GASKET, TAIL LENS	1	
4	47X-84735-00-00	. CORD ASSEMBLY	1	
5	256-84714-61-00	. BULB (12V-27/8W)	2	
6	90480-18407-00	GROMMET	3	
7	90201-063J2-00	WASHER, PLATE	4	
8	90387-060N3-00	COLLAR	2	
9	95601-06200-00	NUT, U FLANGE	2	
10	92906-10200-00	WASHER	1	
11	2LJ-84751-00-90	BRACKET, LICENSE	1	UNICHROME (BLACK CHROMATE)
12	90387-061M0-00	COLLAR	2	
13	95617-06100-00	NUT, U (95607-06100-00)	2	
14	3G1-85130-01-00	REAR REFLECTOR ASSEMBLY	1	
15	95701-05500-00	NUT, FLANGE	1	

HANDLE SWITCH - LEVER






FWD

3HH110-9440

Ref. No.	Part Number	Description	Qty	Remarks
1	3HH-83975-00-00	SWITCH, HANDLE 2	1	
2	98506-05040-00	. SCREW, PAN HEAD	1	
3	98506-05045-00	. SCREW, PAN HEAD	1	
4	3HH-83973-00-00	SWITCH, HANDLE 3	1	
5	98506-05035-00	. SCREW, PAN HEAD	2	
6	29L-82911-01-00	HOLDER, LEVER 1	1	
7	3HE-83912-00-00	LEVER 1	1	
8	31A-83913-00-00	COLLAR, LEVER 1	1	
9	31A-82917-00-00	SWITCH	1	
10	31A-83945-00-00	BOLT, LEVER	1	
11	98707-03008-00	SCREW, FLAT HEAD	1	
12	95607-06100-00	NUT, U	1	
13	97007-06025-00	BOLT	1	
14	92907-06100-00	WASHER, SPRING	1	
15	1FK-83922-00-00	LEVER 2	1	
16	90110-06074-00	BOLT, HEXAGON SOCKET HEAD	1	
17	95607-06100-00	NUT, U	1	
18	36Y-83913-01-00	COLLAR, LEVER 1	1	
19	90501-10312-00	SPRING, COMPRESSION	1	
20	90149-06131-00	SCREW	1	
21	90170-06355-00	NUT	1	
22	J45-82503-01-00	SWITCH, ALARM	1	
23	98507-04016-00	SCREW, PAN HEAD	1	
24	92907-04600-00	WASHER	1	
25	90338-09012-00	PLUG	1	


ELECTRICAL 1



3HHE110-5490

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-82310-01-00	IGNITION COIL ASSEMBLY . . .	1	
2	3HE-82320-00-00	IGNITION COIL ASSEMBLY . . .	1	
3	97006-06065-00	BOLT	2	
4	92906-06600-00	WASHER	2	
5	95316-06600-00	NUT	2	
6	1WG-82370-00-00	PLUG CAP ASSEMBLY	4	
7	3HE-82305-00-00	IGNITOR UNIT ASSEMBLY . . .	1	NON-CA
	3UU-82305-10-00	IGNITOR UNIT ASSEMBLY . . .	1	CA ONLY
8	97707-60520-00	SCREW, TAPPING	2	
9	36Y-81940-00-00	STARTER RELAY ASSEMBLY .	1	
10	95707-06500-00	NUT, FLANGE	2	
11	BTG-GM12A-Z3-A2	BATTERY ASSEMBLY (GM12AZ-3A-2) (2GV-82110-G0-00)	1	
12	1WG-82115-00-00	WIRE, PLUS LEAD	1	
13	3HE-82116-00-00	WIRE, MINUS LEAD	1	
14	90445-08719-00	HOSE	1	
15	1KT-82530-02-00	STOP SWITCH ASSEMBLY . . .	1	
16	3HH-82590-11-00	WIRE HARNESS ASSEMBLY . .	1	NON-CA
	3UU-82590-01-00	WIRE HARNESS ASSEMBLY . .	1	CA ONLY
17	2GH-82151-00-00	. FUSE (20A-BL)	2	
18	42X-82151-00-00	. FUSE (10A-BL)	4	
19	1AE-82151-00-00	. FUSE (30A-BL)	2	
20	90464-13073-00	CLAMP	2	
21	90464-13080-00	CLAMP	1	CA ONLY
22	4JH-81960-00-00	RECTIFIER & REGULATOR ASSEMBLY	1	
23	3HH-81975-00-00	PLATE, RECTIFIER FITTING . .	1	
24	95807-06010-00	BOLT, FLANGE	2	
25	95807-06025-00	BOLT, FLANGE	2	

CONTINUED ON NEXT FRAME ➤




3HHE110-5490

ELECTRICAL 1

Ref. No.	Part Number	Description	Qty	Remarks
26	90179-06520-00	NUT	2	
27	90464-11107-00	CLAMP	1	
28	3JV-82501-00-00	MAIN SWITCH STEERING LOCK	1	
29	90149-06228-00	SCREW	2	
30	90464-10075-00	CLAMP	1	

ELECTRICAL 2



3UU110-4480

Ref. No.	Part Number	Description	Qty	Remarks
1	1AE-82540-00-00	NEUTRAL SWITCH ASSEMBLY	1	
2	93210-29196-00	O-RING	1	
3	98580-06016-00	SCREW, PAN HEAD	2	
4	11H-83591-00-00	THERMO UNIT	1	
5	2GH-82509-00-00	WIRE, SUB LEAD	1	
6	1WG-85720-00-00	OIL LEVEL GAUGE ASSEMBLY	1	
7	95026-06016-00	BOLT, FLANGE	2	
8	2EL-82560-00-00	THERMOSWITCH ASSEMBLY	1	
9	1WG-82541-00-00	WIRE, LEAD	1	
10	3EN-81950-00-00	RELAY ASSEMBLY	1	
11	3LD-82566-50-00	SWITCH, SIDE STAND	1	
12	90157-05079-00	SCREW, PAN HEAD	2	
13	2UJ-83350-00-00	FLASHER RELAY ASSEMBLY	1	
14	3HE-83371-00-00	HORN	1	
15	95807-06012-00	BOLT, FLANGE	1	
16	11H-85110-01-00	REFLECTOR ASSEMBLY	2	
17	3G1-85130-01-00	REAR REFLECTOR ASSEMBLY	2	
18	95701-05500-00	NUT, FLANGE	4	
19	90480-14023-00	GROMMET	2	FOR CA ONLY
20	90387-074W0-00	COLLAR	2	FOR CA ONLY
21	90201-06067-00	WASHER, PLATE	2	FOR CA ONLY
22	95807-06025-00	BOLT, FLANGE	2	FOR CA ONLY
23	3LN-85820-00-00	SERVO MOTOR ASSY	1	FOR CA ONLY