

PARTS CATALOGUE
MODEL YEAR 1997
FZR600RJ (3HHH) U49
FZR600RJC (3UU8) CALIFORNIA

STARTING VIN (3HHH):	JYA3HHE0*VA102699
STARTING VIN (3UU8):	JYA3UUC0*VA019301

OWNERS	LIT-11626-10-37
ASSEMBLY	LIT-11666-09-75
SERVICE	LIT-11616-FZ-00

Color Code	Color Name	Abbreviation
04C	DEEP PURPLISH BLUE METALLIC 1	DPBM1
033	YAMAHA BLACK	YB

FOREWORD

-INTRODUCTION-
To The Yamaha Parts Fiche

This parts fiche lists parts and sub-assemblies for the FZR600RJ/RJC. When preparing a parts order, please refer to the most recently updated microfiche for this model.

THE YAMAHA PARTS FICHE

SYMBOLS

[ ]	Inactive, no longer available
U.R.	Use size (thickness) and/or number as required
U.N.	Use as many as you need
T	Number of teeth in a gear
V	Voltage for light bulbs
S	"S" type oil seal or "S" type circlip
SD,SO,SW	"SD", "SO", or "SW" type oil seal
E,R	"E" or "R" type circlip
F/No.	Frame No. (Applicable Machine No.)
L.M.	Locally made
O.L.	Obtain locally
AP	Alternate Part

SUPERSEDED PART NUMBERS

If part 'A' has been superseded by part 'B', the superseding part number "B" will appear in the part number listing with the superseded part number "A" appearing in parentheses immediately following the description.

EXAMPLE:

Ref. No.	Part No.	Description	Qty.
	(Part 'B')	(Part 'A')	
8	123-45678-00-00	CYLINDER (111-12345-00-00)	1

A part that has been supersede to a kit may be identified by a 99999-00000-00 part number appearing in the part number column. The old superseded part number will appear in parentheses immediately following the description. Listed directly below the 99999 part number will be those parts making up the kit. The description of the parts making up the kit will be preceded by a small black dot (.) and the description will be indented one letter space.

EXAMPLE:

Ref. No.	Part No.	Description	Qty.
8	99999-12345-00	CYLINDER (111-12345-00-00)	1
	234-56789-00-00	• HEAD, CYLINDER	1

SIZES

Except for steel balls (ball sizes are indicated in inches), all parts sizes are indicated in millimeters as in the following examples:

Hose (Rubber or Vinyl) ..... Inside Diameter - Length

O-Ring ..... Section Area - Inside Diameter

Washer, Shim, Collar ..... Inside Diameter - Outside Diameter
Thickness (Length)

ASSEMBLIES AND COMPONENT PARTS

Assemblies and their component parts, are identified by an indention of one letter space, and the description is preceded by a dot (.). If two main assemblies are listed, and have the same basic description (i.e.: left and right sides of the same assembly), one will immediately follow the other. If each of these main assemblies is made up of almost the same components, these component parts will be listed immediately under the second main assembly line and will be indicated, as noted above.


If the component is the same for both main assemblies, the quantity indicated will be the total required. If the component is not the same for both main assemblies, the quantity for each separate item will be listed separately.


EXAMPLE:

Description	Qty
CARBURETOR ASSY, LEFT	1
CARBURETOR ASSY, RIGHT	1
. JET, PILOT	2
. NOZZLE, MAIN	2
. LEVER, STARTER, LEFT	1
. LEVER, STARTER, RIGHT	1

APPLICABLE SERIAL NO.

(1) Engine Serial No. (2) Frame Serial No.






FOREWORD

THE YAMAHA PART NUMBER

The Yamaha part number consists of 12 digits. Each number represents a specific piece of information relating to a replacement part. The following is a guide for reading and interpreting the Yamaha part number.

BASIC PART NUMBER CONFIGURATION:



MODEL CODE NUMBER

FIRST THREE DIGITS . . . 000-00000-00-00


Every model in each Yamaha product line is assigned a model number to identify that particular model. All component parts are given the model code number relating to the model on which they were first used.

Example: 4DU-00000-00-00 identifies the XJ600SE.
3FA-00000-00-00 identifies the YFA1E.

BASIC CODE NUMBER


MIDDLE FIVE DIGITS . . . 000-00000-00-00

These "MIddle Five Digits" indicate the type of part i.e., piston, rings, lower units, etc. The five digits are broken down as follows:



The "Major Classification" indicates the section to which the parts belong, i.e., engine, electrical etc. The "Intermediate" and "Minor Classifications" indicate more specific details.

Example:



DESIGN CODE NUMBER: 000-00000-00-00

The design code distinguishes like component parts from one another when specification differences are involved. For example, distinguishing a standard size piston ring from an oversized piston ring.

Example:

4BR-11610- [0] **0-00** Standard Piston Ring Set for XJ600SE
4BR-11610- [2] **0-00** Oversize Piston Ring Set for XJ600SE

DESIGN CHANGE CODE NUMBER: 000-00000-00-00

This code number is used to identify a difference between a new component part and old one when a new part is created by changing the old one.

Example: YFZ350E

2GU-11610-0 [0] **-00** PISTON RING SET, STD. - ORIGINAL
2GU-11610-0 [1] **-00** PISTON RING SET, STD. - FIRST DESIGN CHANGE


Only major changes to performance, durability, quality, appearance, cost or interchangeability will affect a part number change.

COLOR CODE & SIZE CODE NUMBER: 000-00000-00-00

When applicable, the last two digits of the part number identify:

1. Color Code: The painted color or type of plating or surface treatment used on certain parts.
2. Size Code: The last two digits are also used to show the size of parts (mm). Such as the thickness of shims or the size of pistons.

HARDWARE (Fastener) PART NUMBER CONFIGURATION:



TYPE:

A fastener part number always begins with the number "9" followed by either a 0, 1, 2, 3, 4, 5, 6, 7 or 8 designating one of eight major divisions within this group.

FOREWORD

Example:

9	0	000-00000-00 "0" designates various types.
9	1	000-00000-00 "1" designates bolts, cotter pins, etc.
9	2	000-00000-00 "2" designates screw, nuts, etc.
9	3	000-00000-00 "3" designates oil seals, o-rings, bearings, etc.
9	4	000-00000-00 "4" designates spark plugs.
9	5	000-00000-00 "5" designates bolts and nuts.
9	7	000-00000-00 "7" designates ISO bolts.
9	8	000-00000-00 "8" designates ISO screws and nuts.

The only major divisions which the mechanic should become familiar with are those related to the general hardware (nuts, bolts, and washers), since these are the most commonly used and most often replaced items. By knowing how to interpret the part number, the dimensions of a piece of hardware can be determined. This can be very helpful during major engine repair, and general parts replacement.

BOLT EXAMPLE:

91311 - 06 018 - 00

6mm outside diameter — 18mm in length

EXCEPTION:

It is NOT possible to identify the LENGTH of bolts having a 901 prefix. Only the bolt diameter can be identified with this number.

NUT AND WASHER EXAMPLE:


95301 - 08600 - 00 NUT

8mm inside diameter

90201 - 25290 - 00 WASHER

25mm inside diameter


CYLINDER HEAD



3HE332-9010

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-11101-00-00	CYLINDER HEAD ASSEMBLY .	1	UR NON-CA
	3HW-11101-00-00	CYLINDER HEAD ASSEMBLY .	1	UR CA ONLY
2	1WG-11133-10-00	. GUIDE, INTAKE VALVE	16	
3	93440-10153-00	. CIRCLIP	16	
4	99510-08016-00	. PIN, DOWEL	12	
5	90340-12112-00	. PLUG, STRAIGHT SCREW ...	6	
6	90105-06384-00	. BOLT, WASHER BASED	24	
7	90338-08174-00	. PLUG	12	
8	90116-06437-00	BOLT, STUD	8	
9	90201-086M0-00	WASHER, PLATE	12	
10	90179-08530-00	NUT	12	
11	94701-00319-00	PLUG, SPARK (ND U27ESR-N)	4	UR
	NGK-CR9E0-00-00	PLUG, SPARK (NGK R CR9E) .	4	UR
12	3HE-11181-00-00	GASKET, CYLINDER HEAD 1 .	1	
13	2TK-11191-00-00	COVER, CYLINDER HEAD 1 ..	1	
14	1WG-11193-00-00	GASKET, HEAD COVER 1	1	
15	90109-064F0-00	BOLT	8	
16	90209-11262-00	WASHER	8	
17	2GH-1111G-00-00	RUBBER, MOUNT 1	8	


CYLINDER



3HE332-9020

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-11310-00-00	CYLINDER	1	UR NON -CA
	3HW-11310-00-00	CYLINDER	1	UR CA ONLY
2	93210-63442-00	O-RING	4	
3	99510-12016-00	PIN, DOWEL	2	
4	3HE-11351-00-00	GASKET, CYLINDER	1	
5	95817-06010-00	BOLT, FLANGE	2	
6	90430-06014-00	GASKET	2	


CRANKSHAFT - PISTON



Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-11411-00-00	CRANKSHAFT	1	
2	93101-26156-00	OIL SEAL	1	
3	1WG-11416-00-00	PLANE BEARING, CRANKSHAFT 1	12	UR BLUE
	1WG-11416-10-00	PLANE BEARING, CRANKSHAFT 1	12	UR BLACK
	1WG-11416-20-00	PLANE BEARING, CRANKSHAFT 1	12	UR BROWN
	1WG-11416-30-00	PLANE BEARING, CRANKSHAFT 1	12	UR GREEN
	1WG-11416-40-00	PLANE BEARING, CRANKSHAFT 1	12	UR YELLOW
4	3HE-11631-00-00	PISTON (STD)	4	
	3HE-11636-00-00	PISTON (0.50MM O/S)	4	AP
	3HE-11638-00-00	PISTON (1.00MM O/S)	4	AP
5	3HE-11610-00-00	PISTON RING SET (STD)	4	
	3HE-11610-20-00	PISTON RING SET (0.50MM O/S)	4	AP
	3HE-11610-40-00	PISTON RING SET (1.00MM O/S)	4	AP
6	3HE-11633-00-00	PIN, PISTON	4	
7	93450-17044-00	CIRCLIP	8	
8	3HE-11650-01-00	CONNECTING ROD ASSEMBLY	4	
9	1WG-11654-00-00	. BOLT, CONNECTING ROD	2	
10	90179-07531-00	. NUT	2	
11	1WG-11656-00-00	PLANE BEARING, CONNECTING ROD	8	UR BLUE
	1WG-11656-10-00	PLANE BEARING, CONNECTING ROD	8	UR BLACK
	1WG-11656-20-00	PLANE BEARING, CONNECTING ROD	8	UR BROWN
	1WG-11656-30-00	PLANE BEARING, CONNECTING ROD	8	UR GREEN

CONTINUED ON NEXT FRAME ➤

VALVE




1WG010-6040

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-12111-01-00	VALVE, INTAKE	8	
2	3HE-12121-00-00	VALVE, EXHAUST	8	
3	1WG-12116-00-00	SEAT, VALVE SPRING	16	
4	3HE-12113-00-00	SPRING, VALVE INNER	16	
5	1WG-12117-00-00	RETAINER, VALVE SPRING	16	
6	1WG-12118-00-00	COTTER, VALVE	32	
7	1WG-12119-00-00	SEAL, VALVE STEM	16	
8	1WG-12153-09-00	LIFTER, VALVE (O/S)	16	AP WHITE
	1WG-12153-21-00	LIFTER, VALVE	16	UR BLUE
	1WG-12153-31-00	LIFTER, VALVE	16	UR RED
9	1HX-12168-00-00	PAD, ADJUSTING 2 (1.20)	16	UR
	1HX-12168-20-00	PAD, ADJUSTING 2 (1.25)	16	UR
	1HX-12168-40-00	PAD, ADJUSTING 2 (1.30)	16	UR
	1HX-12168-60-00	PAD, ADJUSTING 2 (1.35)	16	UR
	1HX-12168-80-00	PAD, ADJUSTING 2 (1.40)	16	UR
	1HX-12168-A0-00	PAD, ADJUSTING 2 (1.45)	16	UR
	1HX-12168-F0-00	PAD, ADJUSTING 2 (1.50)	16	UR
	1HX-12168-H1-00	PAD, ADJUSTING 2 (1.55)	16	UR
	1HX-12168-K1-00	PAD, ADUSTING 2 (1.60)	16	UR
	1HX-12168-M1-00	PAD, ADJUSTING 2 (1.65)	16	UR
	1HX-12168-R1-00	PAD, ADJUSTING 2 (1.70)	16	UR
	1HX-12168-U1-00	PAD, ADJUSTING 2 (1.75)	16	UR
	1HX-12168-W1-00	PAD, ADJUSTING 2 (1.80)	16	UR
	1HX-12168-Y1-00	PAD, ADJUSTING 2 (1.85)	16	UR
	1HX-12169-11-00	PAD, ADJUSTING 2 (1.90)	16	UR
	1HX-12169-31-00	PAD, ADJUSTING 2 (1.95)	16	UR
	1HX-12169-50-00	PAD, ADJUSTING 2 (2.00)	16	UR
	1HX-12169-70-00	PAD, ADJUSTING 2 (2.05)	16	UR
	1HX-12169-90-00	PAD, ADJUSTING 2 (2.10)	16	UR

CONTINUED ON NEXT FRAME ➤


VALVE



1WG010-6040

Ref. No.	Part Number	Description	Qty	Remarks
9	1HX-12169-E0-00	PAD, ADJUSTING 2 (2.15)	16	UR
	1HX-12169-G0-00	PAD, ADJUSTING 2 (2.20)	16	UR
	1HX-12169-J0-00	PAD, ADJUSTING 2 (2.25)	16	UR
	1HX-12169-L0-00	PAD, ADJUSTING 2 (2.30)	16	UR
	1HX-12169-N0-00	PAD, ADJUSTING 2 (2.35)	16	UR
	1HX-12169-T0-00	PAD, ADJUSTING 2 (2.40)	16	UR


CAMSHAFT - CHAIN



3HE332-9050


Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-12171-00-00	CAMSHAFT 1	1	UR NON-CA
	3UU-12171-00-00	CAMSHAFT 1	1	UR CA ONLY
2	3HE-12181-00-00	CAMSHAFT 2	1	UR NON-CA
	3UU-12181-00-00	CAMSHAFT 2	1	UR CA ONLY
3	1WG-12176-00-00	SPROCKET, CAM CHAIN	2	
4	90105-07385-00	BOLT, WASHER BASED	4	
5	94581-32118-00	CHAIN (D.I.D. 215F DHA 118L)	1	
6	4TV-11498-00-00	. PIN, JOINT	1	
7	1WG-12241-00-00	GUIDE, STOPPER 2	1	
8	3GM-12210-00-00	TENSIONER ASSEMBLY, CAM CHAIN	1	
9	90109-112F1-00	BOLT	1	
10	4BE-12213-00-00	GASKET, TENSIONER CASE	1	
11	91317-06025-00	BOLT	2	
12	3HE-12251-00-00	DAMPER, CHAIN 1	1	
13	3HE-12252-00-00	DAMPER, CHAIN 2	1	
14	90109-065A8-00	BOLT	2	

WATER PUMP



Ref. No.	Part Number	Description	Qty	Remarks
1	3TJ-Y1242-00-00	WATER PUMP ASSEMBLY	1	
2	1WG-12439-00-00	. O-RING	1	
3	91317-06025-00	. BOLT	2	
4	95027-06012-00	. BOLT, FLANGE	1	
5	90430-06014-00	. GASKET	1	
6	93210-33133-00	. O-RING	1	
7	90110-06237-00	BOLT	2	
8	3HE-12579-00-00	HOSE 4	1	
9	1WG-12481-00-00	PIPE 1	1	
10	93210-21190-00	O-RING	2	
11	91317-06012-00	BOLT	2	
12	1WG-12446-01-00	JOINT	1	
13	93210-17746-00	O-RING	2	
14	91317-06040-00	BOLT	3	
15	91317-06025-00	BOLT	1	
16	1WG-12482-00-00	PIPE 2	1	
17	1WG-12483-00-00	PIPE 3	1	
18	93210-15566-00	O-RING	2	
19	91317-06012-00	BOLT	2	
20	3HE-12576-00-00	HOSE 1	1	
21	3HE-12577-00-00	HOSE 2	1	
22	46X-12410-00-00	THERMOSTAT ASSEMBLY	1	
23	1WG-12417-00-00	HOUSING, THERMOSTAT	1	
24	1WG-12413-01-00	COVER, THERMOSTAT	1	
25	91317-06020-00	BOLT	2	
26	90450-32051-00	HOSE CLAMP ASSY	2	
27	90450-28014-00	HOSE CLAMP ASSY	4	

RADIATOR - HOSE




FWD

3HH110-1070

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-12461-00-00	RADIATOR ASSEMBLY	1	
2	3HE-12405-00-00	BLOWER ASSEMBLY	1	
3	1AA-12630-00-00	. MOTOR ASSEMBLY	1	
4	1UF-12611-00-00	. FAN	1	
5	98507-05008-00	. SCREW, PAN HEAD	3	
6	92990-05600-00	. WASHER, PLATE	3	
7	90119-06044-00	. BOLT, WITH WASHER	3	
8	2TK-12590-00-00	CONDUCTION ASSEMBLY	1	
9	4FL-12462-00-00	. CAP, RADIATOR (22W-12462-00-00)	1	
10	95817-06010-00	BOLT, FLANGE	2	
11	90450-32051-00	HOSE CLAMP ASSY	4	
12	90445-096E8-00	HOSE	1	
13	90467-08003-00	CLIP	2	
14	90338-20188-00	PLUG	1	
15	90480-15483-00	GROMMET	2	
16	90387-074W0-00	COLLAR	2	
17	95817-06025-00	BOLT, FLANGE	2	
18	3HE-12578-00-00	HOSE 3	1	
19	3HE-12588-10-00	HOSE 5	1	
20	25G-83936-01-00	BAND, SWITCH CORD	1	


OIL PUMP



3HE332-9080

Ref. No.	Part Number	Description	Qty	Remarks
1	1WG-13330-01-00	PUMP SHAFT ASSEMBLY	1	
2	1WG-13316-00-00	COVER, PUMP	1	
3	90201-113K2-00	WASHER, PLATE	1	
4	93603-17070-00	PIN, DOWEL	1	
5	1WG-13310-00-00	ROTOR ASSEMBLY 1	1	
6	93603-09106-00	PIN, DOWEL	2	
7	1WG-13336-00-00	HOUSING, ROTOR	1	
8	98517-06020-00	SCREW, PAN HEAD	1	
9	99510-08012-00	PIN, DOWEL	1	
10	1WG-13329-00-00	GASKET, PUMP COVER	1	
11	90110-06130-00	BOLT, HEXAGON SOCKET HEAD	3	
12	1WG-13412-00-00	HOUSING, STRAINER	1	
13	4H7-13411-02-00	STRAINER, OIL	1	
14	90110-06225-00	BOLT, HEXAGON SOCKET HEAD	2	


OIL COOLER



3HH110-1090

Ref. No.	Part Number	Description	Qty	Remarks
1	3TJ-13461-00-00	PLATE, ADAPTOR	1	
2	90401-20145-00	BOLT, UNION	1	
3	93210-87723-00	O-RING	1	
4	3FV-13440-00-00	ELEMENT ASSY, OIL CLEANER	1	
5	11H-13490-00-00	RELIEF VALVE ASSEMBLY	1	
6	93210-10096-00	O-RING	1	
7	1WG-13417-00-00	COVER, STRAINER	1	
8	4TV-13414-00-00	GASKET, STRAINER COVER	1	
9	91317-06025-00	BOLT	14	
10	99510-08016-00	PIN, DOWEL	2	
11	3VD-13455-00-00	PLUG	1	
12	214-11198-01-00	GASKET	1	
13	90465-10306-00	CLAMP	1	
14	3HE-13161-00-00	PIPE, DELIVERY 1	1	
15	91317-06012-00	BOLT	1	
16	90401-10106-00	BOLT, UNION	2	
17	90430-10171-00	GASKET	4	


INTAKE



3HHE110-5100

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-13586-00-00	JOINT, CARBURETOR 1	2	
2	3HE-13596-00-00	JOINT, CARBURETOR 2	2	UR CA ONLY
	3HE-13596-00-00	JOINT, CARBURETOR 2	2	UR NON-CA
3	3HW-13596-00-00	JOINT, CARBURETOR 2	2	CA ONLY
4	91317-06020-00	BOLT	8	
5	90450-49020-00	HOSE CLAMP ASSY	4	
6	3HE-14411-00-00	CASE, AIR CLEANER 1	1	UR NON- CA
	3HW-14411-00-00	CASE, AIR CLEANER 1	1	UR CA ONLY
7	1WG-14421-00-00	CASE, AIR CLEANER 2	1	
8	1VJ-14462-00-00	SEAL	1	
9	97707-50525-00	SCREW, TAPPING	11	
10	1WG-14451-00-00	ELEMENT, AIR CLEANER	1	
11	3HE-14412-00-00	CAP, CLEANER CASE 1	1	
12	5T0-14457-00-00	SEAL	1	
13	3HE-14453-00-00	JOINT, AIR CLEANER 1	4	
14	90460-58015-00	CLAMP, HOSE	4	
15	90445-11452-00	HOSE (L125)	1	
16	90467-10008-00	CLIP	3	
17	4X7-2149Y-00-00	FILTER ASSY	1	
18	90445-115E8-00	HOSE	1	
19	98507-05016-00	SCREW, PAN HEAD	4	
20	92907-05600-00	WASHER, PLATE	4	
21	31A-14435-00-00	GROMMET	1	CA ONLY


EMISSION CONTROL DEVICE (CALIFORNIA ONLY



3HHG110-6110

Ref. No.	Part Number	Description	Qty	Remarks
1	31A-14419-00-00	PIPE	1	
2	42H-14714-10-00	GASKET, MUFFLER	4	
3	3HW-14872-00-00	PIPE 2	1	
4	90450-22052-00	. HOSE CLAMP ASSY	2	
5	3HW-14873-00-00	PIPE 3	1	
6	90450-22052-00	. HOSE CLAMP ASSY	2	
7	2LJ-14883-00-00	HOSE, BEND 3	4	
8	90468-08104-00	CLIP	8	
9	3HW-14808-00-00	REED VALVE ASSEMBLY	1	
10	90480-14229-00	GROMMET	4	
11	90387-07391-00	COLLAR	4	
12	95027-06025-00	BOLT, FLANGE	4	
13	2LJ-14874-00-00	PIPE 4	1	
14	2LJ-14881-00-00	HOSE, BEND 1	2	
15	2LJ-14882-00-00	HOSE, BEND 2	1	
16	90467-17089-00	CLIP	1	
17	3HF-14840-00-00	AIR CUT VALVE ASS''Y	1	
18	90462-20188-00	CLAMP	1	
19	98507-06016-00	SCREW, PAN HEAD	1	
20	92907-06600-00	WASHER, PLATE	1	
21	90445-090G9-00	HOSE	1	
22	90467-08092-00	CLIP	2	
23	3HW-14885-00-00	HOSE, BEND 5	1	
24	3HW-14875-00-00	PIPE 5	1	
25	95027-06012-00	BOLT, FLANGE	2	
26	3HW-14884-00-00	HOSE, BEND 4	1	
27	90467-14015-00	CLIP	1	
28	90464-30040-00	CLAMP	2	
29	90464-23041-00	CLAMP	1	

CARBURETOR




3HHE110-5120

Ref. No.	Part Number	Description	Qty	Remarks
1	3HH-14901-04-00	CARBURETOR ASSEMBLY 1 .	1	UR NON-CA
	3UU-14901-04-00	CARBURETOR ASSEMBLY 1 .	1	UR CA ONLY
2	3HH-14902-04-00	CARBURETOR ASSEMBLY 2 .	1	UR NON-CA
	3UU-14902-04-00	CARBURETOR ASSEMBLY 2 .	1	UR CA ONLY
3	3HH-14903-04-00	CARBURETOR ASSEMBLY 3 .	1	UR NON-CA
	3UU-14903-04-00	CARBURETOR ASSEMBLY 3 .	1	UR CA ONLY
4	3HH-14904-04-00	CARBURETOR ASSEMBLY 4 .	1	UR NON- CA
	3UU-14904-04-00	CARBURETOR ASSEMBLY 4 .	1	UR CA ONLY
5	1A8-14953-00-00	. WASHER	1	
6	256-14997-00-00	. SEAL	1	4
	256-14997-00-00	. SEAL	2	3
7	98580-04010-00	. SCREW, PAN HEAD	2	
8	98507-05016-00	. SCREW, PAN HEAD	2	
9	92907-05100-00	. WASHER, SPRING	2	
10	92907-05600-00	. WASHER, PLATE	2	
11	3EN-14243-00-00	. PLATE	1	
12	3EN-14239-00-00	. SEAL	1	
13	3GM-14147-00-00	. O-RING	1	
14	1AE-14565-00-00	. SCREW	1	
15	137-14153-00-00	. WASHER, MAIN JET	1	
16	1AE-14147-00-00	. O-RING	1	
17	3EN-1411E-00-00	. BLOCK JET ASSEMBLY (3EN-1411A-00-00)	1	
18	3GM-14997-00-00	. SEAL	1	
19	3HE-14933-00-00	. SPRING, DIAPHRAGM	1	
20	3HE-14940-00-00	. DIAPHRAGM ASSEMBLY . . .	1	
21	3HE-14985-00-00	. FLOAT	1	
22	353-14186-00-00	. PIN, FLOAT	1	
23	3HH-14107-10-00	. NEEDLE VALVE SET	1	

CONTINUED ON NEXT FRAME ➤


CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
24	3EN-14147-00-00	. O-RING	1	
25	12R-14191-00-00	. PLUG, DRAIN	1	
26	98517-05012-00	. SCREW, PAN HEAD	2	
27	3EN-1410A-01-00	. STARTER SET	1	
28	12R-14105-00-00	. PILOT SCREW SET	1	
29	3HH-1490J-00-00	. NEEDLE SET	1	
30	3G2-1423A-72-00	. JET, MAIN (107.5)	1	
31	3EN-14141-90-00	. NOZZLE, MAIN	1	
32	4G0-14142-32-A0	. JET, PILOT (32.5)	1	
33	830-1423A-77-00	. JET, PILOT AIR (132.5)	1	
34	3G2-14231-10-00	. JET, POWER (50)	11	UR CA ONLY
	3G2-1423A-61-00	. JET, STARTER (52.5)	1	UR NON-CA
35	3HE-1411A-00-00	. BLOCK JET ASSEMBLY	1	
36	1AE-14227-00-00	. O-RING	1	
37	3F9-14118-00-00	. CAP	1	
38	3HE-14103-00-00	THROTTLE SCREW SET	1	
39	95380-05600-00	NUT	1	
40	2GV-14953-00-00	WASHER	1	
41	3EN-14997-00-00	SEAL	6	
42	3HE-14163-00-00	SPACER	2	
43	3EN-14197-00-00	PIPE	2	
44	8U9-14139-00-00	CLIP, PIPE	2	
45	3EN-14988-00-00	PIPE, STARTER CONNECTING	1	
46	822-14147-00-00	O-RING	4	
47	17A-14251-00-00	NIPPLE	2	
48	3HE-14148-00-00	PIPE	1	
49	95380-06600-00	NUT, HEXAGON	1	
50	92990-06600-00	WASHER, PLATE	1	
51	3EN-1490K-00-00	STOP SCREW SET	3	

CONTINUED ON NEXT FRAME ➤


CARBURETOR



3HHE110-5120

Ref. No.	Part Number	Description	Qty	Remarks
52	3EN-14261-00-00	HOLDER	2	
53	98507-05008-00	SCREW, PAN HEAD	1	


EXHAUST (NON-CALIFORNIA)



3HHH100-7130

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-14602-00-00	EXHAUST PIPE COMP.	1	
2	90101-06576-00	. BOLT	4	
3	92907-06600-00	. WASHER, PLATE	4	
4	3YF-14613-01-00	GASKET, EXHAUST PIPE	4	
5	90179-06668-00	NUT	8	
6	95817-08030-00	BOLT, WASHER BASED	1	
7	90201-08730-00	WASHER, PLATE	1	
8	3HH-14710-11-00	MUFFLER ASSEMBLY 1	1	
9	3HE-14755-00-00	. GASKET, SILENCER	1	
10	95817-08025-00	. BOLT, FLANGE	1	
11	95817-08012-00	BOLT, FLANGE	1	


EXHAUST 2 (CALIFORNIA ONLY)



3HHH100-7140

Ref. No.	Part Number	Description	Qty	Remarks
1	3HW-14610-00-00	EXHAUST PIPE ASSEMBLY 1 .	1	
2	90101-06576-00	. BOLT	4	
3	92907-06600-00	. WASHER, PLATE	4	
4	3FH-14821-01-00	. ARM, SHAFT (VALVE)	1	
5	3FH-14811-00-00	. HOUSING	1	
6	3FH-14815-00-00	. GASKET	1	
7	2TK-14845-00-00	. DUST SEAL ASSEMBLY	1	
8	2TK-14867-01-00	. BRACKET	1	
9	90119-06115-00	. BOLT, WITH WASHER	3	
10	90201-106M5-00	. WASHER, PLATE	1	
11	90380-10197-00	. BUSH, SOLID	2	
12	2TK-14865-01-00	. PULLEY	1	
13	92907-05200-00	. WASHER	1	
14	97017-05012-00	. BOLT	1	
15	90387-106U7-00	. COLLAR	1	
16	4HD-14826-00-00	PROTECTOR, EXHAUST	1	
17	3EN-14624-10-00	COVER, EXHAUST	1	
18	90119-06131-00	BOLT, WITH WASHER	3	
19	3YF-14613-01-00	GASKET, EXHAUST PIPE	4	
20	90179-06668-00	NUT	8	
21	95817-08030-00	BOLT, WASHER BASED	1	
22	90201-08730-00	WASHER, PLATE	1	
23	3HH-14710-11-00	MUFFLER ASSEMBLY 1	1	
24	3HE-14755-00-00	. GASKET, SILENCER	1	
25	95817-08025-00	. BOLT, FLANGE	1	
26	95817-08012-00	BOLT, FLANGE	1	
27	3HX-1133E-03-00	CABLE, PULLEY 1	1	
28	3HX-1133F-03-00	CABLE, PULLEY 2	1	


CRANKCASE



Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-15100-11-00	CRANKCASE ASSEMBLY	1	
2	11H-15138-00-00	. NOZZLE 1	1	
3	26H-15138-00-00	. NOZZLE 1	1	
4	99510-12016-00	. PIN, DOWEL	1	
5	1HX-15138-00-00	. NOZZLE 1	1	
6	93210-12152-00	. O-RING	1	
7	2H7-15361-00-00	. GAUGE, LEVEL	1	
8	36Y-15189-00-00	. PLUG	2	
9	93210-16629-00	. O-RING	2	
10	90201-237K5-00	. WASHER, PLATE	1	
11	93315-32516-00	. BEARING	1	
12	90116-08526-00	BOLT, STUD	2	
13	90116-08525-00	BOLT, STUD	10	
14	90105-08630-00	BOLT, WASHER BASED	12	
15	90201-087K3-00	WASHER, PLATE	12	
16	95817-06040-00	BOLT, FLANGE	10	
17	95817-06050-00	BOLT, FLANGE	5	
18	95817-06070-00	BOLT, FLANGE	3	
19	95817-06080-00	BOLT, FLANGE	1	
20	95817-06090-00	BOLT, FLANGE	2	
21	95817-08070-00	BOLT, FLANGE	1	
22	90430-06166-00	GASKET	1	
23	90465-10307-00	CLAMP	1	
24	90465-10308-00	CLAMP	1	
25	3HE-11165-00-00	PLATE, BREATHER	1	
26	98517-06012-00	SCREW, PAN HEAD	2	
27	3HE-11145-00-00	PLATE, BREATHER 2	1	
28	98517-06012-00	SCREW, PAN HEAD	4	
29	1WG-11166-00-00	PIPE, BREATHER 1	1	


CONTINUED ON NEXT FRAME ➤

CRANKCASE



Ref. No.	Part Number	Description	Qty	Remarks
30	90467-14015-00	CLIP	2	
31	90445-116E9-00	HOSE	1	
32	90465-06289-00	CLAMP	1	
33	90467-10038-00	CLIP	1	
34	1WG-15381-00-00	PLATE, BEARING COVER	1	
35	91317-06012-00	BOLT	2	
36	3HE-15105-00-00	NOZZLE ASSEMBLY	2	
37	93210-06632-00	O-RING	2	
38	99510-12016-00	PIN, DOWEL	2	

CRANKCASE COVER 1




3HE332-9150

Ref. No.	Part Number	Description	Qty	Remarks
1	2TK-15411-00-00	COVER, CRANKCASE 1	1	
2	1L9-15417-00-00	COVER, CAP	1	
3	1WG-15316-00-00	DAMPER, ENGINE MOUNT 1	1	
4	1WG-15427-00-00	COVER, CAP 2	1	
5	98907-05008-00	SCREW, BIND	4	
6	3HE-15451-10-00	GASKET, CRANKCASE COVER 1	1	
7	3FA-15467-00-00	GASKET	1	
8	99510-08016-00	PIN, DOWEL	2	
9	90110-06149-00	BOLT, HEXAGON SOCKET HEAD	4	
10	90110-06130-00	BOLT, HEXAGON SOCKET HEAD	1	
11	2TK-15421-00-00	COVER, CRANKCASE 2	1	
12	3HE-15461-10-00	GASKET, CRANKCASE COVER 2	1	
13	99510-08016-00	PIN, DOWEL	2	
14	91317-06025-00	BOLT	2	
15	90110-06237-00	BOLT	4	
16	91317-06045-00	BOLT	1	
17	2TK-15431-01-00	COVER, CRANKCASE 3	1	
18	1WG-15425-00-00	COVER, GENERATOR 2	1	
19	1WG-15326-00-00	DAMPER, ENGINE MOUNT 2	1	
20	98907-05008-00	SCREW, BIND	4	
21	3HE-15462-10-00	GASKET, CRANKCASE COVER 3	1	
22	99510-08016-00	PIN, DOWEL	2	
23	91317-06025-00	BOLT	8	
24	90110-06237-00	BOLT	2	
25	3F9-15362-00-00	PLUG, OIL LEVEL	1	


CONTINUED ON NEXT FRAME ➤

CRANKCASE COVER 1



Ref. No.	Part Number	Description	Qty	Remarks
26	93210-27778-00	O-RING	1	
27	3HE-15415-01-00	COVER, GENERATOR	1	
28	90340-08M04-00	PLUG, STRAIGHT SCREW	1	
29	99510-08016-00	PIN, DOWEL	2	
30	91317-06025-00	BOLT	3	
31	90110-06237-00	BOLT	1	
32	90110-06237-00	BOLT	1	
33	90462-10182-00	CLAMP	1	
34	98507-06010-00	SCREW, PAN HEAD	1	


STARTER CLUTCH



3HE332-9160

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-15521-00-00	SHAFT 1	1	
2	3HE-15512-00-00	GEAR, IDLER 1	1	
3	3HE-15517-00-00	GEAR, IDLER 2	1	
4	3TJ-15521-00-00	SHAFT 1	2	
5	3HE-15590-02-00	STARTER ONE-WAY ASSEMBLY	1	
6	3HE-15524-00-00	WHEEL, STARTER	1	
7	91317-08020-00	BOLT	3	
8	4JH-15515-00-00	GEAR 3	1	
9	90280-16053-00	KEY, WOODRUFF (90280-05048-00)	1	
10	90201-107K6-00	WASHER, PLATE	1	
11	90105-10445-00	BOLT, WASHER BASED	1	
12	93306-20005-00	BEARING (B6200)	1	NTN


CLUTCH



3HE332-9170

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-16150-00-00	PRIMARY DRIVEN GEAR COMP.	1	
2	1WG-16154-00-00	PLATE, THRUST 1	1	
3	3HE-16371-00-00	BOSS, CLUTCH	1	
4	21V-16321-00-00	PLATE, FRICTION	9	
5	131-16324-00-00	PLATE, CLUTCH 1	8	
6	2TK-16351-00-00	PLATE, PRESSURE 1	1	
7	90501-227E0-00	SPRING, COMPRESSION	5	
8	90119-05001-00	BOLT, WITH WASHER	5	
9	1WG-16356-00-00	ROD, PUSH 1	1	
10	93210-48364-00	O-RING	1	
11	90215-18225-00	WASHER, LOCK	1	
12	90170-18221-00	NUT	1	
13	93109-08058-00	OIL SEAL (SD07 8-21-5.5 HS)	1	
14	1WG-16357-01-00	ROD, PUSH 2	1	
15	93505-16006-00	BALL	1	
16	1WG-16340-01-00	PUSH LEVER ASSEMBLY	1	
17	1WG-16304-00-00	BALL SCREW HOUSING ASSEMBLY	1	
18	90113-08021-00	BOLT, SET	1	
19	90179-08179-00	NUT	1	
20	90506-11488-00	SPRING, TENSION	1	
21	90157-05065-00	SCREW, PAN HEAD	2	
22	132-16346-00-00	HOOK, SPRING	1	
23	90387-212R3-00	COLLAR	1	
24	1WG-16164-00-00	PLATE, THRUST 2	1	
25	1WG-16181-00-00	SPACER 1	1	
26	93310-345R8-00	BEARING	1	

TRANSMISSION




3HE332-9180

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-17411-10-00	AXLE, MAIN (13T)	1	
2	3HE-17151-00-00	GEAR, 5TH PINION (26T)	1	
3	90209-18208-00	WASHER	1	
4	93410-22039-00	CIRCLIP	1	
5	3HE-17131-00-00	GEAR, 3RD PINION (21T)	1	
6	3HE-17161-00-00	GEAR, 6TH PINION (27T)	1	
7	3HE-17121-10-00	GEAR, 2ND PINION (22T)	1	
8	93306-37208-00	BEARING	1	
9	93440-54152-00	CIRCLIP	1	
10	93399-99933-00	BEARING	1	
11	278-17425-00-00	CIRCLIP 2	1	
12	3HE-17421-00-00	AXLE, DRIVE	1	
13	93306-30550-00	BEARING	1	
14	3HE-17221-10-00	GEAR, 2ND WHEEL (37T)	1	
15	90209-27192-00	WASHER	1	
16	93440-30077-00	CIRCLIP	1	
17	3HE-17261-10-00	GEAR, 6TH WHEEL (30T)	1	
18	3HE-17231-00-00	GEAR, 3RD WHEEL (31T)	1	
19	3HE-17241-00-00	GEAR, 4TH WHEEL (28T)	1	
20	90209-22191-00	WASHER	1	
21	93440-25084-00	CIRCLIP	1	
22	3HE-17251-00-00	GEAR, 5TH WHEEL (31T)	1	
23	3HE-17211-10-00	GEAR, 1ST WHEEL (42T)	1	
24	90387-255V4-00	COLLAR	1	
25	93102-35109-00	OIL SEAL (SD-35-62-6 HS)	1	
26	3HE-17460-00-00	SPROCKET, DRIVE (15T)	1	
27	90215-21022-00	WASHER, LOCK	1	
28	90179-18020-00	NUT	1	
29	90201-20276-00	WASHER, PLATE (1.0T)	1	

CONTINUED ON NEXT FRAME ➤


TRANSMISSION



3HE332-9180

Ref. No.	Part Number	Description	Qty	Remarks
30	93311-42045-00	BEARING (20NG3315NE)	1	
31	278-17424-01-00	CIRCLIP 1	1	
32	278-17425-00-00	CIRCLIP 2	1	
33	4G0-17433-01-00	NOZZLE	1	


SHIFT CAM - SHIFT FORK



1WG010-6180

Ref. No.	Part Number	Description	Qty	Remarks
1	1WG-18540-01-00	SHIFT CAM ASSEMBLY	1	
2	90501-06022-00	. SPRING, COMPRESSION	1	
3	278-18542-00-00	. POINT, NEUTRAL	1	
4	278-18566-00-00	. PLATE, SIDE 2	1	
5	98707-05012-00	. SCREW, FLAT HEAD	1	
6	1WG-18531-01-00	BAR, SHIFT FORK GUIDE 1 . . .	1	
7	1WG-18535-01-00	BAR, SHIFT FORK GUIDE 2 . . .	1	
8	1WG-18511-00-00	FORK, SHIFT 1	1	
9	1WG-18512-00-00	FORK, SHIFT 2	1	
10	1WG-18513-00-00	FORK, SHIFT 3	1	
11	1WG-18536-00-00	STOPPER, SHIFT BAR	1	
12	1HX-18127-00-00	STOPPER, SCREW	1	
13	90508-23707-00	SPRING, TORSION	1	
14	1WG-18562-00-00	PLATE, STOPPER 2	1	
15	36Y-18140-00-00	STOPPER LEVER ASSEMBLY .	1	
16	90109-063F7-00	BOLT	1	
17	95817-06016-00	BOLT, FLANGE	2	


SHIFT SHAFT



3HE332-9200


Ref. No.	Part Number	Description	Qty	Remarks
1	3EN-18101-01-00	SHIFT SHAFT ASSEMBLY	1	
2	90508-32682-00	. SPRING, TORSION	1	
3	93102-12321-00	OIL SEAL, SD-TYPE	1	
4	90560-12211-00	SPACER	1	
5	93109-12053-00	OIL SEAL (SDO 12/18/4-1)	2	
6	3HE-18110-00-00	SHIFT PEDAL ASSEMBLY	1	
7	2H9-18154-00-00	. COVER, DUST	1	
8	132-18113-01-00	. COVER, SHIFT PEDAL	1	
9	1WG-18112-01-00	ARM, SHIFT	1	
10	2H9-18154-00-00	. COVER, DUST	1	
11	97017-06020-00	BOLT	1	
12	1WG-18115-01-00	ROD, SHIFT	1	
13	90170-06228-00	NUT (COUNTER CLOCKWISE)	1	
14	95304-06700-00	NUT	1	

FRAME




Ref. No.	Part Number	Description	Qty	Remarks
1	3HW-21110-01-35	FRAME COMP.	1	SILVER
2	1WG-2143A-00-00	CAP	2	
3	3HE-2117E-00-00	BRACKET, TAILLIGHT	1	
4	90109-06757-00	BOLT	4	
5	3HH-21140-01-35	DOWN TUBE COMP.	1	UR SILVER NON-CA
	3HW-21140-00-35	DOWN TUBE COMP.	1	UR SILVER
6	3HH-21150-01-35	DOWN TUBE COMP 2	1	UR SILVER NON-CA
	3HW-21150-00-35	DOWN TUBE COMP 2	1	UR SILVER
7	90105-10436-00	BOLT, WASHER BASED	4	
8	95707-10500-00	NUT, FLANGE	4	
9	91317-08020-00	BOLT	4	
10	95817-10080-00	BOLT, FLANGE	2	
11	95817-10295-00	BOLT, FLANGE	1	
12	95817-10165-00	BOLT, FLANGE	1	
13	95707-10500-00	NUT, FLANGE	4	
14	1WG-21459-00-00	SPACER	2	
15	1WG-2142M-00-00	BRACKET, RADIATOR 3	1	
16	95817-06016-00	BOLT, FLANGE	1	
17	3HE-21238-00-00	BRACKET	1	
18	95817-06012-00	BOLT, FLANGE	1	
19	90480-18171-00	GROMMET	1	
20	3HE-2137Y-00-00	GUIDE, AIR	1	
21	1WG-2139W-00-00	COVER	1	
22	95707-06600-00	NUT, FLANGE	1	
23	90480-01401-00	GROMMET	1	
24	90480-13398-00	GROMMET	1	
25	3HE-2137W-00-00	SCOOP, AIR 1	1	
26	3HE-2137X-00-00	SCOOP, AIR 2	1	
27	3HE-2139U-00-00	DAMPER 2	2	

CONTINUED ON NEXT FRAME ➤



FRAME

Ref. No.	Part Number	Description	Qty	Remarks
28	90119-06079-00	BOLT, WITH WASHER	3	
29	90387-06681-00	COLLAR	2	
30	3HE-2117M-00-00	COVER 2	1	
31	3HE-2117N-00-00	COVER 3	1	
32	90338-15202-00	PLUG	2	
33	3HE-2117R-00-00	COVER 4	2	
34	3HE-2117T-00-00	COVER 5	2	
35	3HE-21446-00-00	STAY, MUFFLER 2	1	
36	3HW-2149T-00-00	BRACKET, SERVO MOTOR	1	CA ONLY
37	95807-06016-00	BOLT, FLANGE	1	CA ONLY




3HHH100-7230

FENDER

Ref. No.	Part Number	Description	Qty	Remarks
1	3FH-21510-00-33	FRONT FENDER COMP.	1	UR YAMAHA BLACK (033)
	3FH-21510-00-P1	FRONT FENDER COMP.	1	UR DEEP PURPLISH BLUE METALLIC C (514)
2	26H-21746-00-00	. DAMPER	2	
3	46X-2313A-00-00	BRACE, FORK	1	
4	90105-06456-00	BOLT, WASHER BASED	4	
5	90338-12192-00	PLUG	1	
6	3LK-25875-00-00	HOLDER, BRAKE HOSE 1 (3FH-25875-00-00)	1	
7	4PR-25876-00-00	HOLDER, BRAKE HOSE 2 (3FH-25876-00-00)	1	
8	95027-06025-00	BOLT, FLANGE	2	
9	3HE-21611-10-00	FENDER, REAR	1	
10	2MG-21639-00-00	DAMPER 2	1	
11	90480-10258-00	GROMMET	2	
12	90387-066M3-00	COLLAR	2	
13	90119-06108-00	BOLT, WITH WASHER	4	
14	31A-14477-00-00	PLATE	2	
15	3HE-85132-01-00	BRACKET, REFLECTOR 1	1	
16	90267-40029-00	RIVET, BLIND	2	
17	90201-04018-00	WASHER, PLATE	2	
18	25G-28379-00-00	HOOK	1	
19	90267-40076-00	RIVET, BLIND	2	
20	90201-04018-00	WASHER, PLATE	2	
21	26L-82131-00-00	BAND, BATTERY	1	
22	34M-21649-00-00	DAMPER	1	
23	3HE-21629-00-00	GUARD, MUD	1	
24	3HE-21651-00-33	COVER, REAR FENDER	1	UR YAMAHA BLACK (033)

CONTINUED ON NEXT FRAME ➤




3HHH100-7230

FENDER

Ref. No.	Part Number	Description	Qty	Remarks
24	3HE-21651-00-P6	COVER, REAR FENDER	1	UR DEEP PURPLISH BLUE METALLIC C (514)
25	99231-00080-00	EMBLEM, YAMAHA	1	
26	2GH-21575-00-00	SEAL 1	1	
27	2GH-21576-00-00	SEAL 2	1	
28	2GH-21735-00-00	SEAL 2	2	
29	1WG-28100-01-00	TOOL KIT	1	
30	90159-06033-00	SCREW, WITH WASHER	4	
31	J44-78248-00-00	SEAL 4	1	
32	2LJ-21688-00-00	BRACKET, REAR STAY	1	
33	2LJ-21689-00-00	BRACKET, REAR STAY 2	1	
34	90267-40076-00	RIVET, BLIND	4	
35	90201-04018-00	WASHER, PLATE	4	
36	3HH-21660-01-00	GRAPHIC	1	FOR YB


SIDE COVER



Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-Y2171-10-P3	COVER, SIDE 1	1	UR DEEP PURPLISH BLUE METALLIC C (564)
	3HE-Y2171-70-33	COVER, SIDE 1	1	UR YAMAHA BLACK (033)
2	3HH-2173E-90-00	. GRAPHIC 1	1	UR FOR YB(033)
	3UU-2173E-00-00	. GRAPHIC 1	1	UR FOR DP BMC (564)
3	3LE-28315-40-00	. EMBLEM	1	
4	3HE-21735-00-00	. SEAL 2	1	
5	3HE-21732-00-00	. SEAL 1	2	
6	2GH-21735-00-00	. SEAL 2	1	
7	3HE-Y2172-10-P3	COVER, SIDE 2	1	UR DEEP PURPLISH-BLUE MET C (564)
	3HE-Y2172-70-33	COVER, SIDE 2	1	UR YAMAHA BLACK (033)
8	3HH-2173F-90-00	. GRAPHIC 2	1	UR FOR YAMAHA BLACK (033)
	3UU-2173F-00-00	. GRAPHIC 2	1	UR FOR DPBL METALLIC C (564)
9	3LE-28315-40-00	. EMBLEM	1	
10	3HE-21735-00-00	. SEAL 2	1	
11	3HE-21732-00-00	. SEAL 1	2	
12	2GH-21735-00-00	. SEAL 2	1	
13	90480-01401-00	GROMMET	4	
14	90480-14052-00	GROMMET	2	
15	1WG-2177G-00-00	BOX, BATTERY	1	
16	90480-22362-00	GROMMET	1	
17	90480-14229-00	GROMMET	2	
18	90387-07391-00	COLLAR	2	
19	31A-14477-00-00	PLATE	2	
20	90119-06097-00	BOLT, WITH WASHER	2	


CONTINUED ON NEXT FRAME ➤

SIDE COVER



Ref. No.	Part Number	Description	Qty	Remarks
21	7H3-82131-00-00	BAND, BATTERY	1	
22	1WG-21871-00-00	TANK, RECOVERY	1	
23	1AA-21815-00-00	CAP	1	
24	1AA-21874-00-00	GASKET	1	
25	3GM-21816-00-00	PIPE 1	1	
26	90159-06033-00	SCREW, WITH WASHER	2	
27	90159-06033-00	SCREW, WITH WASHER	2	
28	3HH-2179V-90-00	PLATE, EPA 1	1	UR NON-CA
	3UU-2179R-70-00	PLATE, EPA 2	1	UR CA ONLY
29	34X-21691-00-00	FLAP	1	

REAR ARM




3HHE110-5260

Ref. No.	Part Number	Description	Qty	Remarks
1	3HH-22110-00-T9	REAR ARM COMP.	1	COMPETITION SILVER (0T9)
2	33M-22184-00-00	BUSH	1	
3	93320-32403-00	BEARING	2	
4	4X7-22129-00-00	COVER, THRUST 2	2	
5	90201-161J3-00	WASHER, PLATE	2	
6	93317-21746-00	BEARING	2	
7	93109-17048-00	OIL SEAL (SDO 17-24-4)	2	
8	90387-122R5-00	COLLAR	1	
9	3HH-22151-00-00	SEAL, GUARD	1	
10	90387-06681-00	COLLAR	2	
11	90387-062M9-00	COLLAR	2	
12	97095-06016-00	BOLT	4	
13	3GM-22311-00-00	CASE, CHAIN	1	
14	90119-06108-00	BOLT, WITH WASHER	1	
15	46X-22141-00-00	SHAFT, PIVOT	1	
16	90185-14070-00	NUT, SELF-LOCKING	1	
17	1WG-2217A-00-00	ARM, RELAY	1	
18	93317-31701-00	BEARING	1	
19	93317-21746-00	BEARING	2	
20	93109-17048-00	OIL SEAL (SDO 17-24-4)	4	
21	90387-102R4-00	COLLAR	1	
22	90387-122R5-00	COLLAR	1	
23	93399-99919-00	BEARING	1	
24	93101-16131-00	OIL SEAL	2	
25	90387-124W2-00	COLLAR	2	
26	1WG-2217M-00-00	ARM 1	2	
27	90105-10376-00	BOLT, WASHER BASED	1	
28	90101-10658-00	BOLT	2	

CONTINUED ON NEXT FRAME ➤


REAR ARM



3HHE110-5260

Ref. No.	Part Number	Description	Qty	Remarks
29	90101-10659-00	BOLT	1	
30	90201-101J1-00	WASHER, PLATE	3	
31	95617-10100-00	BOLT, STUD	4	
32	90119-06117-00	BOLT, WITH WASHER	1	

REAR SUSPENSION




Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-22210-10-00	SHOCK ABSORBER ASSEMBLY, REAR	1	
2	90387-1210W-00	COLLAR	1	
3	90109-10554-00	BOLT	1	
4	90201-101J1-00	WASHER, PLATE	1	
5	95617-10100-00	BOLT, STUD	1	



3HE332-9250

STEERING




Ref. No.	Part Number	Description	Qty	Remarks
1	93332-00079-00	BEARING	1	
2	93332-00008-00	BEARING	1	
3	4DN-23416-20-00	COVER, BALL RACE 2	1	
4	90179-25033-00	NUT	2	
5	90202-26142-00	WASHER, PLATE	1	
6	26H-23418-01-00	WASHER, SPECIAL	1	
7	90176-22081-00	NUT, CROWN	1	
8	3HE-23435-00-00	CROWN, HANDLE	1	
9	91609-40210-00	. PIN, SPRING	2	
10	91317-08030-00	BOLT	2	
11	3HE-2317E-00-00	STAY	1	
12	90201-220T0-00	WASHER, PLATE	1	

FWD

3HHH100-7270

FRONT FORK




3HHE110-5290

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-23102-11-00	FRONT FORK ASSEMBLY (L.H)	1	
2	3HE-23126-10-00	. TUBE, OUTER (LEFT)	1	
3	3R4-23153-00-00	. RING, SNAP	1	
4	3EN-23145-00-00	. OIL SEAL	1	
5	2YK-23125-00-00	. METAL, SLIDE 1	1	
6	3EN-23144-01-00	. SEAL, DUST	1	
7	4V2-23146-L0-00	. WASHER, OIL SEAL	1	
8	3HE-23110-01-00	. INNER TUBE COMP 1	1	
9	3HE-23170-00-00	. CYLINDER COMP., FRONT FORK	1	
10	2YK-23173-00-00	. SPINDLE, TAPER	1	
11	3HE-23141-00-00	. SPRING, FRONT FORK	1	
12	509-23158-L0-00	. GASKET	1	
13	3EN-23111-00-00	. BOLT, CAP	1	
14	4DN-23149-40-00	. WASHER, SPRING UPPER	1	
15	1W4-23114-L0-00	. GASKET	1	
16	278-23181-50-00	. BOLT, HEXAGON SOCKET HEAD	1	
17	1WG-23118-00-00	. SPACER	1	
18	3HE-23103-11-00	FRONT FORK ASSEMBLY (R.H)	1	
19	3HE-23136-10-00	. TUBE, OUTER (RIGHT)	1	
20	3R4-23153-00-00	. RING, SNAP	1	
21	3EN-23145-00-00	. OIL SEAL	1	
22	2YK-23125-00-00	. METAL, SLIDE 1	1	
23	3EN-23144-01-00	. SEAL, DUST	1	
24	4V2-23146-L0-00	. WASHER, OIL SEAL	1	
25	3HE-23110-01-00	. INNER TUBE COMP 1	1	
26	3HE-23170-00-00	. CYLINDER COMP., FRONT FORK	1	
27	2YK-23173-00-00	. SPINDLE, TAPER	1	

CONTINUED ON NEXT FRAME ➤


FRONT FORK



3HHE110-5290

Ref. No.	Part Number	Description	Qty	Remarks
28	3HE-23141-00-00	. SPRING, FRONT FORK	1	
29	509-23158-L0-00	. GASKET	1	
30	3EN-23111-00-00	. BOLT, CAP	1	
31	4DN-23149-40-00	. WASHER, SPRING UPPER ..	1	
32	1W4-23114-L0-00	. GASKET	1	
33	278-23181-50-00	. BOLT, HEXAGON SOCKET HEAD	1	
34	1WG-23128-00-00	. BOLT, AXLE HOLDER	1	
35	1WG-23118-00-00	. SPACER	1	
36	1WG-23340-00-00	UNDER BRACKET COMP.	1	
37	2NX-23356-00-00	BOLT 2	2	

FUEL TANK




3HHH100-7290

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-24110-00-00	FUEL TANK COMP.	1	UR CA ONLY
	3HE-24110-10-00	FUEL TANK COMP.	1	UR NON CA
2	1HX-24181-00-00	DAMPER, LOCATING 1	2	
3	90387-06380-00	COLLAR	1	
4	95807-06080-00	BOLT, FLANGE	1	
5	3EN-21346-00-00	BRACKET, TANK FITTING	2	
6	95807-06016-00	BOLT, FLANGE	4	
7	1WG-21345-00-00	BRACKET, TANK FITTING	1	
8	90179-08410-00	NUT	2	
9	1HX-24182-00-00	DAMPER, LOCATING 2	2	
10	90464-13080-00	CLAMP	2	
11	1WG-21348-00-00	BRACKT, TANK FITTING	1	
12	95807-06016-00	BOLT, FLANGE	2	
13	1WG-24185-00-00	DAMPER, LOCATING 5	1	
14	1WG-24602-00-00	CAP ASSEMBLY	1	UR NON CA
	3FH-24602-00-00	CAP ASSEMBLY	1	UR CA ONLY
15	3HE-24500-00-00	FUEL COCK ASSEMBLY 1 . . .	1	
16	4X8-24512-00-00	. O-RING	1	
17	3AJ-24534-00-00	. SEAL, COCK	1	
18	98580-03008-00	. SCREW, PAN HEAD (98501-03008-00)	2	
19	3HE-24524-00-00	LEVER, COCK	1	
20	98707-04018-00	SCREW, FLAT HEAD	1	
21	90202-05187-00	WASHER, PLATE	2	
22	90149-06011-00	SCREW	2	
23	1FK-24560-01-00	FILTER ASSEMBLY	1	
24	26H-24568-00-00	BAND, FILTER	1	
25	1WG-24566-00-00	BRACKET, FILTER	1	
26	1WG-24398-01-00	BAND 1	1	

CONTINUED ON NEXT FRAME ➤

FUEL TANK




3HHH100-7290

Ref. No.	Part Number	Description	Qty	Remarks
27	3HE-24491-00-00	BRACKET, FUEL PUMP	1	
28	98907-05014-00	SCREW, BIND	3	
29	90480-14229-00	GROMMET	1	
30	90387-07391-00	COLLAR	1	
31	95707-06500-00	NUT, FLANGE	1	
32	90480-11454-00	GROMMET	1	
33	1WG-24311-00-00	PIPE, FUEL 1	1	
34	90445-137F4-00	HOSE	1	
35	90467-10135-00	CLIP	1	
36	90467-11044-00	CLIP	3	
37	3HE-Y217F-10-P1	COVER, TOP (FUEL TANK)	1	UR DEEP PURPLISH BLUE MET.C (564)
	3HE-Y217F-80-33	COVER, TOP (FUEL TANK)	1	UR YAMAHA BLACK (033)
38	99221-00160-00	. EMBLEM, YAMAHA	2	UR FOR DEEP PURPLISH BLUE MET C (564)
	99221-00180-00	. EMBLEM, YAMAHA	2	UR FOR YAMAHA BLACK (033)
39	3UU-24240-00-00	. GRAPHIC SET	1	FOR DEEP PURPLISH BLUE MET C (564)
40	90480-18495-00	. GROMMET	2	
41	3HE-24614-00-00	. PLATE, CAP	1	
42	90110-06134-00	. BOLT, HEXAGON SOCKET HEAD	3	
43	1WG-24665-00-00	. DAMPER	3	
44	90110-06133-00	. BOLT, HEXAGON SOCKET HEAD	3	
45	90201-065F3-00	. WASHER, PLATE	3	
46	95317-06600-00	. NUT	3	
47	3EN-13907-00-00	FUEL PUMP COMP.	1	

CONTINUED ON NEXT FRAME ➤


FUEL TANK



3HHH100-7290

Ref. No.	Part Number	Description	Qty	Remarks
48	90445-146F9-00	HOSE	1	
49	90467-13123-00	CLIP	2	
50	1WG-24183-00-00	DAMPER, LOCATING 3	2	
51	90154-06040-00	SCREW, BINDING	2	
52	4X7-21719-00-00	GROMMET	2	
53	90387-112R6-00	COLLAR	2	
54	90201-06697-00	WASHER, PLATE	2	
55	98517-06025-00	SCREW, PAN HEAD	2	
56	90110-06170-00	BOLT, HEXAGON SOCKET HEAD	2	
57	1WG-2414A-00-00	COVER, FILLER	1	
58	1WG-24622-00-00	WASHER, RING	2	
59	90560-03220-00	SPACER	1	
60	90445-070F1-00	HOSE	1	


FUEL TANK 2 (CALIFORNIA ONLY)



3HHG110-6300

Ref. No.	Part Number	Description	Qty	Remarks
1	25H-24180-00-00	ROLL OVER VALVE ASSY	1	
2	90461-15100-00	CLAMP	1	
3	98507-05010-00	SCREW, PAN HEAD	1	
4	92907-05600-00	WASHER, PLATE	1	
5	3FH-24313-00-00	PIPE 3	1	
6	90445-11706-00	HOSE	1	
7	90445-11501-00	HOSE	1	
8	90467-10008-00	CLIP	6	
9	42H-24119-00-00	TUBE, CONNECTING	1	
10	3FH-24170-00-00	CANISTER ASSEMBLY	1	
11	2JU-2419E-00-00	COVER, CANISTER	1	
12	3FH-24190-00-00	CANISTER HOLDER ASSEMBLY	1	
13	98507-05016-00	SCREW, PAN HEAD	2	
14	92907-05600-00	WASHER, PLATE	2	
15	97007-06020-00	BOLT	2	
16	90201-065F3-00	WASHER, PLATE	2	
17	90480-15058-00	GROMMET	2	
18	90387-060A7-00	COLLAR	2	
19	3HW-24312-00-00	PIPE 2	1	
20	90445-11611-00	HOSE	1	
21	3H3-24376-00-00	PIPE, JOINT 1	1	
22	90467-10008-00	CLIP	6	
23	90445-11732-00	HOSE	1	


SEAT



3HH110-2280

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-24710-00-00	SINGLE SEAT ASSEMBLY ...	1	
2	3HE-24711-00-00	. COVER, SINGLE SEAT	1	
3	1T4-24741-00-00	. PAD, SEAT	1	
4	116-24741-00-00	. PAD, SEAT	1	
5	22W-24741-00-00	. PAD, SEAT	4	
6	3HE-24742-00-00	. GROMMET	1	
7	3HE-24750-00-00	TANDEM SEAT ASSEMBLY ...	1	
8	4K0-24748-00-00	. BRACKET, SEAT	2	
9	3HE-24796-00-00	. COVER	1	
10	90164-05026-00	. SCREW, TAPPING	2	
11	3HE-24734-00-00	. BAND, SEAT	1	
12	95817-06016-00	. BOLT, FLANGE	2	
13	4L0-24712-11-00	. PLATE	2	
14	90468-10050-00	. CLIP	2	
15	47X-24739-00-00	. BOLT, SEAT FITTING	2	
16	3HE-24705-02-00	SEAT LOCK ASSEMBLY (3HH-24705-01-00)	1	
17	95817-06030-00	BOLT, FLANGE	2	
18	26H-21308-00-00	HELMET HANGER ASSEMBLY	1	
19	90149-06150-00	SCREW	1	


FRONT WHEEL



3HE332-9300

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-25168-00-35	CAST WHEEL, FRONT	1	UR SILVER FOR DPBMC
	3HE-25168-00-P1	CAST WHEEL, FRONT	1	UR LIGHT REDDISH YELLOW SOLID1 (586) FOR YB (033)
2	90560-15314-00	SPACER	1	
3	93306-30202-00	BEARING	2	
4	93102-22014-00	OIL SEAL	1	
5	341-25149-00-00	CLUTCH, METER	1	
6	341-25846-00-00	RETAINER, CLUTCH	1	
7	93105-45017-00	OIL SEAL	1	
8	94111-175X5-00	TIRE (MCS110/70 VR17 V240) .	1	UR 1BRIDGESTONE
9	93900-00030-00	VALVE, RIM	1	
10	29L-25398-00-00	BALANCER, WHEEL (10G) ...	1	UR
	29L-25398-10-00	BALANCER, WHEEL (20G) ...	1	UR
	29L-25398-20-00	BALANCER, WHEEL (30G) ...	1	UR
11	4X8-25190-01-00	GEAR UNIT ASSEMBLY	1	
12	42X-25181-00-00	AXLE, WHEEL	1	
13	90387-15550-00	COLLAR	1	


FRONT BRAKE CALIPER



3HE351-1300

Ref. No.	Part Number	Description	Qty	Remarks
1	4HM-2581T-00-00	DISC BRAKE ASSEMBLY	2	
2	90109-08718-00	BOLT	12	
3	3HE-2580T-60-00	CALIPER ASSEMBLY (LEFT) ..	1	
4	3HE-W0057-50-00	. PISTON ASSEMBLY, CALIPER	2	
5	3HE-W0047-50-00	. . CALIPER SEAL KIT	2	
6	3GM-W0045-02-00	. BRAKE PAD KIT	1	
7	3GM-25919-00-00	. SUPPORT, PAD	1	
8	3HE-25924-00-00	. PIN, PAD	2	
9	3GM-25925-00-00	. CLIP	2	
10	1J3-W0048-00-00	. BLEED SCREW KIT	1	
11	1KT-25836-00-00	. COVER, DUST	1	
12	3HE-2580U-60-00	CALIPER ASSEMBLY (RIGHT) .	1	
13	3HE-W0057-50-00	. PISTON ASSEMBLY, CALIPER	2	
14	3HE-W0047-50-00	. . CALIPER SEAL KIT	2	
15	3GM-W0045-02-00	. BRAKE PAD KIT	1	
16	3GM-25919-00-00	. SUPPORT, PAD	1	
17	3HE-25924-00-00	. PIN, PAD	2	
18	3GM-25925-00-00	. CLIP	2	
19	1J3-W0048-00-00	. BLEED SCREW KIT	1	
20	1KT-25836-00-00	. COVER, DUST	1	
21	90105-10638-00	BOLT, WASHER BASED	4	

REAR WHEEL




3HE351-1310

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-25338-50-35	CAST WHEEL, REAR	1	UR SILVER FOR DBPM (564)
	3HE-25338-50-P1	CAST WHEEL, REAR	1	UR LIGHT REDDISH YELLOW SOLID 1(386) FOR Y B (033)
2	93306-30317-00	BEARING	1	
3	93306-20314-00	BEARING (B6203)	2	
4	93102-25044-00	OIL SEAL	1	
5	90387-174V8-00	COLLAR	1	
6	1UF-25364-00-00	DAMPER	3	
7	94114-185X6-00	TIRE (MCS 140/60 VR18 V240)	1	UR 1BRIDGESTONE
8	93900-00030-00	VALVE, RIM	1	
9	29L-25398-00-00	BALANCER, WHEEL (10G)	1	UR
	29L-25398-10-00	BALANCER, WHEEL (20G)	1	UR
	29L-25398-20-00	BALANCER, WHEEL (30G)	1	UR
10	1UF-25366-00-00	CLUTCH, HUB	1	
11	93306-37207-00	BEARING	1	
12	93105-42024-00	OIL SEAL	1	
13	1AE-25445-21-00	SPROCKET, DRIVEN (45T)	1	
14	90116-10485-00	BOLT, STUD	6	
15	95617-10200-00	BOLT, STUD	6	
16	90387-177K0-00	COLLAR	1	
17	94581-59106-00	CHAIN	1	
18	3HH-25388-00-00	PULLER, CHAIN 1	2	
19	95337-08600-00	NUT	4	
20	3HH-22174-00-00	END 1	2	
21	92907-08600-00	WASHER, PLATE	2	
22	3HE-25371-51-00	BAR, TENSION	1	
23	90105-08321-00	BOLT, WASHER BASED	2	
24	95707-08500-00	NUT, FLANGE	2	

CONTINUED ON NEXT FRAME ➤


REAR WHEEL



3HE351-1310

Ref. No.	Part Number	Description	Qty	Remarks
25	91490-20015-00	PIN, COTTER	2	
26	3HE-25381-01-00	AXLE, WHEEL	1	
27	90201-170T3-00	WASHER, PLATE	2	
28	90387-177Y5-00	COLLAR	1	
29	90387-173L5-00	COLLAR	1	
30	90171-16024-00	NUT, CASTLE	1	
31	91490-30030-00	PIN, COTTER	1	


REAR BRAKE CALIPER



3HE351-0330


Ref. No.	Part Number	Description	Qty	Remarks
1	2NX-2582W-00-00	DISC, REAR BRAKE 2	1	
2	90109-08718-00	BOLT	6	
3	3HE-2580W-10-00	CALIPER ASSEMBLY, REAR 2	1	
4	31A-W0057-00-00	. PISTON ASSY, CALIPER	1	
5	31A-W0047-00-00	. . CALIPER SEAL KIT	1	
6	1FK-W0046-02-00	. BRAKE PAD KIT 2	1	
7	29L-25919-A0-00	. SUPPORT, PAD	1	
8	3HE-25924-00-00	. PIN, PAD	2	
9	3GM-25925-00-00	. CLIP	2	
10	1J3-W0048-00-00	. BLEED SCREW KIT	2	
11	51J-25836-00-00	. COVER, DUST	1	
12	1FK-25827-00-00	. SHIM, CALIPER	1	
13	1FK-25828-00-00	. SHIM, CALIPER	1	
14	3HE-25819-01-00	BRACKET, CALIPER	1	
15	90105-10638-00	BOLT, WASHER BASED	2	

STEERING HANDLE - CABLE



Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-26121-00-00	BOSS, HANDLE (LEFT)	1	
2	3HE-26122-00-00	BOSS, HANDLE (RIGHT)	1	
3	91317-06020-00	BOLT	4	
4	3HE-26111-00-00	HANDLEBAR	1	
5	91317-08025-00	BOLT	2	
6	341-23469-00-00	CAP, BOLT	2	
7	51J-26246-01-00	END, GRIP	2	
8	1KG-26241-00-00	GRIP (LEFT)	1	
9	3FH-26240-00-00	GRIP ASSEMBLY	1	
10	3EN-26311-00-00	CABLE, THROTTLE 1	1	
11	3HE-26312-00-00	CABLE, THROTTLE 2	1	
12	5H0-26393-00-00	HOLDER	1	
13	98507-05008-00	SCREW, PAN HEAD	1	
14	3HE-26335-01-00	CABLE, CLUTCH	1	
15	90179-08148-00	NUT	1	
16	90123-08046-00	BOLT	1	
17	3EN-26331-00-00	CABLE, STARTER 1	1	
18	3HE-83940-00-00	STARTER ASSEMBLY	1	
19	1WG-83941-00-00	. LEVER, STARTER	1	
20	3HE-28357-00-00	. STAY 2	1	
21	1WG-83942-00-00	. COVER, STARTER	1	
22	98907-03006-00	. SCREW, BIND	2	
23	90209-10131-00	. WASHER	1	
24	98907-06008-00	. SCREW, BIND	1	
25	95817-06020-00	SCREW, PAN HEAD	1	
26	3HE-26111-00-00	HANDLEBAR	1	


FRONT MASTER CYLINDER



3HHE110-5380

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-2583T-00-00	MASTER CYLINDER ASSEMBLY	1	
2	3HE-25852-00-00	. CAP, RESERVOIR	1	
3	98707-04012-00	. SCREW, FLAT HEAD	2	
4	36Y-25854-00-00	. DIAPHRAGM, RESERVOIR	1	
5	36Y-W0041-00-00	. CYLINDER KIT, MASTER	1	
6	36Y-25867-00-00	BRACKET, MASTER CYLINDER	1	
7	91317-06025-00	BOLT	2	
8	92907-06100-00	WASHER, SPRING	2	
9	3HE-25872-02-00	HOSE, BRAKE 1	1	
10	3HE-25873-12-00	HOSE, BRAKE 2	2	
11	11U-25885-00-00	JOINT	1	
12	91317-06025-00	BOLT	2	
13	90401-10160-00	BOLT, UNION	1	
14	90401-10159-00	BOLT, UNION	4	
15	90201-10118-00	WASHER, PLATE	11	
16	90338-09012-00	PLUG	1	

STAND - FOOTREST




3HE332-9360

Ref. No.	Part Number	Description	Qty	Remarks
1	4BP-27311-00-00	STAND, SIDE	1	
2	90109-10474-00	BOLT	1	
3	90185-10037-00	NUT, SELF-LOCKING	1	
4	90506-18224-00	SPRING, TENSION	1	
5	90506-26225-00	SPRING, TENSION	1	
6	1TX-27351-00-00	GUIDE, SIDE STAND	1	
7	2KT-27315-00-00	LINK, SIDE STAND	1	
8	3HE-27410-00-00	FRONT FOOTREST ASSEMBLY (LEFT)	1	
9	2GH-27413-00-00	. COVER, FOOTREST	1	
10	90157-05079-00	. SCREW, PAN HEAD	2	
11	3HE-27435-00-00	. BOLT	1	
12	3HE-27420-00-00	FRONT FOOTREST ASSEMBLY (RIGHT)	1	
13	2GH-27413-00-00	. COVER, FOOTREST	1	
14	90157-05079-00	. SCREW, PAN HEAD	2	
15	3HE-27435-00-00	. BOLT	1	
16	3HE-27442-00-00	BRACKET 2	1	
17	3HE-27443-00-00	BRACKET 3	1	
18	3VR-27431-01-00	FOOTREST, REAR 1	1	
19	3VR-27441-01-00	FOOTREST, REAR 2	1	
20	90501-12743-00	SPRING, COMPRESSION	2	
21	93501-04011-00	BALL	2	
22	1HX-27437-00-00	WASHER, SPECIAL	2	
23	91701-06035-00	PIN, CLEVIS	2	
24	91490-20015-00	PIN, COTTER	2	
25	90387-064H8-00	COLLAR	2	
26	3HE-2741L-00-00	BRACKET 4	1	
27	3HE-2742L-01-00	BRACKET 5	1	

CONTINUED ON NEXT FRAME ➤


STAND - FOOTREST



3HE332-9360


Ref. No.	Part Number	Description	Qty	Remarks
28	95817-08025-00	BOLT, FLANGE	4	
29	3HE-27445-01-00	PLATE 1	1	
30	3HE-27446-01-00	PLATE 2	1	
31	95024-06016-00	BOLT, FLANGE	4	
32	90109-103A9-00	BOLT	2	
33	90206-17084-00	WASHER, WAVE	2	
34	95024-08025-00	BOLT, FLANGE	4	

REAR MASTER CYLINDER



3HE351-0370


Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-27211-00-00	PEDAL, BRAKE	1	
2	22N-18113-00-00	COVER, SHIFT PEDAL	1	
3	90506-20377-00	SPRING, TENSION	1	
4	90446-17267-00	HOSE	1	
5	1WG-25850-50-00	MASTER CYLINDER ASSEMBLY	1	
6	1WG-W0042-50-00	. CYLINDER KIT, MASTER	1	
7	29L-2582A-50-00	. JOINT	1	
8	93210-15620-00	. O-RING	1	
9	98517-04012-00	. SCREW, PAN HEAD	1	
10	92990-04100-00	. WASHER, SPRING	1	
11	92990-04600-00	. WASHER, PLATE	1	
12	92017-08025-00	BOLT, BUTTON HEAD	2	
13	31A-27222-00-00	JOINT	1	
14	95317-08700-00	NUT	1	
15	90240-08013-00	PIN, CLEVIS	1	
16	90201-08083-00	WASHER, PLATE	1	
17	91490-20015-00	PIN, COTTER	1	
18	31A-25894-01-00	TANK, RESERVOIR	1	
19	360-25854-00-00	DIAPHRAGM, RESERVOIR	1	
20	2GU-25855-00-00	BUSH, DIAPHRAGM	1	
21	2KF-25852-50-00	CAP, RESERVOIR	1	
22	90159-06056-00	SCREW, WITH WASHER	1	
23	31A-14477-00-00	PLATE	1	
24	1WG-25895-00-00	HOSE, RESERVOIR	1	
25	90467-14057-00	CLIP	2	
26	3HE-25872-61-00	HOSE, BRAKE 1	1	
27	90401-10159-00	BOLT, UNION	2	
28	90201-10118-00	WASHER, PLATE	4	



COWLING 1

Ref. No.	Part Number	Description	Qty	Remarks
1	3HH-28381-10-00	WINDSHIELD	1	
2	90150-05020-00	SCREW, ROUND HEAD	6	
3	95707-05500-00	NUT, FLANGE	6	
4	36Y-28348-00-00	MOLE 4	1	
5	3HE-2835G-00-33	BODY, FRONT UPPER 1	1	UR YAMAHA BLACK (033)
	3HE-2835G-00-P3	BODY, FRONT UPPER 1	1	UR DPBMC (564)
6	3EN-2835U-20-00	PANEL 1	1	
7	3EN-2835V-20-00	PANEL 2	1	
8	99231-00080-00	EMBLEM, YAMAHA	1	
9	3HE-21596-00-00	HOLDER	1	
10	3HE-28356-30-00	STAY 1	1	
11	90480-14229-00	GROMMET	4	
12	90179-06500-00	NUT	4	
13	90105-08748-00	BOLT, WASHER BASED	2	
14	90110-05201-00	BOLT, HEXAGON SOCKET HEAD	2	
15	90149-05299-00	SCREW	2	
16	90202-05180-00	WASHER, PLATE	4	
17	90183-05024-00	NUT, SPRING	4	
18	3HE-26280-10-00	REAR VIEW MIRROR ASSEMBLY (LEFT)	1	BLACK
19	3HE-26290-10-00	REAR VIEW MIRROR ASSEMBLY (RIGHT)	1	BLACK
20	1AE-26298-00-00	PLATE, MIRROR FITTING 1	2	
21	3CV-26298-00-00	PLATE, MIRROR FITTING 1	2	
22	90176-06055-00	NUT, CROWN	4	
23	98707-06025-00	SCREW, FLAT HEAD	4	
24	97707-50014-00	SCREW, TAPPING	6	
25	3EN-Y283J-41-P2	BODY, FRONT LOWER 1	1	UR DEEP PU PURPLISH BLUE MET C (564)


CONTINUED ON NEXT FRAME ➤



COWLING 1

Ref. No.	Part Number	Description	Qty	Remarks
25	3EN-Y283J-81-33	BODY, FRONT LOWER 1	1	UR YAMAHA BLACK (033)
26	3HH-28301-C0-00	. GRAPHIC SET, LOWER COVER 1	1	UR FOR YB 1(033)
	3UU-28301-00-00	. GRAPHIC SET, LOWER COVER 1	1	UR FOR 1DPBM (564)
27	99231-00240-00	. EMBLEM, YAMAHA	1	FOR DPBMC (564)
28	90480-13398-00	. GROMMET	4	
29	90387-067K6-00	. COLLAR	4	
30	3HE-2848K-00-00	. SEAT 2	1	
31	3EN-Y283K-40-P2	BODY, FRONT LOWER 2	1	UR DEEP PURPLISH BLUE MET C (564)
	3EN-Y283K-90-33	BODY, FRONT LOWER 2	1	UR YAMAHA BLACK (033)
32	3HH-28303-C0-00	. GRAPHIC SET, LOWER COVER 2	1	UR FOR YB 1(033)
	3UU-28303-00-00	. GRAPHIC SET, LOWER COVER 2	1	UR FOR DPB MET C (564)
33	99231-00280-00	. EMBLEM, YAMAHA	1	FOR DPBMC (564)
34	90480-13398-00	. GROMMET	4	
35	90387-067K6-00	. COLLAR	4	
36	3HE-2848L-00-00	. SEAT 3	1	
37	90110-06200-00	BOLT, HEXAGON SOCKET HEAD	8	
38	90149-05299-00	SCREW	2	
39	90202-05180-00	WASHER, PLATE	2	
40	90179-05523-00	NUT	2	
41	3HE-2831U-00-00	STAY, SIDE 1	2	
42	95817-06012-00	BOLT, FLANGE	2	
43	1WG-2836A-00-00	BRACKET 1	2	


CONTINUED ON NEXT FRAME ➤



COWLING 1

Ref. No.	Part Number	Description	Qty	Remarks
44	3EN-2836A-01-00	BRACKET 1	1	
45	1WG-2836E-00-00	BRACKET 2	1	
46	95817-06010-00	BOLT, FLANGE	4	
47	3EN-2838N-00-00	DUCT 1	1	
48	3EN-2838R-00-00	DUCT 2	1	
49	3EN-2838T-00-00	DUCT 3	1	
50	3EN-2838U-00-00	DUCT 4	1	
51	3HE-2838J-01-00	DUCT 5	2	
52	90460-49058-00	CLAMP, HOSE	4	
53	90154-06046-00	SCREW, BINDING	4	
54	3HE-2831W-00-00	STAY, MIRROR 1	1	
55	91317-06016-00	BOLT	2	
56	3EN-28313-00-00	LID	1	
57	3JJ-2835Y-00-00	LABEL, CAUTION	1	
58	3HF-2848M-00-00	SEAT 4	1	CA ONLY
59	3HF-2848N-00-00	SEAT 5	1	CA ONLY


GENERATOR



3HHG110-6410


Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-81450-00-00	ROTOR ASSEMBLY	1	
2	3HE-81410-01-00	STATOR ASSEMBLY	1	
3	90110-06237-00	BOLT	3	
4	98507-05016-00	SCREW, PAN HEAD	2	
5	92907-05600-00	WASHER, PLATE	2	
6	90280-03047-00	KEY, WOODRUFF	1	
7	90105-10430-00	BOLT, WASHER BASED	1	
8	90201-107K6-00	WASHER, PLATE	1	

STARTING MOTOR



3HE332-9400

Ref. No.	Part Number	Description	Qty	Remarks
1	3HW-81800-00-00	STARTING MOTOR ASSEMBLY	1	
2	3HE-81840-00-00	. BRUSH HOLDER ASSEMBLY	1	
3	1HX-81815-00-00	. CORD, STARTER MOTOR . . .	1	
4	3HE-81850-00-00	. ARMATURE ASSEMBLY	1	
5	3AJ-81809-00-00	. WASHER KIT	1	
6	3HE-81830-00-00	. FRONT BRACKET ASSEMBLY	1	
7	3HE-81826-00-00	. BOLT	1	
8	5H0-81871-00-00	. CAP	1	
9	11H-81844-00-00	. GASKET	2	
10	26H-81847-00-00	. O-RING	1	
11	95027-06025-00	BOLT, FLANGE	2	




3HH110-9400

FLASHER LIGHT

Ref. No.	Part Number	Description	Qty	Remarks
1	1UF-83310-00-00	FRONT FLASHER LIGHT ASSEMBLY 1	1	
2	51L-83332-01-00	. LENS, FLASHER	1	
3	256-84714-61-00	. BULB (12V-27/8W)	1	
4	97707-40620-00	. SCREW, TAPPING	1	
5	1UF-83320-00-00	FRONT FLASHER LIGHT ASSEMBLY 2	1	
6	51L-83342-01-00	. LENS, FLASHER 2	1	
7	256-84714-61-00	. BULB (12V-27/8W)	1	
8	97707-40620-00	. SCREW, TAPPING	1	
9	1UF-83330-00-00	REAR FLASHER LIGHT ASSEMBLY 1	1	
10	51L-83342-01-00	. LENS, FLASHER 2	1	
11	256-83311-70-XX	. BULB (12V-27W)	1	
12	97707-40620-00	. SCREW, TAPPING	1	
13	1UF-83340-00-00	FLASHER LIGHT ASSEMBLY 2	1	
14	51L-83332-01-00	. LENS, FLASHER	1	
15	256-83311-70-XX	. BULB (12V-27W)	1	
16	97707-40620-00	. SCREW, TAPPING	1	
17	95707-12500-00	NUT, FLANGE	4	
18	18G-83365-00-00	CAP	4	
19	2MA-28365-41-00	COVER	2	BLACK
20	90183-04045-00	NUT, SPRING	4	
21	90480-35526-00	GROMMET	2	


METER



Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-83570-60-00	SPEEDOMETER ASSEMBLY ..	1	
2	3GM-83540-00-00	TACHOMETER ASSEMBLY ...	1	
3	3EN-83590-50-00	WATER TEMPERATURE ASSEMBLY	1	
4	3VD-83559-00-00	COVER, METER (3GM-83559-00-00)	1	
5	3LE-8353H-00-00	CASE, UNDER (3GM-8353H-00-00)	1	
6	2GH-83578-00-00	KNOB, TRIP METER	1	
7	3HE-83509-50-00	SOCKET CORD ASSEMBLY ..	1	
8	4G1-84744-00-XX	BULB (12V-3.4W T-10)	4	
9	3GM-83517-00-00	BULB (12V-1.7W)	3	
10	3FV-83517-00-00	BULB (12V-1.7W, T6.5)	1	
11	98507-04010-00	SCREW, PAN HEAD	4	
12	92907-04100-00	WASHER, SPRING	4	
13	92907-04600-00	WASHER	4	
14	90167-04057-00	SCREW, TAPPING	2	
15	98507-03010-00	SCREW, PAN HEAD	3	
16	92990-03100-00	WASHER, SPRING	3	
17	90159-03102-00	SCREW, WITH WASHER	3	
18	90164-04008-00	SCREW, TAPPING	4	
19	90167-03058-00	SCREW, TAPPING	1	
20	4FM-83520-00-00	SOCKET CORD ASSEMBLY ..	1	
21	3GM-83513-00-00	DAMPER	1	
22	3GM-83525-00-00	CLIP	3	
23	98507-03012-00	SCREW, PAN HEAD	1	
24	92990-03100-00	WASHER, SPRING	1	
25	90480-14229-00	GROMMET	2	
26	90387-07391-00	COLLAR	2	
27	95317-06600-00	NUT	2	


CONTINUED ON NEXT FRAME ➤

METER



Ref. No.	Part Number	Description	Qty	Remarks
28	90201-065F3-00	WASHER, PLATE	2	
29	1RH-83550-01-00	SPEEDOMETER CABLE ASSEMBLY	1	


HEADLIGHT



3HHH100-7450

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-84330-00-00	BODY ASSEMBLY	1	
2	2AX-84320-A0-00	LENS ASSEMBLY	1	
3	2AX-8432A-A0-00	LENS ASSEMBLY	1	
4	1ML-84314-00-XX	WIRE, STARTER (D:5MM, 1.7M)	2	HALOGEN
5	2F9-84375-00-00	SETTING PLATE, BULB	2	
6	3MA-8430M-00-00	GEAR UNIT ASSEMBLY	2	
7	97707-40616-00	SCREW, TAPPING	4	
8	2AX-84331-00-00	SCREW, RIM ADJUSTING	2	
9	3AJ-8431U-00-00	HOLDER	2	
10	51L-84334-00-00	NUT, ADJUSTING	4	
11	3HE-84366-00-00	DAMPER, HEADLIGHT 1	1	
12	46X-84397-01-00	COVER, SOCKET	2	
13	3HH-84359-30-00	CORD, HEADLIGHT	1	
14	2F9-84397-01-00	COVER, SOCKET	2	
15	90464-12089-00	CLAMP	2	


TAILLIGHT




3HH110-9430

Ref. No.	Part Number	Description	Qty	Remarks
1	52X-84710-60-00	TAILLIGHT UNIT ASSEMBLY ..	1	
2	47X-84721-00-00	. LENS, TAILLIGHT	1	
3	47X-84723-00-00	. GASKET, TAIL LENS	1	
4	47X-84735-00-00	. CORD ASSEMBLY	1	
5	256-84714-61-00	. BULB (12V-27/8W)	2	
6	90480-18407-00	GROMMET	3	
7	90201-063J2-00	WASHER, PLATE	4	
8	90387-060N3-00	COLLAR	2	
9	95317-06600-00	NUT	2	
10	92907-10200-00	WASHER, PLAIN	1	
11	2LJ-84751-00-90	BRACKET, LICENSE	1	
12	90387-061M0-00	COLLAR	2	
13	95617-06100-00	NUT, U	2	
14	3G1-85130-01-00	REAR REFLECTOR ASSEMBLY	1	
15	95707-05500-00	NUT, FLANGE	1	

HANDLE SWITCH - LEVER






FWD

3HH110-9440

Ref. No.	Part Number	Description	Qty	Remarks
1	3HH-83975-00-00	SWITCH, HANDLE 2	1	
2	98507-05040-00	. SCREW, PAN HEAD	1	
3	98507-05045-00	. SCREW, PAN HEAD	1	
4	3HH-83973-00-00	SWITCH, HANDLE 3	1	
5	98507-05035-00	. SCREW, PAN HEAD	2	
6	29L-82911-01-00	HOLDER, LEVER 1	1	
7	3HE-83912-00-00	LEVER 1	1	
8	31A-83913-00-00	COLLAR, LEVER 1	1	
9	31A-82917-00-00	SWITCH	1	
10	31A-83945-00-00	BOLT, LEVER	1	
11	98707-03008-00	SCREW, FLAT HEAD	1	
12	95617-06100-00	NUT, U	1	
13	97007-06025-00	BOLT	1	
14	92907-06100-00	WASHER, SPRING	1	
15	1FK-83922-00-00	LEVER 2	1	
16	90110-06074-00	BOLT, HEXAGON SOCKET HEAD	1	
17	95617-06100-00	NUT, U	1	
18	36Y-83913-01-00	COLLAR, LEVER 1	1	
19	90501-10312-00	SPRING, COMPRESSION	1	
20	90149-06131-00	SCREW	1	
21	90170-06010-00	NUT	1	
22	J45-82503-01-00	SWITCH, ALARM	1	
23	98507-04016-00	SCREW, PAN HEAD	1	
24	92907-04600-00	WASHER	1	
25	90338-09012-00	PLUG	1	



3HHE110-5490


ELECTRICAL 1

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-82310-01-00	IGNITION COIL ASSEMBLY . . .	1	
2	3HE-82320-00-00	IGNITION COIL ASSEMBLY . . .	1	
3	97007-06065-00	BOLT	2	
4	92907-06600-00	WASHER, PLATE	2	
5	95317-06600-00	NUT	2	
6	1WG-82370-00-00	PLUG CAP ASSEMBLY	4	
7	3HE-82305-00-00	IGNITOR UNIT ASSEMBLY . . .	1	UR NON CA
	3UU-82305-10-00	IGNITOR UNIT ASSEMBLY . . .	1	UR CA ONLY
8	97707-60520-00	SCREW, TAPPING	2	
9	36Y-81940-00-00	STARTER RELAY ASSEMBLY .	1	
10	95707-06500-00	NUT, FLANGE	2	
11	BTG-GM12A-Z3-A2	BATTERY ASSEMBLY (GM12AZ-3A-2) (2GV-82110-G0-00)	1	
12	1WG-82115-00-00	WIRE, PLUS LEAD	1	
13	3HE-82116-00-00	WIRE, MINUS LEAD	1	
14	90445-08719-00	HOSE	1	
15	1KT-82530-03-00	STOP SWITCH ASSEMBLY . . .	1	
16	3HH-82590-11-00	WIRE HARNESS ASSEMBLY . .	1	UR NON CA
	3UU-82590-01-00	WIRE HARNESS ASSEMBLY . .	1	UR CA ONLY
17	2GH-82151-00-00	. FUSE (20A-BL)	2	
18	42X-82151-00-00	. FUSE (10A-BL)	4	
19	1AE-82151-00-00	. FUSE (30A-BL)	2	
20	90464-13073-00	CLAMP	2	
21	90464-13080-00	CLAMP	2	FOR CA
22	4JH-81960-00-00	RECTIFIER & REGULATOR ASSEMBLY	1	
23	3HH-81975-00-00	PLATE, RECTIFIER FITTING . .	1	
24	95817-06010-00	BOLT, FLANGE	2	
25	95817-06025-00	BOLT, FLANGE	2	

CONTINUED ON NEXT FRAME ➤


ELECTRICAL 1

Ref. No.	Part Number	Description	Qty	Remarks
26	90179-06520-00	NUT	2	
27	90464-11107-00	CLAMP	1	
28	3JV-82501-00-00	MAIN SWITCH STEERING LOCK	1	
29	90149-06228-00	SCREW	2	
30	90464-10075-00	CLAMP	1	



3HHE110-5490

ELECTRICAL 2



3UU110-4480

Ref. No.	Part Number	Description	Qty	Remarks
1	1AE-82540-00-00	NEUTRAL SWITCH ASSY	1	
2	93210-29196-00	O-RING	1	
3	98507-06016-00	SCREW, PAN HEAD	2	
4	11H-83591-00-00	THERMO UNIT	1	
5	2GH-82509-00-00	WIRE, SUB LEAD	1	
6	1WG-85720-00-00	OIL LEVEL GAUGE ASSEMBLY	1	
7	95027-06016-00	BOLT, FLANGE	2	
8	3LN-82560-01-00	THERMOSWITCH ASSEMBLY .	1	
9	1WG-82541-00-00	WIRE, LEAD	1	
10	3EN-81950-00-00	RELAY ASSY	1	
11	3LD-82566-50-00	SWITCH, SIDE STAND	1	
12	90157-05079-00	SCREW, PAN HEAD	2	
13	2UJ-83350-00-00	FLASHER RELAY ASSEMBLY .	1	
14	4FM-83371-00-00	HORN	1	
15	95817-06012-00	BOLT, FLANGE	1	
16	11H-85110-01-00	REFLECTOR ASSY	2	
17	3G1-85130-01-00	REAR REFLECTOR ASSEMBLY	2	
18	95707-05500-00	NUT, FLANGE	4	
19	90480-14023-00	GROMMET	1	CA ONLY
20	90387-074W0-00	COLLAR	1	CA ONLY
21	90201-065F3-00	WASHER, PLATE	1	CA ONLY
22	95817-06025-00	BOLT, FLANGE	1	CA ONLY
23	3LN-85820-00-00	SERVO MOTOR ASSY	1	CA ONLY