
PARTS CATALOGUE
MODEL YEAR 1995
YZF600RGC (4NC1)
CALIFORNIA MODEL ONLY

Frame Serial No.	4NC-000101 and following
Engine Serial No.	4NC-000101 and following


PUBLICATION	PART NUMBER	REMARKS
OWNER'S MANUAL	LIT-11626-09-23	
ASSEMBLY	LIT-11666-09-23	
SERVICE MANUAL	LIT-11616-09-23	



YAMAHA ONLINE Parts & Accessories

A1


CYLINDER HEAD



4JH351-4010

Ref. No.	Part Number	Description	Qty	Remarks
1	4MM-11101-00-00	CYLINDER HEAD ASSEMBLY .	1	
2	3TJ-11133-10-00	. GUIDE, INTAKE VALVE	16	
3	93440-07149-00	. CIRCLIP	16	
4	99510-08016-00	. PIN, DOWEL	12	
5	90340-12112-00	. PLUG, STRAIGHT SCREW ...	6	
6	90105-06384-00	. BOLT, WASHER BASED	24	
7	90338-08174-00	. PLUG	12	
8	90116-06437-00	BOLT, STUD	8	
9	90201-090P4-00	WASHER, PLATE	12	
10	90179-09612-00	NUT	12	
11	NGK-CR9E0-00-00	PLUG, SPARK (NGK R CR9E) .	4	UR
12	4JH-11181-00-00	GASKET, CYLINDER HEAD 1 .	1	
13	3TJ-11191-00-00	COVER, CYLINDER HEAD 1 ..	1	
14	3TJ-11193-00-00	GASKET, HEAD COVER 1	1	
15	90109-064F0-00	BOLT	8	
16	90209-11262-00	WASHER	8	
17	2GH-1111G-00-00	RUBBER, MOUNT 1	8	

CYLINDER




FWD

4NC110-5020

Ref. No.	Part Number	Description	Qty	Remarks
1	4MM-11311-00-00	CYLINDER 1	1	
2	91810-08016-00	PIN, DOWEL	2	
3	3TJ-11351-00-00	GASKET, CYLINDER	1	
4	95816-06014-00	BOLT, FLANGE	2	
5	90430-06014-00	GASKET	3	


CRANKSHAFT - PISTON



4NC110-5030

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-11411-00-00	CRANKSHAFT	1	
2	93101-29165-00	OIL SEAL	1	UR
	93101-29166-00	OIL SEAL	1	AP
3	1WG-11416-00-00	PLANE BEARING, CRANKSHAFT 1	12	UR BLUE
	1WG-11416-10-00	PLANE BEARING, CRANKSHAFT 1	12	UR BLACK
	1WG-11416-20-00	PLANE BEARING, CRANKSHAFT 1	12	UR BROWN
	1WG-11416-30-00	PLANE BEARING, CRANKSHAFT 1	12	UR GREEN
	1WG-11416-40-00	PLANE BEARING, CRANKSHAFT 1	12	UR YELLOW
	1WG-11416-50-00	PLANE BEARING, CRANKSHAFT 1	12	UR PINK
4	4JH-11631-00-00	PISTON (STD)	4	
5	4JH-11603-00-00	PISTON RING SET (STD)	4	
6	4JH-11633-00-00	PIN, PISTON	4	
7	90468-12069-00	CLIP	8	
8	4JH-11650-00-00	CONNECTING ROD ASSEMBLY	4	
9	4JH-11654-00-00	. BOLT, CONNECTING ROD	2	
10	90179-07652-00	. NUT	2	
11	1WG-11656-00-00	PLANE BEARING, CONNECTING ROD	8	UR BLUE
	1WG-11656-10-00	PLANE BEARING, CONNECTING ROD	8	UR BLACK
	1WG-11656-20-00	PLANE BEARING, CONNECTING ROD	8	UR BROWN
	1WG-11656-30-00	PLANE BEARING, CONNECTING ROD	8	UR GREEN


VALVE



WG010-6040

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-12111-00-00	VALVE, INTAKE	8	
2	4JH-12121-00-00	VALVE, EXHAUST	8	
3	1WG-12116-00-00	SEAT, VALVE SPRING	16	
4	4JH-12113-00-00	SPRING, VALVE INNER	16	
5	3TJ-12117-00-00	RETAINER, VALVE SPRING	16	
6	1HX-12118-00-00	COTTER, VALVE	32	
7	1HX-12119-00-00	SEAL, VALVE STEM	16	
8	3FV-12153-09-00	LIFTER, VALVE (O/S)	16	UR GREEN
	3FV-12153-10-00	LIFTER, VALVE	16	UR YELLOW
9	1HX-12168-00-00	PAD, ADJUSTING 2 (1.20)	16	UR
	1HX-12168-20-00	PAD, ADJUSTING 2 (1.25)	16	UR
	1HX-12168-40-00	PAD, ADJUSTING 2 (1.30)	16	UR
	1HX-12168-60-00	PAD, ADJUSTING 2 (1.35)	16	UR
	1HX-12168-80-00	PAD, ADJUSTING 2 (1.40)	16	UR
	1HX-12168-A0-00	PAD, ADJUSTING 2 (1.45)	16	UR
	1HX-12168-F0-00	PAD, ADJUSTING 2 (1.50)	16	UR
	1HX-12168-H1-00	PAD, ADJUSTING 2 (1.55)	16	UR
	1HX-12168-K1-00	PAD, ADJUSTING 2 (1.60)	16	UR
	1HX-12168-M1-00	PAD, ADJUSTING 2 (1.65)	16	UR
	1HX-12168-R1-00	PAD, ADJUSTING 2 (1.70)	16	UR
	1HX-12168-U1-00	PAD, ADJUSTING 2 (1.75)	16	UR
	1HX-12168-W1-00	PAD, ADJUSTING 2 (1.80)	16	UR
	1HX-12168-Y1-00	PAD, ADJUSTING 2 (1.85)	16	UR
	1HX-12169-11-00	PAD, ADJUSTING 2 (1.90)	16	UR
	1HX-12169-31-00	PAD, ADJUSTING 2 (1.95)	16	UR
	1HX-12169-50-00	PAD, ADJUSTING 2 (2.00)	16	UR
	1HX-12169-70-00	PAD, ADJUSTING 2 (2.05)	16	UR
	1HX-12169-90-00	PAD, ADJUSTING 2 (2.10)	16	UR
	1HX-12169-E0-00	PAD, ADJUSTING 2 (2.15)	16	UR


CONTINUED ON NEXT FRAME ➤




WG010-6040

VALVE

Ref. No.	Part Number	Description	Qty	Remarks
9	1HX-12169-G0-00	PAD, ADJUSTING 2 (2.20)	16	UR
	1HX-12169-J0-00	PAD, ADJUSTING 2 (2.25)	16	UR
	1HX-12169-L0-00	PAD, ADJUSTING 2 (2.30)	16	UR
	1HX-12169-N0-00	PAD, ADJUSTING 2 (2.35)	16	UR
	1HX-12169-T0-00	PAD, ADJUSTING 2 (2.40)	16	UR






4JH351-4050

CAMSHAFT - CHAIN


Ref. No.	Part Number	Description	Qty	Remarks
1	4NC-12171-00-00	CAMSHAFT 1	1	
2	4NC-12181-00-00	CAMSHAFT 2	1	
3	1WG-12176-00-00	SPROCKET, CAM CHAIN	2	
4	90105-07385-00	BOLT, WASHER BASED	4	
5	94581-32118-00	CHAIN (D.I.D. 215F DHA 118L)	1	
6	94681-32021-00	. JOINT, CHAIN (D.I.D.215F-LJ)	1	
7	3TJ-12241-00-00	GUIDE, STOPPER 2	1	
8	3GM-12210-00-00	TENSIONER ASSEMBLY, CAM CHAIN (1WG-12210-02-00)	1	
9	90109-112F1-00	BOLT	1	
10	4BE-12213-00-00	GASKET, TENSIONER CASE	1	
11	91317-06025-00	BOLT	2	
12	3HE-12251-00-00	DAMPER, CHAIN 1	1	
13	4JH-12252-00-00	DAMPER, CHAIN 2	1	
14	90109-065A8-00	BOLT	2	

WATER PUMP




Ref. No.	Part Number	Description	Qty	Remarks
1	3TJ-Y1242-00-00	WATER PUMP ASSEMBLY . . .	1	
2	1WG-12439-00-00	. O-RING	1	
3	91317-06025-00	. BOLT	2	
4	95027-06012-00	. BOLT, FLANGE	1	
5	90430-06014-00	. GASKET	1	
6	93210-33133-00	. O-RING	1	
7	91317-06035-00	BOLT	2	
8	4JH-12481-00-00	PIPE 1	1	
9	93210-21190-00	O-RING	2	
10	91317-06010-00	BOLT	2	
11	1WG-12446-01-00	JOINT	1	
12	93210-17746-00	O-RING	2	
13	91317-06040-00	BOLT	3	
14	91317-06025-00	BOLT	1	
15	4JH-12482-00-00	PIPE 2	1	
16	93210-15566-00	O-RING	2	
17	91317-06010-00	BOLT	2	
18	3TJ-12576-00-00	HOSE 1	1	
19	90450-32051-00	HOSE CLAMP ASSEMBLY . . .	2	
20	4JH-12577-00-00	HOSE 2	1	
21	90450-32051-00	HOSE CLAMP ASSEMBLY . . .	2	
22	4JH-12410-00-00	THERMOSTAT ASSEMBLY . . .	1	
23	3TJ-12417-00-00	HOUSING, THERMOSTAT	1	
24	3TJ-12413-00-00	COVER, THERMOSTAT	1	
25	91317-06020-00	BOLT	2	

RADIATOR - HOSE



4NC110-5070

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-12461-00-00	RADIATOR ASSEMBLY	1	
2	4JH-12462-00-00	CAP, RADIATOR	1	
3	4JH-12405-00-00	BLOWER ASSEMBLY	1	
4	95811-06010-00	BOLT, FLANGE	3	
5	4JH-12578-00-00	HOSE 3	1	
6	90450-32051-00	HOSE CLAMP ASSEMBLY	2	
7	4MM-12579-00-00	HOSE 4	1	
8	90450-17036-00	HOSE CLAMP ASSEMBLY	2	
9	4JH-12588-00-00	HOSE 5	1	
10	90450-17036-00	HOSE CLAMP ASSEMBLY	2	
11	4JH-1243A-00-00	HOSE 1	1	
12	90467-11090-00	CLIP	2	
13	90480-15363-00	GROMMET	3	
14	90387-07391-00	COLLAR	3	
15	95807-06025-00	BOLT, FLANGE	3	
16	90201-063J2-00	WASHER, PLATE	3	
17	90445-095E9-00	HOSE	1	
18	90467-08003-00	CLIP	2	
19	4JH-1244F-00-00	BRACKET 1	1	
20	4JH-2142K-00-00	BRACKET, RADIATOR	1	
21	95807-06012-00	BOLT, FLANGE	2	




4JH351-4080

OIL PUMP

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-13330-00-00	PUMP SHAFT ASSEMBLY	1	
2	1WG-13316-00-00	COVER, PUMP	1	
3	90201-113K2-00	WASHER, PLATE	1	
4	93603-17070-00	PIN, DOWEL	1	
5	1WG-13310-00-00	ROTOR ASSEMBLY 1	1	
6	93603-09106-00	PIN, DOWEL	2	
7	1WG-13336-00-00	HOUSING, ROTOR	1	
8	98580-06020-00	SCREW	1	
9	99510-08012-00	PIN, DOWEL	1	
10	1WG-13329-00-00	GASKET, PUMP COVER	1	
11	90110-06130-00	BOLT, HEXAGON SOCKET HEAD	3	
12	3TJ-13412-00-00	HOUSING, STRAINER	1	
13	4H7-13411-02-00	STRAINER, OIL	1	
14	90110-06225-00	BOLT, HEXAGON SOCKET HEAD	2	


OIL COOLER



4JH351-4090


Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-13470-00-00	OIL COOLER ASSEMBLY	1	
2	90401-20158-00	BOLT, UNION	1	
3	3FV-13440-00-00	ELEMENT ASSEMBLY, OIL CLEANER	1	
4	11H-13490-00-00	RELIEF VALVE ASSEMBLY	1	
5	93210-10096-00	O-RING	1	
6	4JH-13417-00-00	COVER, STRAINER	1	
7	3HE-13414-10-00	GASKET, STRAINER COVER	1	
8	91316-06025-00	BOLT	14	
9	99510-08016-00	PIN, DOWEL	2	
10	3VD-13455-00-00	PLUG	1	
11	214-11198-01-00	GASKET	1	
12	90465-10306-00	CLAMP	1	
13	3HE-13161-00-00	PIPE, DELIVERY 1	1	
14	91317-06010-00	BOLT	1	
15	90401-10106-00	BOLT, UNION	2	
16	90430-10171-00	GASKET	4	

INTAKE



Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-13586-00-00	JOINT, CARBURETOR 1	2	
2	4JH-13596-00-00	JOINT, CARBURETOR 2	2	
3	91317-06020-00	BOLT	8	
4	90450-52063-00	HOSE CLAMP ASSEMBLY (90450-52074-00)	4	
5	4MM-14411-00-00	CASE, AIR CLEANER 1	1	
6	4JH-14421-00-00	CASE, AIR CLEANER 2	1	
7	4FM-14452-00-00	SEAL	1	
8	97707-50125-00	SCREW, TAPPING	10	
9	4JH-14451-00-00	ELEMENT, AIR CLEANER	1	
10	4JH-14412-00-00	CAP, CLEANER CASE 1	1	
11	1VJ-14462-00-00	SEAL	1	
12	4JH-14453-00-00	JOINT, AIR CLEANER 1	4	
13	90460-59213-00	CLAMP, HOSE	4	
14	90445-11452-00	HOSE	1	
15	90467-10008-00	CLIP	3	
16	4X7-2149Y-00-00	FILTER ASSEMBLY	1	
17	90445-075G7-00	HOSE	1	
18	98507-05030-00	SCREW, PAN HEAD	2	
19	92907-05600-00	WASHER, PLATE	2	
20	4JH-14467-00-00	SEAL	1	
21	90445-09488-00	HOSE	1	
22	90445-09496-00	HOSE	1	
23	90467-08092-00	CLIP	1	
24	90445-09683-00	HOSE	1	
25	90445-090E5-00	HOSE	1	
26	90338-05240-00	PLUG	2	
27	90467-08017-00	CLIP	7	

EMISSION CONTROL DEVICE




4NC110-5110

Ref. No.	Part Number	Description	Qty	Remarks
1	42H-14714-10-00	GASKET, MUFFLER	4	
2	4MM-14872-00-00	PIPE 2	1	
3	4MM-14873-00-00	PIPE 3	1	
4	2LJ-14883-00-00	HOSE, BEND 3	4	
5	90468-08104-00	CLIP	8	
6	4MM-14808-00-00	REED VALVE ASSEMBLY	1	
7	90480-14229-00	GROMMET	4	
8	90387-07391-00	COLLAR	4	
9	95027-06025-00	BOLT, FLANGE	4	
10	2LJ-14874-00-00	PIPE 4	1	
11	4MM-14881-00-00	HOSE, BEND 1	2	
12	2LJ-14882-00-00	HOSE, BEND 2	1	
13	4MM-14840-00-00	AIR CUT VALVE ASS''Y	1	
14	90462-20188-00	CLAMP	1	
15	98507-06016-00	SCREW, PAN HEAD	1	
16	92907-06100-00	WASHER, SPRING	1	
17	92907-06600-00	WASHER, PLATE	1	
18	90445-091J2-00	HOSE	1	
19	90467-08092-00	CLIP	1	
20	4MM-14885-00-00	HOSE, BEND 5	1	
21	4MM-14875-00-00	PIPE 5	1	
22	90467-19051-00	CLIP	3	
23	4MM-14884-00-00	HOSE, BEND 4	1	
24	90464-12196-00	CLAMP	1	
25	90467-23067-00	CLIP	1	
26	90467-14015-00	CLIP	1	
27	90464-23041-00	CLAMP	3	
28	90464-30040-00	CLAMP	1	
29	4MM-14868-00-00	BRACKET 2	1	

CONTINUED ON NEXT FRAME ➤


EMISSION CONTROL DEVICE



4NC110-5110

Ref. No.	Part Number	Description	Qty	Remarks
30	4MM-14869-00-00	BRACKET 3	1	
31	90105-10169-00	BOLT, WASHER BASED	2	
32	92907-10600-00	WASHER, PLATE	2	
33	95617-10100-00	NUT, U	2	
34	4MM-14849-00-00	BRACKET	1	
35	95807-06010-00	BOLT, FLANGE	1	
36	4MM-13582-00-00	PIPE	1	
37	90467-08017-00	CLIP	1	
38	1WT-24311-00-00	PIPE, FUEL 1	1	
39	90445-11763-00	HOSE	1	
40	3H3-24376-00-00	PIPE, JOINT 1	1	
41	90467-10008-00	CLIP	4	


CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
1	4NC-14901-00-00	CARBURETOR ASSEMBLY 1 .	1	
2	4NC-14902-00-00	CARBURETOR ASSEMBLY 2 .	1	
3	4NC-14903-00-00	CARBURETOR ASSEMBLY 3 .	1	
4	4NC-14904-00-00	CARBURETOR ASSEMBLY 4 .	1	
5	4JH-14216-00-00	. SCREW	3	UR #3
	4JH-14216-00-00	. SCREW	4	
6	4JH-14933-00-00	. SPRING, DIAPHRAGM	1	
7	4JH-14940-00-00	. DIAPHRAGM ASSEMBLY . . .	1	
8	4JH-14515-00-00	. JET	1	
9	4JH-14936-00-00	. SEAT, SPRING	1	
10	4NA-14916-00-00	. NEEDLE	1	
11	4JH-1414G-00-00	. PIPE, MAIN BLEED	1	
12	3TJ-14943-81-00	. JET, MAIN (#118)	1	
13	4JH-14948-01-00	. JET (#35)	1	
14	4NA-14105-00-00	. PILOT SCREW SET	1	
15	4JH-14107-00-00	. NEEDLE VALVE SET	1	
16	3TJ-14216-40-00	. SCREW	1	
17	4JH-14985-00-00	. FLOAT	1	
18	663-14548-00-00	. PIN, FLOAT ARM	1	
19	98580-04008-00	. SCREW, PAN HEAD	1	
20	4JH-14984-00-00	. GASKET, FLOAT CHAMBER .	1	
21	3TJ-14191-40-00	. PLUG, DRAIN	1	
22	98503-04014-00	. SCREW, PAN HEAD	3	
	98503-04014-00	. SCREW, PAN HEAD	4	
23	4JH-1410A-00-00	. STARTER SET	1	
24	4MM-14118-00-00	. CAP	1	
25	4JH-14922-00-00	SCREW, THROTTLE	1	
26	4JH-14934-00-00	SPRING, THROTTLE STOP . . .	1	
27	4JH-14429-00-00	SCREW	1	

CONTINUED ON NEXT FRAME ➤


CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
28	4JH-14162-00-00	BOLT, HOLDING	1	
29	4JH-14358-00-00	NUT	1	
30	4JH-14325-00-00	SCREW, PAN HEAD	8	
31	4JH-14121-00-00	SCREW, THROTTLE STOP	3	
32	7A9-14555-00-00	SPRING	3	
33	4JH-14133-00-00	SPRING, THROTTLE STOP	3	
34	4JH-14487-00-00	SPRING	2	
35	90202-06056-00	WASHER, PLATE	6	
36	3TJ-14245-40-00	SCREW, GUIDE	3	
37	4JH-14565-00-00	SCREW	1	
38	4JH-14264-00-00	COLLAR	1	
39	4JH-14567-00-00	SCREW	1	
40	4JH-14935-00-00	SPRING	1	
41	4JH-14350-00-00	PIPE ADAPTOR ASSEMBLY	2	
42	4JH-13918-00-00	PIPE T	1	
43	4JH-14197-00-00	PIPE	2	
44	4JH-14294-00-00	HOSE	1	
45	4JH-14298-00-00	PIPE	1	
46	4JH-14137-00-00	CLIP	4	
47	3TJ-14148-40-00	PIPE	2	
48	3TJ-14937-40-00	CLIP	2	
49	4JH-1440F-00-00	JOINT, AIR FILTER 1	4	
50	4JH-14561-00-00	O-RING	4	
51	4JH-14245-00-00	SCREW, GUIDE	8	
52	4NC-14568-00-00	JOINT	2	
53	4NC-14527-00-00	PLATE	2	
54	4NC-14325-00-00	SCREW, PAN HEAD	2	
55	4NC-14561-00-00	O-RING	4	
56	90445-142H0-00	HOSE	1	


CONTINUED ON NEXT FRAME ➤

CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
57	90467-13123-00	CLIP	2	


EXHAUST



4JH351-4120

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-14602-00-00	EXHAUST PIPE COMP.	1	
2	90101-06576-00	. BOLT	4	
3	92907-06600-00	. WASHER, PLATE	4	
4	3YF-14613-01-00	GASKET, EXHAUST PIPE	4	
5	90179-06499-00	NUT	8	
6	95816-08030-00	BOLT, FLANGE	1	
7	90201-08730-00	WASHER, PLATE	1	
8	4NA-14710-00-00	MUFFLER ASSEMBLY 1	1	
9	3XW-14714-00-00	. GASKET, MUFFLER	1	
10	95816-08025-00	. BOLT, FLANGE	1	
11	95821-08020-00	BOLT, FLANGE (95801-08020) .	1	


CRANKCASE



Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-15100-00-00	CRANKCASE ASSEMBLY	1	
2	11H-15138-00-00	. NOZZLE 1	1	
3	26H-15138-00-00	. NOZZLE 1	1	
4	99510-12016-00	. PIN, DOWEL	1	
5	4JH-15138-00-00	. NOZZLE 1	1	
6	93210-12152-00	. O-RING	1	
7	2H7-15361-00-00	. GAUGE, LEVEL	1	
8	36Y-15189-00-00	. PLUG	2	
9	93210-16629-00	. O-RING	2	
10	90201-237K5-00	. WASHER, PLATE	1	
11	93315-32516-00	. BEARING	1	
12	91810-08016-00	PIN, DOWEL	2	
13	90116-09583-00	BOLT, STUD	2	
14	90116-09584-00	BOLT, STUD	10	
15	90105-08630-00	BOLT, WASHER BASED	12	
16	90201-087K3-00	WASHER, PLATE	12	
17	95816-06040-00	BOLT	10	
18	95816-06050-00	BOLT, FLANGE	5	
19	95816-06070-00	BOLT, FLANGE	3	
20	95816-06080-00	BOLT, FLANGE	1	
21	95816-06090-00	BOLT, FLANGE	2	
22	95816-08070-00	BOLT, FLANGE	1	
23	90430-06166-00	GASKET	1	
24	90465-10307-00	CLAMP	1	
25	90465-10308-00	CLAMP	1	
26	4JH-11165-00-00	PLATE, BREATHER	1	
27	98511-06012-00	SCREW, PAN HEAD	2	
28	3HE-11145-00-00	PLATE, BREATHER 2	1	
29	98511-06012-00	SCREW, PAN HEAD	4	


CONTINUED ON NEXT FRAME ➤

CRANKCASE



Ref. No.	Part Number	Description	Qty	Remarks
30	1WG-11166-00-00	PIPE, BREATHER 1	1	
31	90467-14015-00	CLIP	2	
32	90445-116E9-00	HOSE	1	
33	90465-06289-00	CLAMP	1	
34	90467-10038-00	CLIP	1	
35	4JH-15381-00-00	PLATE, BEARING COVER	1	
36	91316-06012-00	BOLT, SOCKET HEAD	2	
37	3HE-15105-00-00	NOZZLE ASSEMBLY (3HE-15105-01-00)	2	
38	93210-06632-00	O-RING	2	

CRANKCASE COVER 1




4JH351-4140

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-15411-00-00	COVER, CRANKCASE 1	1	
2	1L9-15417-00-00	COVER, CAP	1	
3	1WG-15316-00-00	DAMPER, ENGINE MOUNT 1	1	
4	1WG-15427-00-00	COVER, CAP 2	1	
5	98901-05008-00	SCREW, BIND	4	
6	3HE-15451-10-00	GASKET, CRANKCASE COVER 1	1	
7	3FA-15467-00-00	GASKET	1	
8	99510-08016-00	PIN, DOWEL	2	
9	90110-06149-00	BOLT, HEXAGON SOCKET HEAD	4	
10	90110-06130-00	BOLT, HEXAGON SOCKET HEAD	1	
11	4JH-15421-00-00	COVER, CRANKCASE 2	1	
12	4JH-15461-00-00	GASKET, CRANKCASE COVER 2	1	
13	99510-08016-00	PIN, DOWEL	2	
14	91311-06025-00	BOLT, SOCKET HEAD	2	
15	91311-06035-00	BOLT, SOCKET HEAD	4	
16	91311-06045-00	BOLT	1	
17	4JH-15431-00-00	COVER, CRANKCASE 3	1	
18	1WG-15425-00-00	COVER, GENERATOR 2	1	
19	1WG-15326-00-00	DAMPER, ENGINE MOUNT 2	1	
20	98901-05008-00	SCREW, BIND	4	
21	4JH-15462-00-00	GASKET, CRANKCASE COVER 3	1	
22	99510-08016-00	PIN, DOWEL	2	
23	91311-06025-00	BOLT, SOCKET HEAD	8	
24	91311-06035-00	BOLT, SOCKET HEAD	2	
25	3F9-15362-00-00	PLUG, OIL LEVEL	1	

CONTINUED ON NEXT FRAME ➤


CRANKCASE COVER 1



4JH351-4140

Ref. No.	Part Number	Description	Qty	Remarks
26	93210-27778-00	O-RING	1	
27	4JH-15415-00-00	COVER, GENERATOR	1	
28	90340-08M04-00	PLUG, STRAIGHT SCREW	1	
29	99510-08016-00	PIN, DOWEL	2	
30	91311-06025-00	BOLT, SOCKET HEAD	3	
31	91311-06035-00	BOLT, SOCKET HEAD	1	
32	91311-06035-00	BOLT, SOCKET HEAD	1	
33	90462-10182-00	CLAMP	1	
34	98580-06010-00	SCREW, PAN HEAD (92503-06010)	1	
35	4JH-14413-00-00	STAY	1	


STARTER



3HE332-9160

Ref. No.	Part Number	Description	Qty	Remarks
1	3HE-15521-00-00	SHAFT 1	1	
2	3HE-15512-00-00	GEAR, IDLER 1	1	
3	3HE-15517-00-00	GEAR, IDLER 2	1	
4	3TJ-15521-00-00	SHAFT 1	2	
5	3HE-15590-02-00	STARTER ONE-WAY ASSEMBLY	1	
6	3HE-15524-00-00	WHEEL, STARTER	1	
7	91316-08020-00	BOLT	3	
8	4JH-15515-00-00	GEAR 3	1	
9	90280-16053-00	KEY, WOODRUFF	1	
10	90201-107K6-00	WASHER, PLATE	1	
11	90105-10445-00	BOLT, WASHER BASED	1	
12	93306-20005-00	BEARING (B6200)	1	NTN


CLUTCH



4JH351-4160

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-16150-00-00	PRIMARY DRIVEN GEAR COMP.	1	
2	1WG-16154-00-00	PLATE, THRUST 1	1	
3	4JH-16371-00-00	BOSS, CLUTCH	1	
4	4JH-16321-00-00	PLATE, FRICTION	9	
5	1LX-16324-00-00	PLATE, CLUTCH 1	8	
6	93306-00105-00	BEARING (B6001)	1	
7	4JH-16351-00-00	PLATE, PRESSURE 1	1	
8	90501-224J9-00	SPRING, COMPRESSION	6	
9	90159-06092-00	SCREW, WITH WASHER	6	
10	4JH-16356-00-00	ROD, PUSH 1	1	
11	93210-48364-00	O-RING	1	
12	90215-18225-00	WASHER, LOCK	1	
13	90170-18221-00	NUT	1	
14	93109-08058-00	OIL SEAL (SD07 8-21-5.5 HS)	1	
15	4JH-16357-00-00	ROD, PUSH 2	1	
16	93505-16006-00	BALL	1	
17	4JH-16340-00-00	PUSH LEVER ASSEMBLY	1	
18	1WG-16304-00-00	BALL SCREW HOUSING ASSEMBLY	1	
19	90113-08021-00	BOLT, SET	1	
20	90179-08179-00	NUT	1	
21	90506-11488-00	SPRING, TENSION	1	
22	90157-05065-00	SCREW, PAN HEAD	2	
23	132-16346-00-00	HOOK, SPRING	1	
24	90387-212R3-00	COLLAR	1	
25	1WG-16164-00-00	PLATE, THRUST 2	1	
26	1WG-16181-00-00	SPACER 1	1	
27	93310-345R8-00	BEARING	1	

TRANSMISSION




4JH351-4170

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-17411-00-00	AXLE, MAIN (13T)	1	
2	4JH-17151-00-00	GEAR, 5TH PINION (21T)	1	
3	90209-22191-00	WASHER	1	
4	93440-25084-00	CIRCLIP	1	
5	4JH-17131-00-00	GEAR, 3RD/4TH PINION (22T/21T)	1	
6	4JH-17161-00-00	GEAR, 6TH PINION (27T)	1	
7	4JH-17121-00-00	GEAR, 2ND PINION (19T)	1	
8	93306-37208-00	BEARING	1	
9	93440-54152-00	CIRCLIP	1	
10	93306-20464-00	BEARING	1	
11	4JH-17421-00-00	AXLE, DRIVE	1	
12	93305-20509-00	BEARING	1	
13	90201-25291-00	WASHER, PLATE	1	
14	4JH-17221-00-00	GEAR, 2ND WHEEL (37T)	1	
15	90209-27336-00	WASHER	1	
16	93440-30077-00	CIRCLIP	1	
17	4JH-17261-00-00	GEAR, 6TH WHEEL (29T)	1	
18	4JH-17231-00-00	GEAR, 3RD WHEEL (34T)	1	
19	4JH-17241-00-00	GEAR, 4TH WHEEL (28T)	1	
20	90209-22191-00	WASHER	1	
21	93440-25084-00	CIRCLIP	1	
22	4JH-17251-00-00	GEAR, 5TH WHEEL (25T)	1	
23	4JH-17211-00-00	GEAR, 1ST WHEEL (37T)	1	
24	90387-2504A-00	COLLAR	1	
25	93102-35368-00	OIL SEAL	1	
26	3HE-17460-00-00	SPROCKET, DRIVE (15T)	1	
27	90215-21022-00	WASHER, LOCK	1	
28	90179-18020-00	NUT	1	

CONTINUED ON NEXT FRAME ➤


TRANSMISSION



4JH351-4170

Ref. No.	Part Number	Description	Qty	Remarks
29	93440-52014-00	CIRCLIP	1	
30	90201-20276-00	WASHER, PLATE (1.0T)	1	
31	93311-42045-00	BEARING (20NG3315NE)	1	
32	278-17425-00-00	CIRCLIP 2	1	
33	4G0-17433-01-00	NOZZLE	1	


SHIFT CAM - SHIFT FORK



4JH351-4180


Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-18540-00-00	SHIFT CAM ASSEMBLY	1	
2	90501-06022-00	. SPRING, COMPRESSION	1	
3	278-18542-00-00	. POINT, NEUTRAL	1	
4	278-18566-00-00	. PLATE, SIDE 2	1	
5	98701-05012-00	. SCREW, FLAT HEAD	1	
6	4JH-18531-00-00	BAR, SHIFT FORK GUIDE 1	1	
7	4JH-18535-00-00	BAR, SHIFT FORK GUIDE 2	1	
8	4JH-18511-00-00	FORK, SHIFT 1	1	
9	4JH-18512-00-00	FORK, SHIFT 2	1	
10	4JH-18513-00-00	FORK, SHIFT 3	1	
11	1WG-18536-00-00	STOPPER, SHIFT BAR	1	
12	1HX-18127-00-00	STOPPER, SCREW	1	
13	90508-23707-00	SPRING, TORSION	1	
14	1WG-18562-00-00	PLATE, STOPPER 2	1	
15	36Y-18140-00-00	STOPPER LEVER ASSEMBLY	1	
16	90109-063F7-00	BOLT	1	
17	95817-06016-00	BOLT, FLANGE	2	

SHIFT SHAFT



Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-18101-00-00	SHIFT SHAFT ASSEMBLY	1	
2	90508-32682-00	. SPRING, TORSION	1	
3	93102-12321-00	OIL SEAL, SD-TYPE	1	
4	90560-12211-00	SPACER	1	
5	93109-12053-00	OIL SEAL (SDO 12/18/4-1)	2	
6	4JH-18110-00-00	SHIFT PEDAL ASSEMBLY	1	
7	2H9-18154-00-00	. COVER, DUST	1	
8	132-18113-01-00	. COVER, SHIFT PEDAL	1	
9	4JH-18130-00-00	SHIFT SHAFT ASSEMBLY	1	
10	2H9-18154-00-00	. COVER, DUST	1	
11	97011-06020-00	BOLT	1	
12	4JH-18115-00-00	ROD, SHIFT	1	
13	90170-08358-00	NUT	1	
14	95303-08700-00	NUT	1	


FRAME



Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-21110-00-T9	FRAME COMP.	1	COMPETITION SILVER
2	4FM-21645-01-00	STAY, REAR	1	
3	90338-16148-00	PLUG	2	
4	95817-08016-00	BOLT, FLANGE	2	
5	95817-08035-00	BOLT, FLANGE	2	
6	91317-10045-00	BOLT	2	
7	91317-10050-00	BOLT	2	
8	95817-10025-00	BOLT, FLANGE	2	
9	90387-115V8-00	COLLAR	2	
10	90105-10130-00	BOLT, WASHER BASED	1	
11	95707-10500-00	NUT, FLANGE	3	
12	95827-10175-00	BOLT, FLANGE	1	
13	90201-10774-00	WASHER, PLATE	1	
14	4JH-21359-00-00	BRACKET, COIL	2	
15	95807-06012-00	BOLT, FLANGE	4	
16	4JH-21488-00-00	DAMPER	2	
17	3TJ-82131-00-00	BAND, BATTERY	2	
18	4JH-2117M-00-00	COVER 2	1	
19	4JH-21208-00-00	SEAL SET, 1	1	
20	4JH-21209-00-00	SEAL SET, 2	1	
21	4JH-2117N-01-00	COVER 3	1	
22	4JH-21446-00-00	STAY, MUFFLER 2	1	
23	36Y-21639-00-00	DAMPER 2	4	
24	98507-06016-00	SCREW, PAN HEAD	2	
25	92907-06600-00	WASHER, PLATE	2	
26	90480-18171-00	GROMMET	1	
27	4FM-21871-00-00	TANK, RECOVERY	1	
28	90159-06033-00	SCREW, WITH WASHER	2	
29	4L0-21875-00-00	CAP	1	


CONTINUED ON NEXT FRAME ➤

FRAME



Ref. No.	Part Number	Description	Qty	Remarks
30	1AA-21874-00-00	GASKET	1	
31	90445-08786-00	HOSE	1	
32	90467-08003-00	CLIP	1	


FENDER



Ref. No.	Part Number	Description	Qty	Remarks
1	4FM-Y2151-11-P1	FRONT FENDER COMP.	1	DARK BLUE COCKTAIL 2
2	4FM-21569-30-00	. GRAPHIC 1	1	
3	90154-06061-00	SCREW, BINDING	2	
4	95807-06016-00	BOLT, FLANGE	2	
5	90480-12072-00	GROMMET	2	
6	90387-065J6-00	COLLAR	2	
7	90387-087L0-00	COLLAR	2	
8	4FM-28372-00-00	DAMPER	2	
9	4FM-21611-12-00	FENDER, REAR	1	
10	90119-06118-00	BOLT, WITH WASHER	2	
11	90119-06205-00	BOLT, WITH WASHER	2	
12	3VD-21366-00-00	HOOK, TOOL BAND	2	
13	90267-40054-00	RIVET, BLIND	4	
14	90201-044A2-00	WASHER, PLATE	4	
15	3YX-21376-00-00	BAND, TOOL	1	
16	35T-24724-00-00	DAMPER, SEAT	2	
17	90338-10132-00	PLUG	1	
18	5H0-8235Y-M0-00	DAMPER, LOCATING 5 (2GH-24185-00-00)	2	
19	4G0-21639-00-00	DAMPER 2	1	
20	3XV-21778-00-00	DAMPER, LOCATING 1	1	
21	90464-09130-00	CLAMP	1	
22	1VJ-14426-00-00	DAMPER 2	1	
23	4FM-85132-00-00	BRACKET, REFLECTOR 1	1	
24	90267-40076-00	RIVET, BLIND	2	
25	90201-044A2-00	WASHER, PLATE	2	
26	90480-10258-00	GROMMET	2	
27	1WG-28100-01-00	TOOL KIT	1	


CONTINUED ON NEXT FRAME ➤

FENDER




Ref. No.	Part Number	Description	Qty	Remarks
28	4JH-21650-00-00	REAR FENDER COMP.	1	
29	90119-06194-00	BOLT, WITH WASHER	3	
30	3G1-85130-01-00	REAR REFLECTOR ASSEMBLY	1	
31	95707-05500-00	NUT, FLANGE	1	
32	4FM-21688-00-00	BRACKET, REAR STAY	2	
33	90267-40076-00	RIVET, BLIND	4	
34	90201-044A2-00	WASHER, PLATE	4	
35	3G1-85130-01-00	REAR REFLECTOR ASSEMBLY	2	
36	95707-05500-00	NUT, FLANGE	2	

SIDE COVER



Ref. No.	Part Number	Description	Qty	Remarks
1	4FM-Y2171-11-P3	COVER, SIDE 1	1	DARK BLUE COCK-TAIL 2
2	3GM-21575-00-00	. SEAL 1	1	
3	4FM-2173T-00-00	. TAPE 1	1	
4	90480-13398-00	. GROMMET	2	
5	4FM-2173L-30-00	. GRAPHIC SET 1	1	
6	4FM-21781-10-00	. EMBLEM 1	1	
7	90150-06036-00	SCREW, ROUND HEAD	2	
8	90159-06093-00	SCREW, WITH WASHER	1	
9	4FM-Y2172-11-P3	COVER, SIDE 2	1	DARK BLUE COCKTAIL 2
10	3GM-21576-00-00	. SEAL 2	1	
11	4FM-2173T-00-00	. TAPE 1	1	
12	90480-13398-00	. GROMMET	2	
13	4FM-2174L-30-00	. GRAPHIC SET 2	1	
14	4FM-21781-10-00	. EMBLEM 1	1	
15	3TU-2178A-00-00	LABEL	1	
16	3TU-2178A-00-00	LABEL	1	
17	90150-06036-00	SCREW, ROUND HEAD	2	
18	90159-06093-00	SCREW, WITH WASHER	1	
19	90183-04064-00	NUT, SPRING	1	
20	97707-40010-00	SCREW, TAPPING	1	
21	90480-04166-00	GROMMET	2	
22	4NC-2179R-00-00	PLATE, EPA 2	1	


REAR ARM



Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-22110-00-T9	REAR ARM COMP.	1	COMPETITION SILVER
2	47X-22184-00-00	BUSH	1	
3	93320-32403-00	BEARING	2	
4	90201-161J3-00	WASHER, PLATE	2	
5	4X7-22129-00-00	COVER, THRUST 2	2	
6	1UY-22141-00-00	SHAFT, PIVOT	1	
7	90185-16127-00	NUT, SELF-LOCKING	1	
8	90201-160F6-00	WASHER, PLATE	1	
9	3GM-2217A-00-00	ARM, RELAY	1	
10	3GM-2217M-00-00	ARM 1	2	
11	90101-12673-00	BOLT	2	
12	90387-126T1-00	COLLAR	2	
13	90201-126A7-00	WASHER, PLATE	2	
14	95617-12100-00	NUT, U	2	
15	93317-41761-00	BEARING	4	
16	90105-10727-00	BOLT, WASHER BASED	1	
17	90387-100T8-00	COLLAR	1	
18	93317-42060-00	BEARING	1	
19	90101-10659-00	BOLT	1	
20	90387-124W2-00	COLLAR	2	
21	90201-101J1-00	WASHER, PLATE	2	
22	95607-10100-00	NUT, U	2	
23	93101-16131-00	OIL SEAL	2	
24	93399-99919-00	BEARING	1	
25	4JH-22311-00-00	CASE, CHAIN	1	
26	90119-06194-00	BOLT, WITH WASHER	1	
27	90154-05013-00	SCREW, BINDING	2	
28	90183-05024-00	NUT, SPRING	2	
29	4JH-22151-00-00	SEAL, GUARD	1	


CONTINUED ON NEXT FRAME ➤

REAR ARM



Ref. No.	Part Number	Description	Qty	Remarks
30	97007-06014-00	BOLT	2	
31	90387-062M9-00	COLLAR	2	

REAR SUSPENSION




Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-22210-20-00	SHOCK ABSORBER ASSEMBLY, REAR (4JH-22210-10-00)	1	
2	90387-124T2-00	COLLAR	1	
3	90109-10554-00	BOLT	1	
4	90201-101J1-00	WASHER, PLATE	1	
5	95607-10100-00	NUT, U	1	

FWD

4JH351-4240


STEERING



4JH351-4250

Ref. No.	Part Number	Description	Qty	Remarks
1	93332-00001-00	BEARING	1	
2	93332-00008-00	BEARING	1	
3	3HE-23416-00-00	COVER, BALL RACE 2	1	
4	90179-25033-00	NUT	2	
5	90202-26142-00	WASHER, PLATE	1	
6	26H-23418-01-00	WASHER, SPECIAL	1	
7	90176-22050-00	NUT, CROWN	1	
8	4JH-23435-00-00	CROWN, HANDLE	1	
9	91317-08030-00	BOLT	2	


FRONT FORK



Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-23102-00-00	FRONT FORK ASSEMBLY (L.H)	1	
2	4JH-23126-00-00	. TUBE, OUTER (LEFT)	1	
3	4JH-23110-00-00	. INNER TUBE COMP 1	1	
4	4JH-23170-00-00	. CYLINDER COMP., FRONT FORK	1	
5	3GM-23125-50-00	. METAL, SLIDE 1	1	
6	36Y-23146-10-00	. WASHER, OIL SEAL	1	
7	3SP-23145-L0-00	. OIL SEAL	1	
8	26H-23156-00-00	. CLIP, OIL SEAL	1	
9	3XV-23144-50-00	. SEAL, DUST	1	
10	3GM-23173-00-00	. SPINDLE, TAPER	1	
11	509-23158-L0-00	. GASKET	1	
12	278-23181-50-00	. BOLT, HEXAGON SOCKET HEAD	1	
13	4JH-23141-00-00	. SPRING, FRONT FORK	1	
14	3EN-23149-50-00	. WASHER, SPRING UPPER	1	
15	3FW-23118-00-00	. SPACER	1	
16	4JH-23149-00-00	. WASHER, SPRING UPPER	1	
17	4JH-23111-00-00	. BOLT, CAP	1	
18	43F-23188-10-00	. O-RING	1	
19	91311-10045-00	. BOLT	1	
20	4JH-23103-00-00	FRONT FORK ASSEMBLY (R.H)	1	
21	4JH-23136-00-00	. TUBE, OUTER (RIGHT)	1	
22	4JH-23110-00-00	. INNER TUBE COMP 1	1	
23	4JH-23170-00-00	. CYLINDER COMP., FRONT FORK	1	
24	3GM-23125-50-00	. METAL, SLIDE 1	1	
25	36Y-23146-10-00	. WASHER, OIL SEAL	1	
26	3SP-23145-L0-00	. OIL SEAL	1	
27	26H-23156-00-00	. CLIP, OIL SEAL	1	


CONTINUED ON NEXT FRAME ➤

FRONT FORK



Ref. No.	Part Number	Description	Qty	Remarks
28	3XV-23144-50-00	. SEAL, DUST	1	
29	3GM-23173-00-00	. SPINDLE, TAPER	1	
30	509-23158-L0-00	. GASKET	1	
31	278-23181-50-00	. BOLT, HEXAGON SOCKET HEAD	1	
32	4JH-23141-00-00	. SPRING, FRONT FORK	1	
33	3EN-23149-50-00	. WASHER, SPRING UPPER	1	
34	3FW-23118-00-00	. SPACER	1	
35	4JH-23149-00-00	. WASHER, SPRING UPPER	1	
36	4JH-23111-00-00	. BOLT, CAP	1	
37	43F-23188-10-00	. O-RING	1	
38	91311-10045-00	. BOLT	1	
39	4JH-23340-00-00	UNDER BRACKET COMP.	1	
40	91311-12030-00	BOLT	2	


FUEL TANK



Ref. No.	Part Number	Description	Qty	Remarks
1	4FM-24110-70-02	FUEL TANK COMP.	1	DARK BLUE COCKTAIL 2/ VERY DARK VIOLET COCKTAIL 1
2	4FM-24240-11-00	. GRAPHIC SET	1	
3	99227-00160-00	. EMBLEM, YAMAHA	2	
4	4FM-24191-00-00	BRACKET, FUEL TANK 1	1	
5	90176-06055-00	NUT, CROWN	1	
6	2GH-24181-00-00	DAMPER, LOCATING 1	1	
7	2GH-24183-00-00	DAMPER, LOCATING 3	1	
8	2GH-24186-00-00	WASHER, SPECIAL	1	
9	90387-06553-00	COLLAR	2	
10	97007-06025-00	BOLT	2	
11	92907-06100-00	WASHER, SPRING	2	
12	95817-06075-00	BOLT, FLANGE	1	
13	33M-24182-01-00	DAMPER, LOCATING 2	1	
14	3Y6-24183-00-00	DAMPER, LOCATING 3	1	
15	4FM-24187-00-00	WASHER, SPECIAL	1	
16	95807-08035-00	BOLT, FLANGE	1	
17	4JH-24183-00-00	DAMPER, LOCATING 3	2	
18	3FV-24500-01-00	FUEL COCK ASSEMBLY 1 . . .	1	
19	4X8-24512-00-00	. O-RING	1	
20	90149-06008-00	SCREW	2	
21	90202-05187-00	WASHER, PLATE	2	
22	4FM-13910-00-00	FUEL PUMP ASSEMBLY	1	
23	4FM-2414G-00-00	SEAL	1	
24	98507-05016-00	SCREW, PAN HEAD	6	
25	92907-05100-00	WASHER, SPRING	6	
26	92907-05600-00	WASHER, PLATE	6	
27	4HN-24602-00-00	CAP ASSEMBLY	1	

CONTINUED ON NEXT FRAME ➤


FUEL TANK



4NA110-5280


Ref. No.	Part Number	Description	Qty	Remarks
28	90110-05112-00	BOLT, HEXAGON SOCKET HEAD	3	
29	91317-05010-00	BOLT	1	
30	90445-107H3-00	HOSE	1	
31	90467-09006-00	CLIP	1	

FUEL TANK 2



4NC110-5290


Ref. No.	Part Number	Description	Qty	Remarks
1	90467-10008-00	CLIP	7	
2	90445-11763-00	HOSE	1	
3	25H-24180-00-00	ROLL OVER VALVE ASSEMBLY	1	
4	90461-15100-00	CLAMP	1	
5	98507-05010-00	SCREW, PAN HEAD	1	
6	3LK-24311-00-00	PIPE, FUEL 1	1	
7	3LK-24170-00-00	CANISTER ASSEMBLY	1	
8	4NC-14413-01-00	STAY	1	
9	90387-060G7-00	COLLAR	2	
10	90480-13018-00	GROMMET	2	
11	90110-06200-00	BOLT, HEXAGON SOCKET HEAD	2	
12	4NC-24313-00-00	PIPE 3	1	
13	90445-10141-00	HOSE	1	



SEAT

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-24710-00-00	SINGLE SEAT ASSEMBLY ...	1	
2	4JH-24711-00-00	. COVER, SINGLE SEAT	1	
3	278-27114-00-00	. STOPPER, MAIN STAND	4	
4	4FM-24780-00-00	SEAT LOCK ASSEMBLY	1	
5	95807-06016-00	BOLT, FLANGE	2	
6	88T-77198-00-00	DAMPER 1	1	
7	4FM-24750-00-00	TANDEM SEAT ASSEMBLY ...	1	
8	4FM-24751-00-00	. COVER, TANDEM SEAT	1	
9	509-24724-00-00	. DAMPER, SEAT	2	
10	4BP-24780-00-00	SEAT LOCK ASSEMBLY	1	
11	4BP-24792-00-00	PLATE	1	
12	95707-06500-00	NUT, FLANGE	2	
13	4FM-2478E-00-00	CABLE, SEAT LOCK	1	
14	3CK-W2470-00-00	SEAT LOCK ASSEMBLY	1	
15	4FM-2117K-00-00	STAY, LOCK	1	
16	90149-06308-00	SCREW	2	
17	4FM-Y2479-30-P3	COVER, SEAT	1	DARK BLUE COCKTAIL 2
18	4FM-2478M-10-00	. GRAPHIC, SEAT	1	
19	4FM-24786-10-00	. EMBLEM	2	
20	4FM-2475J-00-00	BRACKET, SEAT LEVER 2 ...	1	
21	4FM-2475H-00-00	BRACKET, SEAT LEVER 1 ...	1	


FRONT WHEEL



4JH351-4290

Ref. No.	Part Number	Description	Qty	Remarks
1	3TJ-25168-00-P0	CAST WHEEL, FRONT	1	DEEP REDDISH PURPLE SOLID 1
2	93102-23252-00	OIL SEAL	1	
3	93306-20314-00	BEARING (B6203)	2	
4	90560-17358-00	SPACER	1	
5	341-25149-00-00	CLUTCH, METER	1	
6	341-25846-00-00	RETAINER, CLUTCH	1	
7	93105-45017-00	OIL SEAL	1	
8	94112-1703B-00	TIRE (120/60ZR17 BT50F)	1	BRIDGESTONE
9	93900-00030-00	VALVE, RIM	1	
10	29L-25398-00-00	BALANCER, WHEEL (10G)	1	UR
	29L-25398-10-00	BALANCER, WHEEL (20G)	1	UR
	29L-25398-20-00	BALANCER, WHEEL (30G)	1	UR
11	4HM-25190-00-00	GEAR UNIT ASSEMBLY	1	
12	90387-177V5-00	COLLAR	1	
13	4JH-25181-00-00	AXLE, WHEEL	1	
14	92907-14200-00	WASHER	1	
15	90170-14415-00	NUT	1	


FRONT BRAKE CALIPER



4JH351-4300

Ref. No.	Part Number	Description	Qty	Remarks
1	4HM-2581T-00-00	DISC BRAKE ASSEMBLY	2	
2	90109-08718-00	BOLT	12	
3	3HE-2580T-60-00	CALIPER ASSEMBLY (LEFT) ..	1	
4	3HE-W0057-50-00	. PISTON ASSEMBLY, CALIPER	2	
5	3HE-W0047-50-00	. . CALIPER SEAL KIT	2	
6	3GM-W0045-02-00	. BRAKE PAD KIT	1	
7	3GM-25919-00-00	. SUPPORT, PAD	1	
8	3HE-25924-00-00	. PIN, PAD	2	
9	3GM-25925-00-00	. CLIP	2	
10	1J3-W0048-00-00	. BLEED SCREW KIT	1	
11	1KT-25836-00-00	. COVER, DUST	1	
12	3HE-2580U-60-00	CALIPER ASSEMBLY (RIGHT) .	1	
13	3HE-W0057-50-00	. PISTON ASSEMBLY, CALIPER	2	
14	3HE-W0047-50-00	. . CALIPER SEAL KIT	2	
15	3GM-W0045-02-00	. BRAKE PAD KIT	1	
16	3GM-25919-00-00	. SUPPORT, PAD	1	
17	3HE-25924-00-00	. PIN, PAD	2	
18	3GM-25925-00-00	. CLIP	2	
19	1J3-W0048-00-00	. BLEED SCREW KIT	1	
20	1KT-25836-00-00	. COVER, DUST	1	
21	90105-10638-00	BOLT, WASHER BASED	4	
22	4FM-21596-00-00	HOLDER	1	


REAR WHEEL




Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-25338-00-P0	CAST WHEEL, REAR	1	DEEP REDDISH PURPLE SOLID 1
2	93306-20469-00	BEARING	2	
3	93102-28022-00	OIL SEAL	1	
4	90387-2004F-00	COLLAR	1	
5	4FM-25364-00-00	DAMPER	6	
6	94116-1703F-00	TIRE (160/60ZR17 BT50R)	1	BRIDGESTONE
7	93900-00030-00	VALVE, RIM	1	
8	29L-25398-00-00	BALANCER, WHEEL (10G)	1	UR
	29L-25398-10-00	BALANCER, WHEEL (20G)	1	UR
	29L-25398-20-00	BALANCER, WHEEL (30G)	1	UR
9	4FM-25366-00-00	CLUTCH, HUB	1	
10	93306-20644-00	BEARING	1	
11	93102-40211-00	OIL SEAL	1	
12	90387-2004E-00	COLLAR	1	
13	4JH-25447-00-00	SPROCKET, DRIVEN (47T)	1	
14	90116-10575-00	BOLT, STUD	6	
15	95607-10200-00	NUT, SELF-LOCKING	6	
16	94581-59108-00	CHAIN (DID50VA7-108LE)	1	
17	3XW-25388-00-00	PULLER, CHAIN 1	2	
18	4JH-22174-00-00	END 1	2	
19	92907-08600-00	WASHER, PLATE	2	
20	95307-08600-00	NUT	4	
21	4JH-25371-00-00	BAR, TENSION	1	
22	90105-08321-00	BOLT, WASHER BASED	2	
23	95707-08500-00	NUT, FLANGE	2	
24	91490-20020-00	PIN, COTTER	2	
25	3GM-25381-A0-00	AXLE, WHEEL	1	
26	95607-18200-00	NUT, SELF-LOCKING	1	

CONTINUED ON NEXT FRAME ➤

REAR WHEEL



Ref. No.	Part Number	Description	Qty	Remarks
27	4JH-25384-01-00	WASHER, WHEEL	1	
28	4JH-25384-10-00	WASHER, WHEEL	1	
29	90387-2004C-00	COLLAR	1	
30	90387-2004D-00	COLLAR	1	




4JH351-4320

REAR BRAKE CALIPER


Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-2582W-00-00	DISC, REAR BRAKE 2	1	
2	90109-081F0-00	BOLT	6	
3	3HE-2580W-10-00	CALIPER ASSEMBLY, REAR 2	1	
4	31A-W0057-00-00	. PISTON ASSEMBLY, CALIPER	1	
5	31A-W0047-00-00	. . CALIPER SEAL KIT	1	
6	1FK-W0046-02-00	. BRAKE PAD KIT 2	1	
7	29L-25919-A0-00	. SUPPORT, PAD	1	
8	3HE-25924-00-00	. PIN, PAD	2	
9	3HE-25925-00-00	. CLIP	2	
10	1J3-W0048-00-00	. BLEED SCREW KIT	2	
11	42H-25836-00-00	. COVER, DUST	1	
12	1FK-25827-00-00	. SHIM, CALIPER	1	
13	1FK-25828-00-00	. SHIM, CALIPER	1	
14	4JH-25819-00-00	BRACKET, CALIPER	1	
15	90105-10638-00	BOLT, WASHER BASED	2	

STEERING HANDLE - CABLE



Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-26121-00-00	BOSS, HANDLEBAR (L.H)	1	
2	4JH-26122-00-00	BOSS, HANDLEBAR (R.H)	1	
3	91317-06020-00	BOLT	4	
4	4JH-26111-00-00	BAR, HANDLE (L.H)	1	
5	4JH-26112-00-00	BAR, HANDLE (R.H)	1	
6	91317-08025-00	BOLT	2	
7	341-23469-00-00	CAP, BOLT	2	
8	91317-06025-00	BOLT	2	
9	10L-23469-00-00	CAP, BOLT	2	
10	36Y-26246-00-00	END, GRIP	2	
11	4FM-26241-00-00	GRIP (LEFT)	1	
12	4JD-26240-00-00	GRIP ASSEMBLY	1	
13	4JH-26302-00-00	THROTTLE CABLE ASSEMBLY	1	
14	3LN-26270-01-00	CABLE CONNECTOR CAP ASSEMBLY	1	
15	98507-05020-00	. SCREW, PAN HEAD	1	
16	98507-05025-00	. SCREW, PAN HEAD	1	
17	4JH-26335-00-00	CABLE, CLUTCH	1	
18	4JH-26331-00-00	CABLE, STARTER 1	1	
19	90179-08316-00	NUT	1	
20	90123-08083-00	BOLT	1	
21	4JH-83940-00-00	STARTER ASSEMBLY	1	
22	1WG-83941-00-00	. LEVER, STARTER	1	
23	90209-10131-00	. WASHER	1	
24	98907-06008-00	. SCREW, BIND	1	
25	95807-06010-00	BOLT, FLANGE	1	

FRONT MASTER CYLINDER




4NC110-5360

Ref. No.	Part Number	Description	Qty	Remarks
1	3GM-W2587-50-00	MASTER CYLINDER SUB ASSEMBLY	1	
2	3GM-W0041-50-00	. CYLINDER KIT, MASTER	1	
3	93210-15620-00	. O-RING	1	
4	2VN-25866-00-00	. CIRCLIP	1	
5	3FV-2589A-00-00	. COVER, DUST	1	
6	56A-25867-00-00	BRACKET, MASTER CYLINDER	1	
7	97016-06025-00	BOLT	2	
8	92906-06600-00	WASHER	2	
9	3TJ-83922-00-00	LEVER 2	1	
10	3FV-2589F-00-00	BOLT, LEVER	1	
11	95617-06100-00	NUT, U	1	
12	3FV-25894-00-00	TANK, RESERVOIR	1	
13	3GM-25852-50-00	CAP, RESERVOIR	1	
14	3FV-25854-00-00	DIAPHRAGM, RESERVOIR	1	
15	2J2-25855-50-00	BUSH, DIAPHRAGM	1	
16	3FV-83980-00-00	FRONT STOP SWITCH ASSEMBLY	1	
17	98517-04012-00	SCREW, PAN HEAD	1	
18	92990-04100-00	WASHER, SPRING	1	
19	92901-04600-00	WASHER, PLATE	1	
20	3GM-2585F-00-00	HOSE	1	
21	3PA-24356-00-00	CLIP, PIPE 1	2	
22	3FV-2589G-00-00	HOLDER	1	
23	3GM-2589H-00-00	SCREW	1	
24	4JH-26292-00-00	STAY	1	
25	91317-06012-00	BOLT	2	
26	4JH-2134K-00-00	BRACKET, HORN	1	
27	95807-06012-00	BOLT, FLANGE	2	


CONTINUED ON NEXT FRAME ➤

FRONT MASTER CYLINDER



Ref. No.	Part Number	Description	Qty	Remarks
28	4JH-25872-00-00	HOSE, BRAKE 1	1	
29	4JH-25873-00-00	HOSE, BRAKE 2	1	
30	90461-10132-00	CLAMP	2	
31	95807-06012-00	BOLT, FLANGE	2	
32	90401-10160-00	BOLT, UNION	1	
33	90401-10159-00	BOLT, UNION	2	
34	90201-10118-00	WASHER, PLATE	7	
35	4NA-25875-00-00	HOLDER, BRAKE HOSE 1	1	
36	4NA-25876-00-00	HOLDER, BRAKE HOSE 2	1	
37	95807-06012-00	BOLT, FLANGE	2	


STAND - FOOTREST



Ref. No.	Part Number	Description	Qty	Remarks
1	4FM-27311-00-00	STAND, SIDE	1	
2	90109-104E6-00	BOLT	1	
3	90185-10037-00	NUT, SELF-LOCKING	1	
4	90506-18224-00	SPRING, TENSION	1	
5	90506-26225-00	SPRING, TENSION	1	
6	4FM-27315-00-00	LINK, SIDE STAND	1	
7	1TX-27351-00-00	GUIDE, SIDE STAND	1	
8	4JH-27410-00-00	FRONT FOOTREST ASSEMBLY (LEFT)	1	
9	3YX-27413-00-00	. COVER, FOOTREST	1	
10	90159-05122-00	. SCREW, WITH WASHER	2	
11	3HE-27435-00-00	. BOLT	1	
12	4JH-27420-00-00	FRONT FOOTREST ASSEMBLY (RIGHT)	1	
13	3YX-27413-00-00	. COVER, FOOTREST	1	
14	90159-05122-00	. SCREW, WITH WASHER	2	
15	3HE-27435-00-00	. BOLT	1	
16	4FM-27442-00-00	BRACKET 2	1	
17	4FM-27443-00-00	BRACKET 3	1	
18	4BP-27434-01-00	BOLT	1	
19	90201-08326-00	WASHER, PLATE	1	
20	90201-127J6-00	WASHER, PLATE	1	
21	90179-10247-00	NUT	2	
22	90506-20377-00	SPRING, TENSION	1	
23	90446-17346-00	HOSE	1	
24	91317-08025-00	BOLT	4	
25	3XV-27431-00-00	FOOTREST, REAR 1	1	
26	3XV-27441-10-00	FOOTREST, REAR 2	1	
27	90501-12743-00	SPRING, COMPRESSION	2	


CONTINUED ON NEXT FRAME ➤

STAND - FOOTREST



Ref. No.	Part Number	Description	Qty	Remarks
28	93501-04011-00	BALL	2	
29	1HX-27437-00-00	WASHER, SPECIAL	4	
30	90387-064H8-00	COLLAR	2	
31	91317-06045-00	BOLT	2	
32	95607-06100-00	NUT, U	2	
33	1HX-27415-00-00	PLATE, FOOTREST	2	
34	4JH-2741L-01-00	BRACKET 4	1	
35	4JH-2742L-01-00	BRACKET 5	1	
36	95817-08035-00	BOLT, FLANGE	2	

REAR MASTER CYLINDER




4JH351-4360

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-27211-00-00	PEDAL, BRAKE	1	
2	22N-18113-00-00	COVER, SHIFT PEDAL	1	
3	3YF-27261-00-00	SHAFT	1	
4	90201-104R2-00	WASHER, PLATE	1	
5	90206-14086-00	WASHER, WAVE	1	
6	4BH-2583V-00-00	RR. MASTER CYLINDER ASSEMBLY.	1	
7	4BH-W0042-50-00	. CYLINDER KIT, MASTER	1	
8	3LN-2585G-00-00	. . CIRCLIP	1	
9	4BP-2582A-00-00	. JOINT	1	
10	4BP-2585F-00-00	. BUSH	1	
11	47X-27222-00-00	JOINT	1	
12	95307-08700-00	NUT	1	
13	92017-08020-00	BOLT, BUTTON HEAD	2	
14	90240-08124-00	PIN, CLEVIS	1	
15	90201-08083-00	WASHER, PLATE	1	
16	91490-20020-00	PIN, COTTER	1	
17	4FM-2144G-00-00	STAY, STOP SWITCH	1	
18	98507-06010-00	SCREW, PAN HEAD	1	
19	31A-25894-01-00	TANK, RESERVOIR	1	
20	360-25854-00-00	DIAPHRAGM, RESERVOIR	1	
21	2GU-25855-00-00	BUSH, DIAPHRAGM	1	
22	2KF-25852-50-00	CAP, RESERVOIR	1	
23	3PJ-25888-00-00	COVER, RESERVOIR TANK	1	
24	98507-06020-00	SCREW, PAN HEAD	1	
25	92907-06100-00	WASHER, SPRING	1	
26	4FM-2133G-00-00	BRACKET, RESERVER	1	
27	95807-06016-00	BOLT, FLANGE	1	
28	4JH-25895-00-00	HOSE, RESERVOIR	1	

CONTINUED ON NEXT FRAME ➤


REAR MASTER CYLINDER



4JH351-4360

Ref. No.	Part Number	Description	Qty	Remarks
29	90467-14057-00	CLIP	2	
30	4JH-25874-01-00	HOSE, BRAKE	1	
31	90461-08031-00	CLAMP	1	
32	95807-06012-00	BOLT, FLANGE	1	
33	90401-10159-00	BOLT, UNION	1	
34	90201-10118-00	WASHER, PLATE	3	
35	3LC-25885-00-00	JOINT	1	

COWLING 1




FWD

4NA110-5380

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-28381-00-00	WINDSHIELD	1	
2	90150-05023-00	SCREW, ROUND HEAD	2	
3	90179-05523-00	NUT	2	
4	90149-05273-00	SCREW	4	
5	4FM-28215-00-00	WASHER, SPECIAL	4	
6	95707-05500-00	NUT, FLANGE	4	
7	4JH-Y2835-30-P1	COWLING ASS''Y	1	DARK BLUE COCKTAIL 2
8	89X-77167-00-00	. TRIM 3	2	
9	3MA-21649-00-00	. DAMPER	2	
10	90183-05024-00	. NUT, SPRING	6	
11	4NA-28390-01-00	. GRAPHIC SET, COWLING	1	
12	4JH-28356-00-00	STAY 1	1	
13	51L-28371-00-00	DAMPER	1	
14	95607-08200-00	NUT, SELF-LOCKING	2	
15	90154-05059-00	SCREW, BINDING	6	
16	95807-06030-00	BOLT, FLANGE	4	
17	95607-06200-00	NUT, SELF U-FLANGE	4	
18	90480-14229-00	GROMMET	4	
19	90387-07391-00	COLLAR	4	
20	4FM-26280-10-00	REAR VIEW MIRROR ASSEMBLY (LEFT)	1	BLACK
21	4FM-26290-10-00	REAR VIEW MIRROR ASSEMBLY (RIGHT)	1	BLACK
22	4JH-2831W-00-00	STAY, MIRROR 1	1	
23	90480-13398-00	GROMMET	2	
24	90387-067N5-00	COLLAR	2	
25	95027-06016-00	BOLT, FLANGE	2	
26	4JH-2832W-00-00	STAY, MIRROR 2	1	
27	95027-06012-00	BOLT, FLANGE	2	

CONTINUED ON NEXT FRAME ➤

COWLING 1




FWD

4NA110-5380

Ref. No.	Part Number	Description	Qty	Remarks
28	4FM-26299-00-00	PLATE, MIRROR FITTING 2	2	
29	3XV-26298-00-00	PLATE, MIRROR FITTING 1	2	
30	98707-06025-00	SCREW, FLAT HEAD	4	
31	90176-06055-00	NUT, CROWN	4	

COWLING 2




4NC110-5400

Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-Y283U-20-P0	PANEL ASSEMBLY 1	1	DARK BLUE COCKTAIL 2
2	90480-13398-00	. GROMMET	4	
3	4JH-2172A-00-00	. PANEL 1	1	
4	90183-03010-00	. NUT, SPRING	4	
5	90183-05024-00	. NUT, SPRING	3	
6	4NA-28301-00-00	. GRAPHIC SET, LOWER COVER 1	1	
7	4JH-Y283V-20-P0	PANEL ASSEMBLY 2	1	DARK BLUE COCKTAIL 2
8	90480-13398-00	. GROMMET	4	
9	4JH-2172F-00-00	. PANEL 2	1	
10	90183-03010-00	. NUT, SPRING	4	
11	90183-05024-00	. NUT, SPRING	3	
12	4NA-28303-01-00	. GRAPHIC SET, LOWER COVER 2	1	
13	4JH-2832U-00-00	STAY, SIDE 1	1	
14	95807-06010-00	BOLT, FLANGE	5	
15	4JH-2836H-00-00	BRACKET 5	1	
16	1HX-24188-01-00	MOLD, FUEL TANK	1	
17	4JH-2836J-00-00	BRACKET 6	1	
18	90150-06036-00	SCREW, ROUND HEAD	4	
19	3FV-28365-00-00	COVER	1	
20	4JH-2836K-00-P1	PANEL, INNER 1	1	DARK BLUE COCKTAIL 2
21	1A8-21518-00-00	HOLDER, CABLE	1	
22	4JH-Y2808-30-P2	COVER ASSEMBLY, UNDER	1	VERY DARK VIOLET COCKTAIL 1
23	90480-13398-00	. GROMMET	3	
24	90183-05024-00	. NUT, SPRING	2	
25	4NA-28304-00-00	. GRAPHICSET, LOWER COVER 3	1	

CONTINUED ON NEXT FRAME ➤


COWLING 2



4NC110-5400

Ref. No.	Part Number	Description	Qty	Remarks
26	90150-06036-00	SCREW, ROUND HEAD	2	
27	90154-05059-00	SCREW, BINDING	8	
28	4JH-28396-00-00	PLATE 1	1	
29	4JH-28397-00-00	PLATE 2	1	
30	4DN-21669-00-00	SEAL	4	
31	90269-07036-00	RIVET	4	
32	4JH-2836F-00-00	BRACKET 3	1	
33	4JH-2836G-00-00	BRACKET 4	1	
34	90480-12320-00	GROMMET	2	
35	4JH-2831T-00-00	STAY, SUPPORT 1	1	
36	95807-06010-00	BOLT, FLANGE	1	

GENERATOR




Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-81450-00-00	ROTOR ASSEMBLY	1	
2	4JH-81410-00-00	STATOR ASSEMBLY	1	
3	91317-06035-00	BOLT	3	
4	98507-05016-00	SCREW, PAN HEAD	2	
5	92907-05100-00	WASHER, SPRING	2	
6	90201-05027-00	WASHER, PLATE	2	
7	90280-03047-00	KEY, WOODRUFF	1	
8	90105-10430-00	BOLT, WASHER BASED	1	
9	90201-107K6-00	WASHER, PLATE	1	



4JH351-4390


STARTING MOTOR



3HE332-9400

Ref. No.	Part Number	Description	Qty	Remarks
1	3HW-81800-00-00	STARTING MOTOR ASSEMBLY	1	
2	3HE-81840-00-00	. BRUSH HOLDER ASSEMBLY	1	
3	1HX-81815-00-00	. CORD, STARTER MOTOR . . .	1	
4	3HE-81850-00-00	. ARMATURE ASSEMBLY	1	
5	3AJ-81809-00-00	. WASHER KIT	1	
6	3HE-81830-00-00	. FRONT BRACKET ASSEMBLY	1	
7	3HE-81826-00-00	. BOLT	1	
8	5H0-81871-00-00	. CAP	1	
9	11H-81844-00-00	. GASKET	2	
10	26H-81847-00-00	. O-RING	1	
11	95027-06025-00	BOLT, FLANGE	2	


FLASHER LIGHT - TURNSIGNAL



4NA110-5420


Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-83310-10-00	FRONT FLASHER LIGHT ASSEMBLY 1	1	
2	256-84714-61-00	. BULB (12V-27/8W)	1	
3	4JH-83332-10-00	. LENS, FLASHER	1	
4	97702-40610-00	. SCREW, TAPPING	1	
5	4JH-83320-10-00	FRONT FLASHER LIGHT ASSEMBLY 2	1	
6	256-84714-61-00	. BULB (12V-27/8W)	1	
7	4JH-83342-10-00	. LENS, FLASHER 2	1	
8	97702-40610-00	. SCREW, TAPPING	1	
9	4JH-83318-00-00	STAY, FLASHER 1	2	
10	98507-04008-00	SCREW, PAN HEAD	2	
11	92907-04600-00	WASHER	2	
12	4JH-83330-20-00	REAR FLASHER LIGHT ASSEMBLY 1	1	
13	256-83311-70-XX	. BULB, TS 12V27W	1	
14	4JH-83332-10-00	. LENS, FLASHER	1	
15	97702-40610-00	. SCREW, TAPPING	1	
16	4JH-83340-20-00	FLASHER LIGHT ASSEMBLY 2	1	
17	256-83311-70-XX	. BULB, TS 12V27W	1	
18	4JH-83342-10-00	. LENS, FLASHER 2	1	
19	97702-40610-00	. SCREW, TAPPING	1	
20	4FM-83345-00-00	PLUG, BLIND	2	
21	4FM-83369-00-00	STAY, FLASHER 2	2	
22	95707-06500-00	NUT, FLANGE	2	

METER



Ref. No.	Part Number	Description	Qty	Remarks
1	4FM-83570-10-00	SPEEDOMETER ASSEMBLY	1	
2	4FM-83540-00-00	TACHOMETER ASSEMBLY	1	
3	4FM-83590-00-00	WATER TEMPERATURE ASSEMBLY	1	
4	4FM-83559-00-00	COVER, METER	1	
5	4FM-8353H-50-00	CASE, UNDER	1	
6	2GH-83578-00-00	KNOB, TRIP METER	1	
7	4FM-83509-00-00	SOCKET CORD ASSEMBLY	1	
8	4G1-84744-00-00	BULB, MTR.12V3.4W	5	
9	2GV-83517-00-00	BULB (12V-1.7W, T6.5)	4	
10	98580-04010-00	SCREW, PAN HEAD	4	
11	92990-04100-00	WASHER, SPRING	4	
12	92901-04600-00	WASHER, PLATE	4	
13	97902-04122-00	SCREW, WITH WASHER	2	
14	98580-03010-00	SCREW, PAN HEAD (98502-03010)	3	
15	92990-03100-00	WASHER, SPRING (92901-03100)	3	
16	90159-03102-00	SCREW, WITH WASHER	3	
17	90164-04023-00	SCREW, TAPPING	5	
18	4FM-83520-00-00	SOCKET CORD ASSEMBLY	1	
19	90480-14585-00	GROMMET	2	
20	90201-06059-00	WASHER, PLATE	2	
21	95307-06600-00	NUT	2	
22	3GM-87278-A0-00	COVER, METER	1	
23	97707-40012-00	SCREW, TAPPING	1	
24	4JH-83550-00-00	SPEEDOMETER CABLE ASSEMBLY	1	


HEADLIGHT



4NA110-5450


Ref. No.	Part Number	Description	Qty	Remarks
1	4FM-84330-41-00	BODY ASSEMBLY	1	
2	4FM-84320-40-00	LENS ASSEMBLY	1	
3	4FM-8432A-40-00	LENS ASSEMBLY	1	
4	1ML-84314-00-XX	BULB (12V-35/35W) (1FM-84314-H0-00)	2	HALOGEN
5	4JG-84397-00-00	COVER, SOCKET	2	
6	51L-84334-00-00	NUT, ADJUSTING	4	
7	90338-24112-00	PLUG, SPEC''L SHAPE	1	
8	3LK-84378-00-P4	CAP	1	VERY DARK VIOLET COCKTAIL 1
9	90167-05041-00	SCREW, TAPPING	2	
10	4NA-84359-00-00	CORD, HEADLIGHT	1	
11	90464-13133-00	CLAMP	1	
12	90464-16021-00	CLAMP	1	
13	90464-13073-00	CLAMP	3	

TAILLIGHT




4HA700-3480

Ref. No.	Part Number	Description	Qty	Remarks
1	4FM-84710-10-00	TAILLIGHT UNIT ASSEMBLY . .	1	
2	31L-84714-00-00	. BULB, TAILLIGHT (12V-21/5W)	2	
3	4FM-84735-00-00	. CORD ASSEMBLY	1	
4	90179-05523-00	NUT	4	
5	92907-05600-00	WASHER, PLATE	4	
6	90110-05112-00	BOLT, HEXAGON SOCKET HEAD	4	
7	4FM-84745-10-00	LICENCE LIGHT UNIT ASSEMBLY	1	
8	4FM-84749-10-00	. BODY, LICENCE LIGHT	1	
9	3F9-84744-00-XX	. BULB, METER 12V3.8W	2	
10	4FM-84742-00-00	SEAT, BASE	1	
11	3F9-84553-00-00	DAMPER	2	
12	90201-05033-00	WASHER, PLATE	2	
13	90387-0601Y-00	COLLAR	2	
14	95707-05500-00	NUT, FLANGE	2	
15	4FM-84751-00-00	BRACKET, LICENSE	1	
16	95027-06016-00	BOLT, FLANGE	2	
17	90201-06059-00	WASHER, PLATE	2	
18	95607-06100-00	NUT, U	2	
19	99237-00080-00	EMBLEM, YAMAHA	1	




HANDLE SWITCH - LEVER

Ref. No.	Part Number	Description	Qty	Remarks
1	4DU-83973-00-00	SWITCH, HANDLE 3	1	
2	98506-05030-00	. SCREW, PAN HEAD	1	
3	98506-05040-00	. SCREW, PAN HEAD	1	
4	4FM-83975-00-00	SWITCH, HANDLE 2	1	
5	98506-05018-00	. SCREW, PAN HEAD	2	
6	29L-82911-01-00	HOLDER, LEVER 1	1	
7	3LN-83912-00-00	LEVER 1	1	
8	31A-83913-00-00	COLLAR, LEVER 1	1	
9	31A-82917-00-00	SWITCH	1	
10	31A-83945-00-00	BOLT, LEVER	1	
11	98707-03008-00	SCREW, FLAT HEAD	1	
12	95607-06100-00	NUT, U	1	
13	97007-06025-00	BOLT	1	
14	92907-06100-00	WASHER, SPRING	1	
15	90338-09012-00	PLUG	1	



4JH351-4450


ELECTRICAL 1



4JH300-4470


Ref. No.	Part Number	Description	Qty	Remarks
1	4JH-82310-00-00	IGNITION COIL ASSEMBLY	1	
2	4JH-82320-00-00	IGNITION COIL ASSEMBLY	1	
3	1WG-82370-00-00	PLUG CAP ASSEMBLY	4	
4	1AE-82540-00-00	NEUTRAL SWITCH ASSEMBLY	1	
5	93210-29196-00	O-RING	1	
6	98507-06016-00	SCREW, PAN HEAD	2	
7	11H-83591-00-00	THERMO UNIT	1	
8	3TJ-82583-00-00	WIRE, SUB LEAD	1	
9	4JH-85720-00-00	OIL LEVEL GAUGE ASSEMBLY	1	
10	95027-06016-00	BOLT, FLANGE	2	
11	4JH-82305-40-00	IGNITOR UNIT ASSEMBLY	1	
12	97707-60016-00	SCREW, TAPPING	2	
13	90338-08226-00	PLUG	2	
14	2EL-82560-00-00	THERMO SWITCH ASSEMBLY	1	
15	1WG-82541-00-00	WIRE, LEAD	1	
16	3GM-83350-00-00	FLASHER RELAY ASSEMBLY	1	
17	34Y-83371-00-00	HORN	1	
18	95807-06010-00	BOLT, FLANGE	1	
19	11H-85110-01-00	REFLECTOR ASSEMBLY	2	
20	95707-05500-00	NUT, FLANGE	2	

ELECTRICAL 2



Ref. No.	Part Number	Description	Qty	Remarks
1	4DN-81940-00-00	STARTER RELAY ASSEMBLY .	1	
2	95027-06008-00	BOLT, FLANGE	2	
3	BTY-YTX12-BS-00	BATTERY ASSEMBLY (YTX12-BS)	1	
4	4BP-82131-00-00	BAND, BATTERY	1	
5	4JH-82115-00-00	WIRE, PLUS LEAD	1	
6	4JH-82116-00-00	WIRE, MINUS LEAD	1	
7	1KT-82530-02-00	STOP SWITCH ASSEMBLY . . .	1	
8	4NA-82590-01-00	WIRE HARNESS ASSEMBLY . .	1	
9	2GH-82151-00-00	. FUSE (20A-BL)	2	
10	2KW-82151-00-00	. FUSE (7.5A-BL)	3	
11	36Y-82151-00-00	. FUSE (15A-BL)	1	
12	4JH-81960-00-00	RECTIFIER & REGULATOR ASSEMBLY	1	
13	95807-06020-00	BOLT, FLANGE	2	
14	4NA-82501-01-00	MAIN SWITCH STEERING LOCK	1	
15	90109-080G5-00	BOLT	2	
16	3TJ-83964-10-00	SWITCH	1	
17	98780-05016-00	SCREW, FLAT HEAD	2	
18	95707-05500-00	NUT, FLANGE	2	
19	1UA-82591-00-00	BAND	2	
20	90464-13073-00	CLAMP	2	
21	90464-12089-00	CLAMP	5	
22	90464-10190-00	CLAMP	2	
23	90464-15192-00	CLAMP	1	
24	90464-15195-00	CLAMP	3	
25	3EN-81950-00-00	RELAY ASSEMBLY	1	
26	3LD-82566-50-00	SWITCH, SIDE STAND	1	
27	90157-05079-00	SCREW, PAN HEAD	2	

CONTINUED ON NEXT FRAME ➤



ELECTRICAL 2

Ref. No.	Part Number	Description	Qty	Remarks
28	90464-07121-00	CLAMP	2	
29	90464-08211-00	CLAMP	2	
30	25G-83936-01-00	BAND, SWITCH CORD	1	