




Ref No	Part No	Description
01	3VD-11101-20-00	Cylinder Head Assy
02	3LD-11133-L0-00	• . Guide, Valve 1
03	3LD-11134-10-00	• . Guide, Valve 2
04	93440-10109-00	• . Circlip
05	99510-08016-00	• . Pin, Dowel
06	90340-18101-00	• . Plug, Straight Screw
07	91005-06153-00	• . Bolt, Flange
08	90116-08321-00	• . Bolt, Stud
09	90338-10150-00	• . Plug
10	94701-00361-00	Plug, Spark
11	90201-103M4-00	Washer, Plate
12	90179-10414-00	Nut
13	91317-06150-00	Bolt
14	95027-08012-00	Bolt, Flange
15	90430-08143-00	Gasket
16	3VD-11181-01-00	Gasket, Cylinder Head 1
17	3VD-Y1119-40-00	Cover Assy, Cylinder Head
18	3LD-11193-01-00	• . Gasket, Head Cover 1
19	3LD-11160-02-00	• . Breather Assy
20	98507-04006-00	• . Screw, Pan Head
21	92907-04100-00	• . Washer, Spring
22	90109-064F0-00	Bolt
23	90109-062G1-00	Bolt
24	90109-062G2-00	Bolt
25	90209-11262-00	Washer
26	2GH-1111G-00-00	Rubber, Mount 1

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-11310-10-00	Cylinder
02	93210-90785-00	O-ring
03	3VD-11351-00-00	Gasket, Cylinder
04	99530-14016-00	Pin, Dowel
05	90153-06029-00	Screw, Hexagon
06	90430-06104-00	Gasket

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-11400-02-00	Crankshaft Assy
02	3LD-11416-00-00	Plane Bearing, Crankshaft 1
02	3LD-11416-10-00	Plane Bearing, Crankshaft 1
02	3LD-11416-20-00	Plane Bearing, Crankshaft 1
02	3LD-11416-30-00	Plane Bearing, Crankshaft 1
02	3LD-11416-40-00	Plane Bearing, Crankshaft 1
02	3LD-11416-50-00	Plane Bearing, Crankshaft 1
02	3LD-11416-60-00	Plane Bearing, Crankshaft 1
03	3VD-11631-00-00	Piston (std)
03	3VD-11636-00-00	Piston (0.50mm O/s)
03	3VD-11638-00-00	Piston (1.00mm O/s)
04	3VD-11610-00-00	Piston Ring Set
04	3VD-11610-20-00	Piston Ring Set
04	3VD-11610-40-00	Piston Ring Set
05	3LD-11633-00-00	Pin, Piston
06	93450-22027-00	Circlip
07	3VD-11650-00-00	Connecting Rod Assy
08	3LD-11654-00-00	• . Bolt, Connecting Rod
09	90179-09379-00	• . Nut
10	3LD-11656-00-00	Plane Bearing, Connecting Rod
10	3LD-11656-10-00	Plane Bearing, Connecting Rod
10	3LD-11656-20-00	Plane Bearing, Connecting Rod
10	3LD-11656-30-00	Plane Bearing, Connecting Rod
11	3LD-11500-00-00	Balancer Assy
12	3VD-11510-00-00	Balancer Assy, 2
13	3LD-11583-00-00	Shaft, Balancer 1
14	3LD-11584-00-00	Shaft, Balancer 2
15	93210-30660-00	O-ring
16	90280-05029-00	Key, Woodruff
17	90105-12584-00	Bolt, Washer Based
18	90201-121H0-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3LD-12111-00-00	Valve, Intake
02	3LD-12121-00-00	Valve, Exhaust
03	3LD-12121-00-00	Valve, Exhaust
04	1WG-12116-00-00	Seat, Valve Spring
05	3LD-12113-00-00	Spring, Valve Inner
06	3LD-12117-00-00	Retainer, Valve Spring
07	3LD-12118-00-00	Cotter, Valve
08	51Y-12119-00-00	Seal, Valve Stem
09	1WG-12153-09-00	Lifter, Valve
09	1WG-12153-21-00	Lifter, Valve
09	1WG-12153-31-00	Lifter, Valve
10	3LD-12169-L0-00	Pad, Adjusting
10	3LD-12169-N0-00	Pad, Adjusting
10	3LD-12169-T0-00	Pad, Adjusting
10	3LD-12168-00-00	Pad, Adjusting
10	3LD-12168-20-00	Pad, Adjusting
10	3LD-12168-40-00	Pad, Adjusting
10	3LD-12168-60-00	Pad, Adjusting
10	3LD-12168-80-00	Pad, Adjusting
10	3LD-12168-A0-00	Pad, Adjusting
10	3LD-12168-F0-00	Pad, Adjusting
10	3LD-12168-H1-00	Pad, Adjusting
10	3LD-12168-K1-00	Pad, Adjusting
10	3LD-12168-M1-00	Pad, Adjusting
10	3LD-12168-R1-00	Pad, Adjusting
10	3LD-12168-U1-00	Pad, Adjusting
10	3LD-12168-W1-00	Pad, Adjusting
10	3LD-12168-Y1-00	Pad, Adjusting
10	3LD-12169-11-00	Pad, Adjusting
10	3LD-12169-31-00	Pad, Adjusting
10	3LD-12169-50-00	Pad, Adjusting
10	3LD-12169-70-00	Pad, Adjusting
10	3LD-12169-90-00	Pad, Adjusting
10	3LD-12169-E0-00	Pad, Adjusting
10	3LD-12169-G0-00	Pad, Adjusting
10	3LD-12169-J0-00	Pad, Adjusting

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3LD-12171-00-00	Camshaft 1
02	3LD-12181-00-00	Camshaft 2
03	3LD-12176-00-00	Sprocket, Cam Chain
04	90105-07342-00	Bolt, Washer Based
05	94591-40138-00	Chain
06	3LD-12241-00-00	Guide, Stopper 2
07	3LD-12210-00-00	Tensioner Assy, Cam Chain
08	3VD-12213-00-00	Gasket, Tensioner Case
09	91317-06025-00	Bolt
10	3LD-12251-00-00	Damper, Chain 1
11	3LD-12252-00-00	Damper, Chain 2
12	3LD-12247-00-00	Shaft, Tensioner

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-12420-10-00	Water Pump Assy
02	3LD-12439-00-00	• . O-ring
03	99009-12400-00	• . Circlip
04	95027-06012-00	• . Bolt, Flange
05	90430-06104-00	• . Gasket
06	3VD-12459-00-00	Gear, Impeller Shaft
07	90201-127E1-00	Washer, Plate
08	95027-06030-00	Bolt, Flange
09	95027-06045-00	Bolt, Flange
10	95027-06060-00	Bolt, Flange
11	93210-33133-00	O-ring
12	3LD-12481-00-00	Pipe 1
13	93210-21190-00	O-ring
14	93210-36788-00	O-ring
15	3LD-12469-00-00	Joint 1
16	95027-06106-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-12461-00-00	Radiator Assy
02	1UF-12405-00-00	Blower Assy
03	1UF-12611-00-00	• . Fan
04	26H-12630-00-00	• . Motor Assy
05	98507-05008-00	• . Screw, Pan Head
06	92901-05600-00	• . Washer, Plate
07	26H-12462-00-00	Cap, Radiator
08	1AA-12561-00-00	Plug,drain Cock
09	1AA-12435-00-00	Gasket
10	1AA-12535-00-00	Plate
11	3VD-12465-00-00	Damper, Radiator
12	3VD-12578-00-00	Hose 3
13	90450-38040-00	Hose Clamp Assy
14	1UF-12467-00-00	Cover, Radiator
15	1UF-12435-00-00	Gasket
16	90183-05024-00	Nut, Spring
17	98507-05100-00	Screw, Pan Head
18	92907-05100-00	Washer, Spring
19	92907-05600-00	Washer, Plate
20	90480-15363-00	Grommet
21	90387-07392-00	Collar
22	95807-06025-00	Bolt, Flange
23	90201-063J2-00	Washer, Plate
24	90480-18276-00	Grommet
25	90387-07037-00	Collar
26	3VD-12482-10-00	Pipe 2
27	93210-18417-00	O-ring
28	91317-06016-00	Bolt
29	3VD-12577-00-00	Hose 2
30	3VD-12567-00-00	Cap, Water
31	90450-32051-00	Hose Clamp Assy
32	1AE-12410-00-00	Thermostat Assy
33	1UF-12417-01-00	Housing, Thermostat
34	1UF-12413-00-00	Cover, Thermostat
35	93210-49046-00	O-ring
36	95027-06020-00	Bolt, Flange
37	95027-06030-00	Bolt, Flange
38	3VD-1244E-00-00	Bracket 1
39	95027-06010-00	Bolt, Flange
40	3VD-12579-00-00	Hose 4

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3LD-13300-00-00	Oil Pump Assy
02	99510-08012-00	Pin, Dowel
03	3LD-13329-00-00	Gasket, Pump Cover
04	98507-06045-00	Screw, Pan Head
05	90430-14131-00	Gasket
06	90387-120W5-00	Collar
07	3LD-13303-00-00	Oil Pump Assy, 2
08	3LD-13371-00-00	• . Plate
09	3LD-13339-00-00	Gasket, Pump Cover
10	98507-06035-00	Screw, Pan Head
11	3VD-13325-00-00	Gear, Pump Driven
12	99009-11400-00	Circlip
13	3VD-13412-00-00	Housing, Strainer
14	95027-06025-00	Bolt, Flange
15	95027-06020-00	Bolt, Flange
16	3VD-13411-00-00	Strainer, Oil
17	98507-06010-00	Screw, Pan Head
18	4X7-13440-90-00	Element Assy, Oil Cleaner
19	3VD-13447-00-00	Cover, Oil Element
20	93210-64297-00	O-ring
21	95027-06020-00	Bolt, Flange
22	95027-06030-00	Bolt, Flange
23	95027-06040-00	Bolt, Flange
24	3LD-13161-00-00	Pipe, Delivery 1
25	90401-10106-00	Bolt, Union
26	90430-10171-00	Gasket
27	3VD-13417-00-00	Cover, Strainer
28	3LD-13113-00-00	Seat, Check Ball
29	93505-08030-00	Ball
30	90501-104F9-00	Spring, Compression
31	90387-106W6-00	Collar
32	93210-12790-00	O-ring
33	11H-13490-00-00	Relief Valve Assy
34	93210-10096-00	O-ring
35	3LD-13151-00-00	Stay
36	90105-06553-00	Bolt, Washer Based
37	99510-08016-00	Pin, Dowel
38	4H7-15138-00-00	Nozzle 1
39	3VD-13414-00-00	Gasket, Strainer Cover
40	90105-06456-00	Bolt, Washer Based
41	95027-06025-00	Bolt, Flange
42	95027-10040-00	Bolt, Flange
43	90430-10171-00	Gasket
44	95027-06035-00	Bolt, Flange
45	3VD-13455-00-00	Plug
46	214-11198-01-00	Gasket
47	3VD-13464-10-00	Hose, Oil 1
48	3VD-13465-00-00	Hose, Oil 2
49	3VD-13416-00-00	Pipe, Oil 1
50	93210-13657-00	O-ring
51	91317-06020-00	Bolt
52	90110-06093-00	Bolt, Hexagon Socket Head
53	90460-27270-00	Clamp, Hose
54	3VD-13317-00-00	Plate, Baffle

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
55	91005-06553-00	Bolt, Flange
56	3VD-13415-00-00	Seal, Oil Strainer

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3LD-13586-01-00	Joint, Carburetor 1
02	3LD-13597-00-00	Joint, Carburetor 3
03	90445-090E5-00	Hose
04	90467-08017-00	Clip
05	90467-08021-00	Clip
06	90338-05194-00	Plug
07	93210-44545-00	O-ring
08	91317-06020-00	Bolt
09	90465-20035-00	Clamp
10	90450-57034-00	Hose Clamp Assy
11	3VD-14411-00-00	Case, Air Cleaner 1
12	3VD-14421-00-00	Case, Air Cleaner 2
13	1VJ-14462-00-00	Seal
14	97707-50125-00	Screw, Tapping
15	1AE-14451-00-00	Element, Air Cleaner
16	3VD-14422-00-00	Cap, Cleaner Case 2
17	5T0-14457-00-00	Seal
18	98507-05016-00	Screw, Pan Head
19	92907-05600-00	Washer, Plate
20	3GM-14453-00-00	Joint, Air Cleaner 1
21	3VD-14425-00-00	Damper 1
22	3VD-14426-00-00	Damper 2
23	3VD-1442G-00-00	Damper 3
24	26H-21746-00-00	Damper
25	90480-14023-00	Grommet
26	90387-060M9-00	Collar
27	90450-67066-00	Hose Clamp Assy
28	97007-06030-00	Bolt
29	90201-06M08-00	Washer, Plate
30	3VD-11166-00-00	Pipe, Breather 1
31	90467-22080-00	Clip
32	90467-24113-00	Clip

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-14900-00-00	Carburetor Assy
02	3VD-14901-00-00	• . Carburetor Assy 1
03	3VD-14902-00-00	• . Carburetor Assy 2
04	3FV-14191-00-00	•• .. Plug, Drain
05	98507-05012-00	•• .. Screw, Pan Head
06	3GM-14985-00-00	•• .. Float
07	53L-14186-00-00	•• .. Pin, Float
08	3FV-14147-00-00	•• .. O-ring
09	98507-05016-00	•• .. Screw, Pan Head
10	92906-05100-00	•• .. Washer, Spring
11	92906-05600-00	•• .. Washer, Plate
12	98580-04008-00	•• .. Screw, Pan Head
13	3GM-14940-00-00	•• .. Diaphragm Assy
14	3VD-14933-00-00	•• .. Spring, Diaphragm
15	1AE-14147-00-00	•• .. O-ring
16	3LF-14147-00-00	•• .. O-ring
17	3GM-14153-00-00	•• .. Washer, Main Jet
18	1HX-14565-00-00	•• .. Screw
19	3LD-14147-00-00	•• .. O-ring
20	3GM-14997-00-00	•• .. Seal
21	3GM-1411E-00-00	•• .. Block, Jet
22	3LD-14945-00-00	•• .. Jet
23	97601-04312-00	•• .. Screw, Pan Head With Washer
24	3GM-14107-17-00	•• .. Needle Valve Set
25	3EN-14147-00-00	•• .. O-ring
26	3EN-1410A-00-00	•• .. Starter Set
27	12R-14105-00-00	•• .. Pilot Screw Set
28	3VD-1490J-00-00	•• .. Needle Set
29	3LD-1490H-00-00	•• .. Diaphragm Set 5
30	3VD-1411A-00-00	•• .. Block Jet Assy
31	620-14231-15-00	•• .. Jet, Main
32	239-14172-00-00	•• .. Pilot Jet, Air
33	830-14231-14-00	•• .. Jet, Main
34	4G0-14142-37-A0	•• .. Jet, Pilot
35	3GM-14141-94-00	•• .. Nozzle, Main
36	3LD-14231-00-00	•• .. Jet, Main
37	92901-05600-00	• . Washer, Plate
38	95380-05600-00	• . Nut
39	3LD-14986-00-00	• . Lever, Starter
40	3LD-14919-00-00	• . Clip
41	3EN-14261-00-00	• . Holder
42	3GM-14974-00-00	• . Lever, Connect
43	3LD-14988-00-00	• . Pipe, Starter Connecting
44	95380-06600-00	• . Nut, Hexagon
45	2LH-14197-00-00	• . Pipe
46	8U9-14139-00-00	• . Clip, Pipe
47	3EN-14988-00-00	• . Pipe, Starter Connecting
48	1KT-14994-00-00	• . Net, Filter
49	3EN-14997-00-00	• . Seal
50	822-14147-00-00	• . O-ring
51	3VD-14987-00-00	• . Hose
52	90467-07029-00	• . Clip
53	3JE-14197-00-00	• . Pipe
54	3EN-1490K-00-00	• . Stop Screw Set

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
55	3VD-14103-00-00	• . Throttle Screw Set
56	3VD-14148-01-00	Pipe
57	90467-12052-00	Clip

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-14602-01-00	Exhaust Pipe Comp.
02	92907-06600-00	• . Washer, Plate
03	90101-06576-00	• . Bolt
04	3VD-14613-00-00	Gasket, Exhaust Pipe
05	90179-08345-00	Nut
06	3VD-14710-10-00	Muffler Assy 1
07	3VD-14755-00-00	• . Gasket, Silencer
08	95027-08025-00	• . Bolt, Flange
09	90201-08326-00	Washer, Plate
10	91317-08110-00	Bolt
11	90105-10316-00	Bolt, Washer Based
12	95707-10500-00	Nut, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-15100-20-00	Crankcase Assy
02	4H7-15138-00-00	• . Nozzle 1
03	4G0-15138-00-00	• . Nozzle 1
04	99530-10014-00	• . Pin, Dowel
05	3VD-15316-00-00	• . Damper, Engine Mount 1
06	3VD-15317-00-00	• . Spacer, Engine Mount
07	93210-11313-00	• . O-ring
08	3VD-15199-00-00	Bracket
09	91317-08016-00	Bolt
10	99530-14016-00	Pin, Dowel
11	3LD-11361-00-00	Bolt, Cylinder Holding 1
12	90105-10560-00	Bolt, Washer Based
13	90201-10131-00	Washer, Plate
14	95817-06040-00	Bolt, Flange
15	90201-066F0-00	Washer, Plate
16	95817-06055-00	Bolt, Flange
17	95817-06020-00	Bolt, Flange
18	95817-06030-00	Bolt, Flange
19	95817-08050-00	Bolt, Flange
20	90201-08087-00	Washer, Plate
21	95817-08060-00	Bolt, Flange
22	90201-08087-00	Washer, Plate
23	95817-06070-00	Bolt, Flange
24	95817-08065-00	Bolt, Flange
25	95817-08050-00	Bolt, Flange
26	95817-08070-00	Bolt, Flange
27	95817-08075-00	Bolt, Flange
28	95817-06025-00	Bolt, Flange
29	95817-06040-00	Bolt, Flange
30	90201-066F0-00	Washer, Plate
31	90465-08341-00	Clamp
32	3LD-15191-00-00	Plate
33	90149-06285-00	Screw
34	3LD-15118-00-00	Holder
35	99510-08016-00	Pin, Dowel
36	95817-06045-00	Bolt, Flange
37	95817-06070-00	Bolt, Flange
38	3VD-15416-10-00	Cover, Oil Pump
39	3VD-15456-00-00	Gasket, Oil Pump Cover 1
40	95027-06020-00	Bolt, Flange
41	99510-08012-00	Pin, Dowel

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-15411-10-00	Cover, Crankcase 1
02	3VD-15451-00-00	Gasket, Crankcase Cover 1
03	99510-08012-00	Pin, Dowel
04	95027-06025-00	Bolt, Flange
05	90105-06456-00	Bolt, Washer Based
06	3LD-15418-00-00	Cover, Chain Case
07	95027-06025-00	Bolt, Flange
08	90465-08277-00	Clamp
09	3VD-15420-10-00	Crankcase Cover Assy 2
10	3VD-15326-00-00	• . Damper, Engine Mount 2
11	3VD-15335-00-00	• . Damper 3
12	95027-06055-00	Bolt, Flange
13	3VD-15430-10-00	Crankcase Cover Assy 3
14	3VD-15417-10-00	• . Cover, Cap
15	3LD-15449-00-00	• . Ring, Rubber
16	1JK-15486-00-00	• . Grommet
17	90209-05279-00	• . Washer
18	98507-05010-00	• . Screw, Pan Head
19	3VD-15462-00-00	Gasket, Crankcase Cover 3
20	95027-06025-00	Bolt, Flange
21	99510-08012-00	Pin, Dowel
22	3VD-15425-10-00	Cover, Generator 2
23	583-11126-00-00	Pipe, Breather 3
24	3VD-15463-00-00	Gasket, Carburetor Cover 2
25	95890-06035-00	Bolt, Flange
26	95027-06035-00	Bolt, Flange
27	90201-066F0-00	Washer, Plate
28	95027-06070-00	Bolt, Flange
29	99530-10014-00	Pin, Dowel
30	90465-26349-00	Clamp
31	90340-14141-00	Plug, Straight Screw
32	93210-14369-00	O-ring
33	90340-32142-00	Plug, Straight Screw
34	93210-32172-00	O-ring
35	90387-086W7-00	Collar
36	93210-10096-00	O-ring
37	90387-106W6-00	Collar
38	93210-12790-00	O-ring
39	90387-06761-00	Collar
40	93210-07438-00	O-ring
41	90387-130W6-00	Collar
42	93210-15566-00	O-ring
43	90465-20342-00	Clamp
44	3VD-15490-01-00	Cover Assy
45	3VD-21621-01-00	Flap
46	90338-06233-00	Plug
47	3KJ-15481-00-00	Bolt 1
48	90462-10147-00	Clamp
49	90465-06332-00	Clamp
50	95027-06030-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3LD-15515-00-00	Gear 3
02	3LD-15517-00-00	Gear, Idler 2
03	26H-15521-00-00	Shaft 1
04	3LD-15512-00-00	Gear, Idler 1
05	3LD-15590-01-00	Starter One-way Assy
06	91317-06018-00	Bolt
07	90201-301P3-00	Washer, Plate
08	3LD-81800-00-00	Starting Motor Assy
09	3AJ-81801-00-00	• . Brush Set
10	3AJ-81809-00-00	• . Washer Kit
11	3AJ-81830-00-00	• . Front Bracket Assy
12	3AJ-81826-00-00	• . Bolt
13	11H-81844-00-00	• . Gasket
14	26H-81847-00-00	• . O-ring
15	3LD-81815-00-00	• . Cord, Starter Motor
16	5H0-81871-00-00	•• .. Cap
17	95817-06050-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-16150-10-00	Primary Driven Gear Comp.
02	3LD-1637A-01-00	Rod Push Assy
03	93340-21505-00	Bearing
04	90201-150H2-00	Washer, Plate
05	4H7-16154-00-00	Plate, Thrust 1
06	3VD-16371-02-00	Boss, Clutch
07	168-16324-00-00	Plate, Clutch 1
08	4H7-16321-01-00	Plate, Friction
09	3LD-16351-00-00	Plate, Pressure 1
10	90501-225A9-00	Spring, Compression
11	90159-06123-00	Screw, With Washer
12	31A-16325-00-00	Plate, Clutch 2
13	90215-20231-00	Washer, Lock
14	90170-20327-00	Nut
15	3VD-16340-11-00	Push Lever Assy
16	90508-161A4-00	Spring, Torsion
17	3LD-16382-00-00	Axle, Push Lever
18	3LD-16398-00-00	Pinion, Releas
19	92907-08600-00	Washer, Plate
20	99080-07600-00	Circlip
21	93317-11020-00	Bearing
22	93102-12224-00	Oil Seal
23	90201-12M34-00	Washer, Plate
24	93315-11206-00	Bearing
25	90201-10119-00	Washer, Plate
26	99009-10400-00	Circlip
27	3VD-16164-00-00	Plate, Thrust 2
28	3VD-16154-00-00	Plate, Thrust 1
29	3LD-16181-00-00	Spacer 1
30	93310-365B8-00	Bearing

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-17411-00-00	Axle, Main
02	3VD-17151-00-00	Gear, 5th Pinion
03	90209-21332-00	Washer
04	93440-25084-00	Circlip
05	3VD-17131-10-00	Gear, 3rd Pinion
06	3VD-17141-01-00	Gear, 4th Pinion
07	3LD-17121-00-00	Gear, 2nd Pinion
08	93306-30525-00	Bearing
09	90387-252M6-00	Collar
10	90387-203M7-00	Collar
11	90201-200K3-00	Washer, Plate
12	3LD-15163-10-00	Housing, Bearing 1
13	93306-20464-00	Bearing
14	90149-06285-00	Screw
15	3VD-17402-00-00	Drive Axle Assy
16	3VD-17231-10-00	Gear, 3rd Wheel
17	3VD-17241-10-00	Gear, 4th Wheel
18	90209-28331-00	Washer
19	93440-31172-00	Circlip
20	3VD-17251-10-00	Gear, 5th Wheel
21	3VD-17211-00-00	Gear, 1st Wheel
22	93102-35381-00	Oil Seal
23	3VD-17460-00-00	Sprocket, Drive
24	90215-21022-00	Washer, Lock
25	90179-18020-00	Nut
26	93306-20455-00	Bearing
27	93440-45144-00	Circlip
28	3LD-17471-01-00	Plate, Cover
29	95827-06012-00	Bolt, Flange
30	3LD-15414-00-00	Cover, Air Cleaner
31	93210-33133-00	O-ring
32	90209-29329-00	Washer
33	90209-28330-00	Washer
34	90387-2802W-00	Collar
35	90201-20278-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-18540-00-00	Shift Cam Assy
02	98701-05012-00	• . Screw, Flat Head
03	278-18542-00-00	• . Point, Neutral
04	90501-06022-00	• . Spring, Compression
05	278-18566-00-00	• . Plate, Side 2
06	90105-06597-00	Bolt, Washer Based
07	90105-06397-00	Bolt, Washer Based
08	3VD-18511-00-00	Fork, Shift 1
09	3VD-18512-00-00	Fork, Shift 2
10	3VD-18513-00-00	Fork, Shift 3
11	3VD-18531-00-00	Bar, Shift Fork Guide 1
12	3VD-18535-00-00	Bar, Shift Fork Guide 2
13	90501-071F1-00	Spring, Compression
14	3LD-18536-00-00	Stopper, Shift Bar
15	90508-265A4-00	Spring, Torsion
16	36Y-18140-00-00	Stopper Lever Assy
17	90109-063F8-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3LD-18101-02-00	Shift Shaft Assy
02	90508-32682-00	• . Spring, Torsion
03	90201-191J4-00	• . Washer, Plate
04	99009-19400-00	• . Circlip
05	90201-12575-00	Washer, Plate
06	99006-10600-00	Circlip
07	3LD-18130-00-00	Shift Shaft Assy
08	2H9-18154-00-00	• . Cover, Dust
09	95827-06020-00	Bolt, Flange
10	3VD-18115-00-00	Rod, Shift
11	90170-06228-00	Nut
12	95304-06700-00	Nut
13	3VD-18110-10-00	Shift Pedal Assy
14	2H9-18154-00-00	• . Cover, Dust
15	132-18113-01-00	• . Cover, Shift Pedal
16	2YK-27434-01-00	Bolt
17	90206-12074-00	Washer, Wave
18	90201-08326-00	Washer, Plate
19	4G0-18127-00-00	Stopper, Screw
20	93120-12106-00	Oil Seal

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-21110-30-T9	Frame Comp.
02	3VD-21411-10-T9	Bracket, Engine 1
03	3VD-21419-10-T9	Bracket, Engine 2
04	90109-082A1-00	Bolt
05	91317-10045-00	Bolt
06	91317-10030-00	Bolt
07	90201-100F7-00	Washer, Plate
08	90110-10299-00	Bolt, Hexagon Socket Head
09	90179-10377-00	Nut
10	3VD-21489-00-00	Bracket, Engine Lower
11	95827-08020-00	Bolt, Flange
12	90105-10328-00	Bolt, Washer Based
13	3SX-2135F-00-00	Cover
14	3LD-2143A-00-00	Cap
15	3VD-24188-00-00	Mold, Fuel Tank
16	3VD-2143A-00-00	Cap
17	3VD-21164-00-00	Holder, Cable
18	95807-06010-00	Bolt, Flange
19	34M-21639-00-00	Damper 2
20	5H0-8235Y-M0-00	Damper
21	3VD-15491-00-00	Protector
22	90480-15397-00	Grommet
23	3VD-15764-00-00	Collar 1
24	3VD-15659-00-00	Shaft
25	3VD-15327-00-00	Spacer, Engine Mount
26	90201-08326-00	Washer, Plate
27	90480-14023-00	Grommet
28	90387-07391-00	Collar
29	97707-06025-00	Screw, Tapping
30	91401-25020-00	Pin, Cotter
31	10V-25188-00-00	Cap
32	90465-08252-00	Clamp
33	3VD-21717-00-00	Damper

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-Y2151-00-MV	Front Fender Comp.
01	3VD-Y2151-00-P2	Front Fender Comp.
01	3VD-Y2151-00-P5	Front Fender Comp.
02	3GM-21512-00-00	• . Bracket, Fender
03	90267-32071-00	• . Rivet, Blind
04	90387-0702E-00	• . Collar
05	1A8-21518-00-00	• . Holder, Cable
06	90105-06605-00	Bolt, Washer Based
07	3VD-Y2161-60-00	Rear Fender Comp.
08	90480-10258-00	• . Grommet
09	3VD-21366-00-00	• . Hook, Tool Band
10	90267-40073-00	• . Rivet, Blind
11	92907-04200-00	• . Washer
12	95807-06016-00	Bolt, Flange
13	90387-07717-00	Collar
14	90183-06023-00	Nut, Spring
15	4G0-21639-00-00	Damper 2
16	3VD-W247K-A0-P2	Cover, Tail Assy
16	3VD-W247K-B0-P5	Cover, Tail Assy
16	3VD-W247K-C0-MV	Cover, Tail Assy
17	3VD-2173E-50-00	• . Graphic 1
17	3VD-2173E-60-00	• . Graphic 1
17	3VD-2173E-70-00	• . Graphic 1
18	99234-00080-00	• . Emblem, Yamaha
18	99236-00080-00	• . Emblem, Yamaha
19	3VD-2173F-50-00	• . Graphic 2
19	3VD-2173F-60-00	• . Graphic 2
19	3VD-2173F-70-00	• . Graphic 2
20	90183-08065-00	• . Nut, Spring
21	98907-05012-00	• . Screw, Bind
22	90183-05024-00	• . Nut, Spring
23	2YK-21747-00-00	• . Damper
24	1AE-2837J-00-00	• . Damper 5
25	3VD-21652-00-00	• . Protector
26	97707-50012-00	Screw, Tapping
27	90480-12550-00	Grommet
28	3VD-21645-00-MV	Stay, Rear
28	3VD-21645-00-P2	Stay, Rear
28	3VD-21645-00-P5	Stay, Rear
29	97027-08035-00	Bolt
30	92907-08600-00	Washer, Plate
31	3VD-2117E-00-00	Bracket, Taillight
32	J44-78248-00-00	Seal 4
33	95827-08016-00	Bolt, Flange
34	3LD-21621-01-00	Flap
35	90149-04278-00	Screw
36	95607-04100-00	Nut, U
37	90201-047A2-00	Washer, Plate
38	3VD-28100-00-00	Tool Kit
39	3YX-21376-00-00	Band, Tool

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-22535-00-00	Stay, Battery 1
02	90464-11163-00	Clamp
03	95807-06012-00	Bolt, Flange
04	90480-16233-00	Grommet
05	90480-01401-00	Grommet
06	3VD-2177G-00-00	Box, Battery
07	95807-06012-00	Bolt, Flange
08	90209-07319-00	Washer
09	3VD-21750-01-00	Oil Tank Assy
10	3VD-21761-00-00	Gauge, Level
11	93210-21190-00	O-ring
12	3VD-2312F-00-00	Hose, Breather
13	90467-10008-00	Clip
14	90119-06096-00	Bolt, With Washer
15	90387-060A7-00	Collar
16	90480-16233-00	Grommet
17	3VD-21871-00-00	Tank, Recovery
18	90119-06056-00	Bolt, With Washer
19	1AA-21815-00-00	Cap
20	1AA-21874-00-00	• . Gasket
21	90445-095E9-00	Hose
22	90467-08017-00	Clip
23	3VD-21816-00-00	Pipe 1
24	97007-06025-00	Bolt
25	90201-063J2-00	Washer, Plate
26	90560-07007-00	Spacer
27	90480-16404-00	Grommet

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	3VD-22110-00-00	Rear Arm Comp.
02	33M-22184-00-00	Bush
03	93320-32403-00	Bearing
04	4X7-22129-00-00	Cover, Thrust 2
05	90201-161J3-00	Washer, Plate
06	46X-22141-00-00	Shaft, Pivot
07	90185-14070-00	Nut, Self-locking
08	3VD-22311-00-00	Case, Chain
09	90119-06044-00	Bolt, With Washer
10	3VD-22151-00-00	Seal, Guard
11	90387-06681-00	Collar
12	90119-06108-00	Bolt, With Washer
13	3VD-25875-01-00	Holder, Brake Hose 1
14	90387-064J1-00	Collar
15	97007-06025-00	Bolt
16	92907-06600-00	Washer, Plate
17	3VD-W2165-00-00	Cover, Rear Fender
18	3VD-2164F-00-00	• . Stay 1
19	90267-40105-00	• . Rivet, Blind

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-22210-30-00	Shock Absorber Assy, Rear
02	3VD-22216-00-00	• . Bush, Rear Shock Absorber
03	90384-18190-00	• . Bush, Bimetal Formed
04	90387-127X0-00	• . Collar
05	93109-18020-00	• . Oil Seal
06	90109-125F1-00	Bolt
07	95607-12100-00	Nut, U
08	90101-10659-00	Bolt
09	90201-124G9-00	Washer, Plate
10	95607-10100-00	Nut, U
11	3VD-22464-00-00	Knob, Control

END


3VD1351-1230

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	93332-00001-00	Bearing
02	93332-00008-00	Bearing
03	3HE-23416-00-00	Cover, Ball Race 2
04	90179-25033-00	Nut
05	90202-26142-00	Washer, Plate
06	26H-23418-01-00	Washer, Special
07	90176-22050-00	Nut, Crown
08	3VD-Y2343-10-00	Crown, Handle
09	3VD-23434-00-00	• . Holder, Damper
10	91317-08030-00	• . Bolt
11	4H7-23441-00-38	Holder, Handle Upper
12	42X-23442-00-38	Holder, Handle Lower
13	3VD-23389-00-00	Guide, Cable
14	90201-100A1-00	Washer, Plate
15	92907-10100-00	Washer, Spring
16	95307-10700-00	Nut
17	90468-12006-00	Clip
18	91317-08030-00	Bolt
19	90338-08163-00	Plug

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-23102-01-00	Front Fork Assy (l.h)
02	3VD-23106-00-00	• . Outer Tube Comp. (l.h)
03	5U8-23129-00-00	•• .. Gasket, Drain Plug
04	98501-04006-00	•• .. Screw, Pan Head
05	3VD-23110-00-00	• . Inner Tube Comp.1
06	3VD-23135-00-00	•• .. Metal, Slide 2
07	3VD-2330E-00-00	• . Damper Assy
08	3VD-2312K-00-00	•• .. Piston, Front Fork
09	3VD-23111-00-00	• . Bolt, Cap
10	93210-09350-00	•• .. O-ring
11	93503-16010-00	•• .. Ball
12	3VD-23183-00-00	•• .. Circlip
13	93210-18N01-00	•• .. O-ring
14	3VD-2319U-00-00	•• .. Cap
15	93210-35N02-00	• . O-ring
16	3VD-23173-00-00	• . Spindle, Taper
17	90430-10171-00	• . Gasket
18	91311-10025-00	• . Bolt
19	3VD-23125-01-00	• . Metal, Slide 1
20	3VD-23115-00-00	• . Seat 1
21	3VD-23156-00-00	• . Clip, Oil Seal
22	3VD-23144-00-00	• . Seal, Dust
23	3GM-23145-A0-00	• . Oil Seal
24	3VD-23141-01-00	• . Spring, Front Fork
25	3VD-23142-00-00	• . Seat, Spring Upper
26	3VD-2318Y-00-00	• . Plunger
27	3VD-23103-01-00	Front Fork Assy (r.h)
28	3VD-23107-00-00	• . Outer Tube Comp. (r.h)
29	5U8-23129-00-00	•• .. Gasket, Drain Plug
30	98501-04006-00	•• .. Screw, Pan Head
31	3VD-23110-00-00	• . Inner Tube Comp.1
32	3VD-23135-00-00	•• .. Metal, Slide 2
33	3VD-2330E-00-00	• . Damper Assy
34	3VD-2312K-00-00	•• .. Piston, Front Fork
35	3VD-23111-00-00	• . Bolt, Cap
36	93210-09350-00	•• .. O-ring
37	93503-16010-00	•• .. Ball
38	3VD-23183-00-00	•• .. Circlip
39	93210-18N01-00	•• .. O-ring
40	3VD-2319U-00-00	•• .. Cap
41	93210-35N02-00	• . O-ring
42	3VD-23173-00-00	• . Spindle, Taper
43	90430-10171-00	• . Gasket
44	91311-10025-00	• . Bolt
45	3VD-23125-01-00	• . Metal, Slide 1
46	3VD-23115-00-00	• . Seat 1
47	3VD-23156-00-00	• . Clip, Oil Seal
48	3VD-23144-00-00	• . Seal, Dust
49	3GM-23145-A0-00	• . Oil Seal
50	3VD-23141-01-00	• . Spring, Front Fork
51	3VD-23142-00-00	• . Seat, Spring Upper
52	3VD-2318Y-00-00	• . Plunger
53	91311-08040-00	• . Bolt
54	3VD-23340-00-00	Under Bracket Comp.

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
55	95817-08035-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-24110-30-08	Fuel Tank Comp.
01	3VD-24110-30-09	Fuel Tank Comp.
01	3VD-24110-30-X1	Fuel Tank Comp.
02	3VD-24240-90-00	• . Graphic Set
02	3VD-24240-A0-00	• . Graphic Set
02	3VD-24240-B0-00	• . Graphic Set
03	99224-00120-00	• . Emblem, Yamaha
03	99226-00120-00	• . Emblem, Yamaha
04	3VD-24191-00-00	Bracket, Fuel Tank 1
05	3VD-24181-00-00	Damper, Locating 1
06	47X-24183-00-00	Damper, Locating 3
07	47X-24186-00-00	Washer, Special
08	90387-060N3-00	Collar
09	95807-06035-00	Bolt, Flange
10	90109-086A0-00	Bolt
11	2GH-24184-00-00	Damper, Locating 4
12	3Y6-24183-00-00	Damper, Locating 3
13	12R-24186-00-00	Washer, Special
14	97007-08030-00	Bolt
15	3VD-24560-00-00	Filter Assy
16	4X8-24512-00-00	• . Gasket
17	90149-06011-00	Screw
18	90202-05187-00	Washer, Plate
19	3VD-24311-00-00	Pipe, Fuel 1
20	3VD-24313-00-00	Pipe 3
21	1JK-24327-00-00	Protector, Pipe
22	90467-10135-00	Clip
23	3LN-24500-00-00	Fuel Cock Assy 1
24	3AJ-24523-00-00	• . Valve
25	3AJ-24534-00-00	• . Seal, Cock
26	95027-06010-00	Bolt, Flange
27	90445-112H2-00	Hose
28	90501-085G0-00	Spring, Compression
29	3VD-24327-00-00	Protector, Pipe
30	90467-10135-00	Clip
31	4HN-24602-00-00	Cap Assy
32	90110-05112-00	Bolt, Hexagon Socket Head
33	91317-05010-00	Bolt
34	90445-105G5-00	Hose
35	90467-09006-00	Clip
36	3VD-24339-00-00	Grommet
37	1HX-24188-01-00	Mold, Fuel Tank
38	51L-28371-00-00	Damper
39	J44-78248-00-00	Seal 4
40	3LD-13910-00-00	Fuel Pump Assy
41	95707-05500-00	Nut, Flange
42	3VD-13929-00-00	Pipe, Impulse
43	90467-08017-00	Clip
44	90467-08021-00	Clip
45	3VD-14294-00-00	Hose
46	90467-11106-00	Clip
47	90467-10091-00	Clip
48	90445-11153-00	Hose
49	4X7-2149Y-00-00	Filter Assy

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
50	90445-112E1-00	Hose
51	90467-11106-00	Clip
52	90467-10008-00	Clip
53	90445-104H3-00	Hose
54	90467-09006-00	Clip


Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



3VD7351-4270


Ref No	Part No	Description
01	3VD-24730-30-00	Double Seat Assy
01	3VD-24730-50-00	Double Seat Assy
02	3VD-2470F-20-00	• . Seat Cover Comp.
02	3VD-2470F-50-00	• . Seat Cover Comp.
03	3VD-24776-00-00	• . Lever, Seat
04	1JK-2478F-00-00	• . Rod, Connecting
05	3VD-24728-00-00	• . Bracket, Seat
06	3VD-24718-00-00	• . Bracket, Seat
07	95707-06500-00	• . Nut, Flange
08	1T4-24741-00-00	• . Pad, Seat
09	1L9-24741-00-00	• . Pad, Seat
10	116-24741-00-00	• . Pad, Seat
11	22W-24741-00-00	• . Pad, Seat
12	4BH-24705-00-00	Seat Lock Assy
13	95707-05500-00	Nut, Flange
14	1AE-24796-00-00	Cover

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-25168-00-7B	Cast Wheel, Front
01	3VD-25168-00-WG	Cast Wheel, Front
02	90560-17233-00	Spacer
03	93306-30309-00	Bearing
04	93102-28022-00	Oil Seal
05	341-25149-00-00	Clutch, Meter
06	341-25846-00-00	Retainer, Clutch
07	93105-45017-00	Oil Seal
08	94111-186X9-00	Tire
08	94111-187X0-00	Tire
10	93900-00030-00	Valve, Rim
11	29L-25398-00-00	Balancer, Wheel
11	29L-25398-10-00	Balancer, Wheel
11	29L-25398-20-00	Balancer, Wheel
12	1FK-25190-00-00	Gear Unit Assy
13	3GM-25181-00-00	Axle, Wheel
14	90387-177R1-00	Collar

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3RG-2581T-00-00	Disc Brake Assy
02	90109-08718-00	Bolt
03	3XW-2580T-00-00	Caliper Assy (left)
04	1NL-W0057-00-00	• . Piston Assy, Caliper
05	1NL-W0047-00-00	•• .. Caliper Seal Kit
06	2GH-W0045-01-00	• . Brake Pad Kit
07	3HE-25924-00-00	• . Pin, Pad
08	3GM-25925-00-00	• . Clip
09	2GH-25919-00-00	• . Support, Pad
10	1J3-W0048-00-00	• . Bleed Screw Kit
11	1KT-25386-00-00	• . Collar, Sprocket Axle
12	3XW-2580U-00-00	Caliper Assy (right)
13	1NL-W0057-00-00	• . Piston Assy, Caliper
14	1NL-W0047-00-00	•• .. Caliper Seal Kit
15	2GH-W0045-01-00	• . Brake Pad Kit
16	3HE-25924-00-00	Pin, Pad
17	3GM-25925-00-00	• . Clip
18	2GH-25919-00-00	• . Support, Pad
19	1J3-W0048-00-00	• . Bleed Screw Kit
20	1KT-25386-00-00	• . Collar, Sprocket Axle
21	90105-10638-00	Bolt, Washer Based

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-25338-00-7B	Cast Wheel, Rear
01	3VD-25338-00-WG	Cast Wheel, Rear
02	93306-30309-00	Bearing
03	93306-20314-00	Bearing
04	93102-25044-00	Oil Seal
05	90387-173M5-00	Collar
06	3VD-25364-10-00	Damper
07	93306-20314-00	Bearing
08	94115-176X7-00	Tire
08	94115-176X8-00	Tire
09	92900-00030-00	Washer
10	29L-25398-00-00	Balancer, Wheel
10	29L-25398-10-00	Balancer, Wheel
10	29L-25398-20-00	Balancer, Wheel
11	1UF-25366-00-00	Clutch, Hub
12	93306-37207-00	Bearing
13	93105-42024-00	Oil Seal
14	3VD-25444-20-00	Sprocket, Driven
15	90116-10485-00	Bolt, Stud
16	95607-10200-00	Nut, Self-locking
17	90387-177K0-00	Collar
18	94581-46114-00	Chain
19	4BP-25388-00-00	Puller, Chain 1
20	92907-08200-00	Washer
21	95307-08600-00	Nut
22	3HE-22174-00-00	End 1
23	1AE-25381-00-00	Axle, Wheel
24	90201-177K7-00	Washer, Plate
25	90387-177Y5-00	Collar
26	90387-177Y4-00	Collar
27	90171-16024-00	Nut, Castle
28	90201-165L8-00	Washer, Plate
29	91401-30030-00	Pin, Cotter

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4DU-2582W-00-00	Disc, Rear Brake 2
02	90109-08718-00	Bolt
03	3HE-2580W-00-00	Caliper Assy, Rear 2
04	31A-W0057-00-00	• . Piston Assy, Caliper
05	31A-W0047-00-00	•• .. Caliper Seal Kit
06	1FK-W0046-01-00	• . Brake Pad Kit 2
07	1WG-25919-00-00	• . Support, Pad
08	3HE-25924-00-00	• . Pin, Pad
09	3GM-25925-00-00	• . Clip
10	1J3-W0048-00-00	• . Bleed Screw Kit
11	51J-25386-00-00	• . Collar, Sprocket Axle
12	1FK-25827-00-00	• . Shim, Caliper
13	1FK-25828-00-00	• . Shim, Caliper
14	3VD-25819-00-00	Bracket, Caliper
15	90105-10638-00	Bolt, Washer Based
16	95827-10030-00	Bolt, Flange
17	90201-10437-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-26111-10-00	Handlebar
02	1KG-26241-00-00	Grip
03	3FH-26240-00-00	Grip Assy
04	3VD-26246-00-00	End, Grip
05	90387-22660-00	Collar
06	3VD-26302-00-00	Throttle Cable Assy
07	3XW-26281-01-00	Cap, Grip Upper
08	3XW-26282-01-00	Cap, Grip Lower
09	98507-05035-00	Screw, Pan Head
10	3VD-26331-00-00	Cable, Starter 1
11	1VJ-26333-00-00	Nut
12	3VD-26335-10-00	Cable, Clutch
13	3VD-26292-00-00	Stay
14	95807-06012-00	Bolt, Flange
15	3VD-26280-01-00	Rear View Mirror Assy(left)
16	3VD-26290-01-00	Rear View Mirror Assy (right)

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	4KM-W2587-00-00	Master Cylinder Sub Assy
02	4BH-W0041-00-00	• . Cylinder Kit, Master
03	3YX-25854-00-00	• . Diaphragm, Reservoir
04	3YX-25852-00-00	• . Cap, Reservoir
05	98707-04012-00	• . Screw, Flat Head
06	4BH-83980-00-00	• . Front Stop Switch Assy
07	98506-04012-00	• . Screw, Pan Head
08	92906-04600-00	• . Washer, Plate
09	3YX-25880-00-00	• . Push Rod Comp.
10	95380-06600-00	• . Nut, Hexagon
11	3YX-W0091-02-00	Screw Kit, Master Cylinder
12	3YX-25866-00-00	• . Circlip
13	3YX-25866-10-00	• . Circlip
14	3YX-2583H-00-00	• . Boot
15	3YX-25867-00-00	Bracket, Master Cylinder
16	3YX-83922-09-00	Lever 2
17	3YX-2589F-00-00	Bolt, Lever
18	3YX-25838-00-00	Sleeve, Caliper
19	95617-06100-00	Nut, U
20	95027-06030-00	Bolt, Flange
21	3VD-25872-01-00	Hose, Brake 1
22	3VD-25874-00-00	Hose, Brake
23	90401-10159-00	Bolt, Union
24	90401-10160-00	Bolt, Union
25	90201-10118-00	Washer, Plate
26	3VD-25384-01-00	Washer, Wheel
27	3VD-25844-00-00	Washer, Lock
28	42H-25885-01-00	Joint
29	91317-06025-00	Bolt
30	3VD-26131-00-00	Guide, Cable 1
31	3VD-26132-00-00	Guide, Cable 2
32	3EN-25875-00-00	Holder, Brake Hose 1
32	3EN-25875-01-00	Holder, Brake Hose 1
33	2R8-25876-00-00	Holder, Brake Hose 2
33	2R8-25876-01-00	Holder, Brake Hose 2
34	95027-06025-00	Bolt, Flange
35	3VD-23317-00-00	Holder, Cable

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	1UA-27410-00-00	Front Footrest Assy (left)
02	2GH-27413-00-00	• . Cover, Footrest
03	90157-05079-00	• . Screw, Pan Head
04	1UA-27420-00-00	Front Footrest Assy (right)
05	2GH-27413-00-00	• . Cover, Footrest
06	90157-05079-00	• . Screw, Pan Head
07	90109-083E2-00	Bolt
08	90109-083E2-00	Bolt
09	3VD-27442-10-00	Bracket 2
10	3VD-27443-10-00	Bracket 3
11	90179-10247-00	Nut
12	90110-08071-00	Bolt, Hexagon Socket Head
13	1NL-27424-00-00	Damper, Footrest 2
14	90209-08295-00	Washer
15	3VD-27414-00-00	Damper, Footrest
16	4VD-27311-01-00	Stand, Side
17	90109-104E6-00	Bolt
18	90185-10037-00	Nut, Self-locking
19	90506-18224-00	Spring, Tension
20	90506-26225-00	Spring, Tension
21	1TX-27351-00-00	Guide, Side Stand
22	3VD-27315-00-00	Link, Side Stand
23	2GH-27431-00-00	Footrest, Rear 1
24	2GH-27441-00-00	Footrest, Rear 2
25	90501-12743-00	Spring, Compression
26	93501-04011-00	Ball
27	1HX-27437-00-00	Washer, Special
28	91701-06040-00	Pin, Clevis
29	91490-20020-00	Pin, Cotter
30	90387-064H8-00	Collar
31	2GH-27413-00-00	Cover, Footrest
32	90157-05079-00	Screw, Pan Head
33	3VD-27412-10-00	Bracket, Footrest 1
34	3VD-27422-10-00	Bracket, Footrest 2
35	90380-20213-00	Bush, Solid
36	90110-08199-00	Bolt, Hexagon Socket Head
37	36Y-27424-00-00	Damper, Footrest 2
38	90387-104L8-00	Collar
39	90201-10669-00	Washer, Plate
40	3VD-2139X-00-00	Damper

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-27211-00-00	Pedal, Brake
02	3VD-27212-00-00	Shaft, Brake Pedal
03	22N-18113-00-00	Cover, Shift Pedal
04	90101-06278-00	Bolt
05	92907-06100-00	Washer, Spring
06	90506-20192-00	Spring, Tension
07	3VD-2583V-00-00	Rr. Master Cylinder Assy.
08	3VD-W0042-50-00	• . Cylinder Kit, Master
09	3LN-2582A-00-00	• . Joint
10	3LN-2585F-00-00	• . O-ring
11	3LN-2585H-00-00	• . Screw,set
12	92017-08030-00	Bolt, Button Head
13	47X-27222-00-00	Joint
14	95307-08700-00	Nut
15	90240-08013-00	Pin, Clevis
16	90201-08083-00	Washer, Plate
17	91490-20020-00	Pin, Cotter
18	47X-25894-00-00	Tank, Reservoir
19	360-25854-00-00	Diaphragm, Reservoir
20	2GU-25855-00-00	Bush,diaphragm
21	2KF-25852-00-00	Cap, Reservoir
22	90159-06056-00	Screw, With Washer
23	3VD-2582E-01-00	Holder, Reserve Tank
24	95807-06010-00	Bolt, Flange
25	3VD-25895-00-00	Hose, Reservoir
26	90467-14057-00	Clip
27	3VD-25872-51-00	Hose, Brake 1
28	90401-10159-00	Bolt, Union
29	3LC-25885-00-00	Joint
30	90201-10118-00	Washer, Plate

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-28350-00-MV	Cowling Assy
01	3VD-28350-00-P2	Cowling Assy
01	3VD-28350-00-P5	Cowling Assy
02	3VD-28390-90-00	Graphic Set, Cowling
02	3VD-28390-A0-00	Graphic Set, Cowling
02	3VD-28390-B0-00	Graphic Set, Cowling
03	99234-00100-00	Emblem, Yamaha
03	99236-00100-00	Emblem, Yamaha
04	3VD-28328-51-00	Emblem
04	3VD-28328-71-00	Emblem
04	4VD-28328-61-00	Emblem
05	3VD-28338-50-00	Emblem
05	3VD-28338-60-00	Emblem
05	3VD-28338-70-00	Emblem
06	3VD-28381-00-00	Windshield
07	90149-05273-00	Screw
08	3HX-28215-00-00	Washer, Special
09	95707-05500-00	Nut, Flange
10	95807-06012-00	Bolt, Flange
11	90387-072Y3-00	Collar
12	90110-05201-00	Bolt, Hexagon Socket Head
13	90202-05180-00	Washer, Plate
14	90202-08111-00	Washer, Plate
15	90149-05244-00	Screw
16	90179-05525-00	Nut
17	90201-05660-00	Washer, Plate
18	3VD-2837M-00-00	Panel, Console 2
19	90110-05201-00	Bolt, Hexagon Socket Head
20	3VD-28356-00-00	Stay 1
21	2TV-21638-00-00	Damper 1
22	91317-08035-00	Bolt
23	95807-08012-00	Bolt, Flange
24	90480-14229-00	Grommet
25	3VD-28365-00-00	Cover
26	90179-06500-00	Nut
27	3VD-2835U-00-MV	Panel 1
27	3VD-2835U-00-P2	Panel 1
27	3VD-2835U-00-P5	Panel 1
28	90149-05299-00	Screw
29	3VD-2835V-00-MV	Panel 2
29	3VD-2835V-00-P2	Panel 2
29	3VD-2835V-00-P5	Panel 2
30	90179-05523-00	Nut
31	90202-05180-00	Washer, Plate
32	3VD-28322-00-00	Stay 2
33	5H0-8235Y-M0-00	Damper
34	95807-08012-00	Bolt, Flange
35	3VD-2837N-00-00	Grill, Air Intake 1
36	3VD-2837R-00-00	Grill, Air Intake 2
37	97007-50012-00	Bolt
38	3VD-28371-00-00	Damper
39	2TV-21638-00-00	Damper 1

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3LD-81410-00-00	Stator Assy
02	3VD-81450-00-00	Rotor Assy
03	98507-06030-00	Screw, Pan Head
04	92907-06100-00	Washer, Spring
05	98507-05016-00	Screw, Pan Head
06	92907-05100-00	Washer, Spring

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3GM-83310-00-00	Front Flasher Light Assy 1
02	306-83311-40-00	• . Bulb, Flasher
03	51L-83332-01-00	• . Lens, Flasher
04	97707-40620-00	• . Screw, Tapping
05	3GM-83320-00-00	Front Flasher Light Assy 2
06	306-83311-40-00	• . Bulb, Flasher
07	51L-83342-01-00	• . Lens, Flasher 2
08	97707-40620-00	• . Screw, Tapping
09	3VD-83330-00-00	Rear Flasher Light Assy 1
10	1VU-83332-00-00	• . Lens, Flasher
11	306-83311-40-00	• . Bulb, Flasher
12	97707-40620-00	• . Screw, Tapping
13	3VD-83340-00-00	Flasher Light Assy 2
14	1VU-83342-00-00	• . Lens, Flasher 2
15	306-83311-40-00	• . Bulb, Flasher
16	97707-40620-00	• . Screw, Tapping
17	95307-12600-00	Nut
18	18G-83365-00-00	Cap

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-83570-00-00	Speedometer Assy
02	3VD-83540-00-00	Tachometer Assy
03	3GM-83590-00-00	Water Temperature Assy
04	3VD-83559-00-00	Cover, Meter
05	3VD-8353H-00-00	Case, Under
06	2GH-83578-00-00	Knob, Trip Meter
07	3VD-83509-00-00	Socket Cord Assy
08	4G1-84744-00-00	Bulb (12v-5w)
09	4G1-84744-00-00	Bulb (12v-5w)
10	42X-83517-00-00	Bulb
11	98507-05010-00	Screw, Pan Head
12	92907-04100-00	Washer, Spring
13	92907-04600-00	Washer
14	90167-04057-00	Screw, Tapping
15	98507-03100-00	Screw, Pan Head
16	92907-03100-00	Washer
17	90159-03102-00	Screw, With Washer
18	90164-04008-00	Screw, Tapping
19	90167-03058-00	Screw, Tapping
20	4FM-83520-00-00	Socket Cord Assy
21	3VD-83513-10-00	Damper
22	3VD-83611-00-00	Panel, Meter
23	3GM-83525-00-00	Clip
24	90480-14229-00	Grommet
25	90387-07391-00	Collar
26	95307-06600-00	Nut
27	90201-06059-00	Washer, Plate
28	1FK-83550-10-00	Speedometer Cable Assy

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-84330-00-00	Body Assy
02	3VD-84320-10-00	Lens Assy
03	3VD-8432A-00-00	Lens Assy
05	2LA-84375-00-00	Fitting Plate, Bulb
06	2LA-84393-00-00	Holder, Bulb
07	2GH-84397-00-00	Cover, Socket
08	2F9-84314-00-00	Bulb, Headlight
09	2F9-84375-00-00	Fitting Plate, Bulb
10	3SX-84397-00-00	Cover, Socket
11	3AJ-8431U-00-00	Holder
12	51L-84334-00-00	Nut, Adjusting
13	2AX-84331-00-00	Screw, Rim Adjusting
14	3MA-8430M-00-00	Gear Unit Assy
15	97707-40616-00	Screw, Tapping
16	3GM-84344-00-00	Washer, Plain
17	3HE-84366-00-00	Damper, Headlight 1
18	3VD-84359-00-00	Cord, Headlight
19	3GM-84301-00-00	Pilot Light Assy 1
20	3GM-84321-00-00	• . Lens Assy
21	3GM-84322-00-00	• . Gasket, Lens
22	2JE-84744-00-00	• . Bulb (12v-5w)
23	3GM-84192-00-00	• . Screw, Special
24	97007-50012-00	Bolt
25	3GM-8431R-00-00	Stay, Setting
26	90480-10517-00	Grommet
27	90387-052U5-00	Collar
28	90167-05037-00	Screw, Tapping
29	3GM-84367-10-00	Damper, Headlight 2
30	2LA-84397-00-00	Cover, Socket
31	2LA-84397-10-00	Cover, Socket

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3GM-84710-20-00	Taillight Unit Assy
02	31L-84714-00-00	• . Bulb
03	3LK-8473A-00-00	• . Cord Assy
04	90480-18276-00	Grommet
05	90201-063J2-00	Washer, Plate
06	90387-062W4-00	Collar
07	95307-06600-00	Nut
08	90480-15259-00	Grommet
09	90201-105J4-00	Washer, Plate
10	3YF-84751-00-00	Bracket, License
11	90387-07717-00	Collar
12	95607-06100-00	Nut, U
13	3G1-85130-01-00	Rear Reflector Assy
14	95707-05500-00	Nut, Flange
15	95027-06016-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.




Ref No	Part No	Description
01	3VD-83975-00-00	Switch, Handle 2
02	90157-05057-00	• . Screw, Pan Head
03	3VD-83969-01-00	Switch, Handle 5
04	98507-05030-00	• . Screw, Pan Head
05	98507-05040-00	• . Screw, Pan Head
06	437-83936-01-00	Band, Switch Cord
07	90464-13080-00	Clamp
08	3YX-82911-00-00	Holder, Lever 1
09	3YX-83912-00-00	Lever 1
10	3YX-82917-00-00	Switch
11	90123-08046-00	Bolt
12	90179-08316-00	Nut
13	3YX-83945-00-00	Bolt, Lever
14	95607-06100-00	Nut, U
15	98707-03020-00	Screw, Flat Head
16	95027-06020-00	Bolt, Flange

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	3VD-82305-00-00	Ignitor Unit Assy
02	98507-06016-00	Screw, Pan Head
03	92907-06600-00	Washer, Plate
04	90183-06023-00	Nut, Spring
05	3VD-82310-00-00	Ignition Coil Assy
06	95807-06020-00	Bolt, Flange
07	25G-83936-01-00	Band, Switch Cord
08	3LD-82370-00-00	Plug Cap Assy
09	3VD-82100-00-00	Battery Assy
10	3VD-82131-00-00	Band, Battery
11	3Y6-21747-00-00	Damper
12	3VD-82115-00-00	Wire, Plus Lead
13	3VD-82116-00-00	Wire, Minus Lead
14	3VD-82530-01-00	Stop Switch Assy
15	3VD-82590-10-00	Wire Harness Assy
16	1AE-82151-00-00	• . Fuse
17	2GH-82151-00-00	• . Fuse
18	42X-82151-00-00	• . Fuse
19	90464-13073-00	Clamp
20	90464-12027-00	Clamp
21	98907-06012-00	Screw, Bind
22	90464-13080-00	Clamp
23	3VD-81960-00-00	Rectifier & Regulator Assy
24	90109-076E6-00	Bolt
25	3VD-82501-11-00	Main Switch Steering Lock
26	90109-080G5-00	Bolt

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.



Ref No	Part No	Description
01	1AE-82540-00-00	Neutral Switch Assy
02	93210-29196-00	O-ring
03	98507-06016-00	Screw, Pan Head
04	3LD-82541-00-00	Wire, Lead
05	3LN-82560-00-00	Thermo Switch Assy
06	11H-83591-00-00	Thermo Unit
07	26H-83354-00-00	Wire, Earth Lead 1
08	98507-04008-00	Screw, Pan Head
09	92907-04100-00	Washer, Spring
10	92907-04600-00	Washer
11	3Y1-83350-00-00	Flasher Relay Assy
11	3YA-83350-10-00	Flasher Relay Assy
12	3HE-83371-00-00	Horn
13	3VD-2317E-00-00	Stay
14	95807-06010-00	Bolt, Flange
15	36Y-81940-00-00	Starter Relay Assy
16	95707-06500-00	Nut, Flange
17	2UJ-81950-00-00	Relay Assy
18	3LD-82566-50-00	Switch, Side Stand
19	90157-05079-00	Screw, Pan Head
20	90464-13080-00	Clamp

Copyright © 2004 Yamaha Motor Distribution B.V. All Rights Reserved.